



Manuals.plus /

› Armitron /

› Armitron Men's 204692BKTI Black Plated Stainless-Steel and Black Dial Dress Watch Instruction Manual

Armitron 20/4692BKTI

Armitron Men's 204692BKTI Dress Watch Instruction Manual

Model: 20/4692BKTI

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Armitron Men's 204692BKTI Black Plated Stainless-Steel and Black Dial Dress Watch. This timepiece combines sophisticated design with reliable Japanese quartz movement, offering both style and precision. Its durable construction, including a scratch-resistant mineral crystal lens and water resistance up to 165 feet (50 meters), ensures longevity and versatility for daily wear.



Figure 1: Front view of the Armitron 204692BKT1 watch, showcasing its black dial with silver-toned numerals and black-plated stainless steel bracelet.

2. SETUP

2.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first click position to set the date, or to the second click position to set the time.
2. **Set the date:** If at the first click, turn the crown clockwise or counter-clockwise to adjust the date.
3. **Set the time:** If at the second click, turn the crown to move the hour and minute hands to the desired time. Ensure you differentiate between AM and PM when setting the date changeover.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal operating position. The second hand will begin to move.



Figure 2: Side view of the watch, highlighting the crown used for time and date adjustments.

2.2 Adjusting the Bracelet

The watch features a black-plated stainless steel link bracelet with a fold-over push-button clasp with safety. For proper fit, the bracelet may need to be adjusted by adding or removing links. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch repair professional to avoid damage to the bracelet or clasp.



Figure 3: Rear view of the watch, displaying the fold-over push-button clasp with safety mechanism.

3. OPERATION

3.1 Basic Timekeeping

Once the time is set, the watch will accurately display hours, minutes, and seconds. The black analog dial features silver-toned Arabic numerals at 3, 6, 9, and 12 o'clock, with luminous indices at other hours for improved visibility in low light conditions. White hour and minute hands, along with a sweeping red-tipped second hand, provide clear time indication.

3.2 Date Display

The date window is conveniently located at the 4 o'clock position. The date will automatically advance once every 24 hours. If the date needs manual adjustment (e.g., after months with fewer than 31 days), refer to Section 2.1.

3.3 Water Resistance

This watch is water-resistant to a depth of 165 feet (50 meters). This rating makes it suitable for short periods of recreational swimming and showering. It is *not* suitable for diving, snorkeling, or prolonged water immersion. Always ensure the crown is fully pushed in before exposing the watch to water.



Figure 4: The Armitron 204692BKT1 watch worn on a wrist, demonstrating its fit and appearance.

4. MAINTENANCE

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the finish and seals.

4.2 Battery Replacement

The watch is powered by one product-specific battery, which is included. When the watch stops running or the second hand begins to skip, it indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

4.3 General Care

- Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as these can affect the accuracy of the quartz movement.
- Protect the watch from impacts and drops.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Battery depleted or crown not fully pushed in.	Ensure crown is fully pushed in. If not, battery replacement may be required by a professional.
Date not changing at midnight	Time set incorrectly (e.g., AM/PM confusion).	Advance the time by 12 hours.
Condensation under crystal	Exposure to extreme temperature changes or water ingress.	Contact customer support or a qualified watch repair service immediately.
Inaccurate timekeeping	Weak battery or exposure to strong magnetic fields.	Replace battery if needed. Keep watch away from magnets. If problem persists, seek professional service.

6. SPECIFICATIONS

- **Model Number:** 20/4692BKTI
- **Movement:** Japanese Quartz
- **Case Material:** Black-plated Stainless Steel
- **Band Material:** Black-plated Stainless Steel Link Bracelet
- **Crystal:** Scratch-resistant Mineral Crystal
- **Dial:** Black analog dial with silver-toned Arabic numerals (3, 6, 9, 12), luminous indices, white hour/minute hands, red-tipped second hand.
- **Date Display:** Window at 4 o'clock position
- **Clasp:** Fold-over push-button clasp with safety
- **Water Resistance:** 165 feet (50 meters) - suitable for swimming and showering.
- **Product Dimensions:** Approximately 0.59 x 0.59 x 0.59 inches
- **Item Weight:** Approximately 8.01 ounces
- **Battery:** 1 Product Specific battery (included)




Figure 5: Illustrative watch size comparison chart, providing a general idea of watch dimensions relative to common sizes.

7. WARRANTY & SUPPORT

For specific warranty information regarding your Armitron watch, please refer to the warranty card included with your purchase or visit the official Armitron website. Warranty terms typically cover manufacturing defects but may not cover damage due to misuse, accidents, or unauthorized repairs.

If you require technical assistance, service, or have questions not covered in this manual, please contact Armitron customer support through their official channels. Keep your purchase receipt as proof of purchase for any warranty claims.

You can find more information and contact details on the official Armitron website www.armitron.com