

## Small Foot 2098 (Manufacturer Reference: 2020260)

# Small foot 2098 Children's Piano User Manual

Model: 2098 (Manufacturer Reference: 2020260) | Brand: Small Foot

## 1. INTRODUCTION

This manual provides essential information for the safe and proper use, setup, and maintenance of your Small foot 2098 Children's Piano. This musical toy is designed to introduce children aged 3 and up to the world of music through interactive play.

The Small foot 2098 piano features a shiny black lacquered finish and produces musical sounds through its internal sound tubes when the keys are pressed. It is crafted from wood, ensuring durability for young users.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before allowing a child to use this product. Keep this manual for future reference.

- **Age Recommendation:** Suitable for children aged 3 years and older.
- **Supervision:** Adult supervision is recommended during play.
- **Material:** The piano is made of wood. Ensure no small parts become loose that could pose a choking hazard.
- **Cleaning:** Clean only with a damp cloth. Do not immerse in water.
- **Placement:** Place the piano on a stable, flat surface to prevent tipping.
- **Damage:** If the product is damaged, discontinue use immediately to prevent injury.

## 3. PRODUCT OVERVIEW

The Small foot 2098 piano is a robust and elegantly designed musical toy. Its primary components include:

- **Keyboard:** Features a set of keys designed for small hands.
- **Sound Tubes:** Internal mechanism that produces musical tones when keys are pressed.
- **Lacquered Finish:** A durable, shiny black coating.
- **Sturdy Base:** Provides stability during play.



Figure 3.1: Front view of the Small foot 2098 Children's Piano. This image displays the black lacquered finish and the white and black keys of the keyboard.

## 4. SETUP

---

The Small foot 2098 Children's Piano comes pre-assembled and ready for use. No additional assembly or batteries are required.

1. **Unpacking:** Carefully remove the piano from its packaging.
2. **Placement:** Place the piano on a stable, flat, and level surface, such as a table or floor, where the child can comfortably reach the keys.
3. **Inspection:** Before first use, inspect the piano for any signs of damage or loose parts. If any issues are found, refer to the Troubleshooting section or contact customer support.

## 5. OPERATING INSTRUCTIONS

---

Using the Small foot 2098 piano is straightforward and intuitive for children.

1. **Playing Notes:** Gently press down on any of the white or black keys. Each key corresponds to a specific musical note produced by the internal sound tubes.
2. **Exploring Sounds:** Encourage the child to experiment with different keys and combinations to discover various

melodies and harmonies.

3. **Musical Development:** This toy is designed to promote early musical understanding and hand-eye coordination.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and continued enjoyment of your Small foot 2098 piano.

- **Cleaning:** Wipe the surface of the piano with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the lacquered finish and wood.
- **Storage:** Store the piano in a dry place, away from direct sunlight and extreme temperatures, which can cause warping or fading of the wood.
- **Avoid Impact:** While robust, avoid dropping the piano or subjecting it to strong impacts, which could damage the internal sound mechanism or exterior finish.

7. TROUBLESHOOTING

If you encounter any issues with your Small foot 2098 piano, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound or muffled sound from a key.	Debris under the key, or internal sound tube obstruction/damage.	Gently try to dislodge any visible debris. If the problem persists, contact customer support. Do not attempt to open the piano.
Key is stuck or difficult to press.	Debris lodged around the key, or minor misalignment.	Carefully inspect for foreign objects. If none are visible, avoid forcing the key and contact customer support.
Piano wobbles on a flat surface.	Uneven surface or slight manufacturing variation.	Ensure the piano is on a completely flat surface. If wobbling persists, a small felt pad can be placed under the shorter leg.

8. SPECIFICATIONS

Feature	Detail
Model Number	2098 (Manufacturer Reference: 2020260)
Brand	Small Foot
Material	Wood
Color	Black
Dimensions (L x W x H)	Approximately 25 x 30 x 40 cm (9.8 x 11.8 x 15.7 inches)
Weight	Approximately 5.02 kg (11.07 lbs)
Recommended Age	3 years and up
Assembly Required	No
Batteries Required	No

Feature	Detail
Educational Value	Musicality
Number of Keys	Approximately 25 (visual estimate; note: some product listings may incorrectly state 88 keys for this child's model)
UPC	798521935320
ASIN	B00455QJ0G



Figure 8.1: Side view of the Small foot 2098 Children's Piano illustrating its approximate dimensions (height 14 inches / 34 cm).

## 9. WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For any questions regarding product defects, returns, or general support, please contact your retailer or the manufacturer directly.

**Manufacturer:** Small Foot

Please refer to the official Small Foot website or your purchase documentation for the most up-to-date contact information and warranty policies.



### Related Documents

[small foot 12361 Feuerwehrrucksack Produktsicherheitsrückruf wegen Ble](#)

Informationen zum Produktsicherheitsrückruf des small foot 12361 Feuerwehrucksacks aufgrund erhöhter Bleiwerte in den Schultergurten. Erfahren Sie, wie Sie das Produkt zurückgeben können.