

## Everpure EV9612-22

# Everpure EV9612-22 i2000 2 Filter Cartridge Instruction Manual

Model: EV9612-22

## 1. PRODUCT OVERVIEW

The Everpure EV9612-22 i2000 2 Filter Cartridge is designed to deliver premium quality water, specifically optimized for ice machine applications. This filter reduces water-related problems in ice machines, such as scale build-up caused by dirt and dissolved minerals.

Key features include:

- **Micro-Pure II Media with AgION:** Proprietary filtration media that inhibits bacterial growth on the filter, extending product life.
- **Precoat Submicron Technology:** Reduces dirt and particles as small as 0.5 micron in size.
- **Chlorine Taste and Odor Reduction:** Improves the taste and smell of water.
- **Cyst Reduction:** NSF/ANSI Standard 53 certified to reduce cysts like *Cryptosporidium* and *Giardia*.
- **Scale Inhibitor:** Self-contained feed helps prevent limescale build-up in water-using equipment.
- **Sanitary Cartridge Replacement:** Designed for simple, quick, and clean replacement.





This image displays the Everpure i2000 2 filter cartridge, highlighting its brand, model number EV9612-22, and key features such as Micro-Pure II filtration and scale inhibition.

## 2. INSTALLATION AND SETUP

This section provides general guidelines for installing or replacing your Everpure EV9612-22 i2000 2 filter cartridge. Always refer to your specific filter head system's instructions for detailed steps.

## 2.1 Safety Precautions

- Ensure the water supply to the filter system is turned off before beginning installation or replacement.
- Relieve any pressure in the system by opening a downstream faucet.
- Have a bucket or towel ready to catch any residual water.

## 2.2 Cartridge Replacement Steps

1. **Turn Off Water Supply:** Locate the shut-off valve for your filter system and turn it to the OFF position.
2. **Relieve Pressure:** Open a nearby cold water faucet to release pressure from the system. Allow water to drain until flow stops.
3. **Remove Old Cartridge:** Grasp the old filter cartridge firmly and twist it counter-clockwise until it detaches from the filter head. Pull it downwards to remove.
4. **Prepare New Cartridge:** Remove the protective cap from the new Everpure EV9612-22 i2000 2 cartridge.
5. **Install New Cartridge:** Align the new cartridge with the filter head. Push it upwards into the head and twist clockwise until it is securely seated. You should feel it lock into place.
6. **Restore Water Supply:** Slowly turn the water supply shut-off valve back to the ON position.
7. **Flush the System:** Open the cold water faucet and allow water to run for several minutes (e.g., 3-5 minutes) to flush out any air and fine carbon particles. The water may appear cloudy initially; this is normal.
8. **Check for Leaks:** Inspect the filter head and cartridge connection for any leaks.

## 3. OPERATION

---

Once installed, the Everpure EV9612-22 i2000 2 filter cartridge operates continuously to filter your water supply. Water flows through the filter media, which removes impurities and inhibits scale build-up before the water reaches your ice machine or other connected appliances.

The filter is designed for optimal performance within standard household water pressure ranges. Significant drops in water pressure may indicate that the filter is nearing the end of its service life or that there is an issue with the water supply.

## 4. MAINTENANCE

---

Regular maintenance, primarily cartridge replacement, is crucial for ensuring continuous high-quality water and optimal performance of your ice machine.

### 4.1 Cartridge Replacement Frequency

It is recommended to replace the Everpure EV9612-22 i2000 2 filter cartridge every 6 to 12 months, or sooner if you observe a noticeable drop in water flow or a change in water taste/odor. Actual replacement frequency may vary based on water quality and usage volume.

### 4.2 Cleaning

The filter cartridge itself does not require cleaning. Its design ensures sanitary replacement, minimizing exposure to contaminants.

## 5. TROUBLESHOOTING

If you encounter issues with your Everpure EV9612-22 i2000 2 filter system, consider the following common problems and solutions:

| Problem               | Possible Cause                                     | Solution                                                               |
|-----------------------|----------------------------------------------------|------------------------------------------------------------------------|
| Low Water Flow        | Clogged filter cartridge (due to sediment buildup) | Replace the filter cartridge.                                          |
|                       | Air trapped in the system                          | Flush the system by running water for several minutes.                 |
|                       | Kinked water line                                  | Inspect and straighten water lines.                                    |
| Unusual Taste or Odor | New filter not adequately flushed                  | Flush the system by running water for several minutes.                 |
|                       | Filter cartridge is expired or saturated           | Replace the filter cartridge.                                          |
| Water Leaks           | Cartridge not properly seated                      | Ensure the cartridge is fully twisted and locked into the filter head. |
|                       | Damaged O-rings or filter head                     | Contact Everpure support for assistance.                               |

## 6. SPECIFICATIONS

| Attribute                      | Detail                                               |
|--------------------------------|------------------------------------------------------|
| Model Number                   | EV9612-22                                            |
| Material                       | Micro-Pure II (Filter Media)                         |
| Product Dimensions             | 4"D x 4"W x 22"H                                     |
| Item Weight                    | 0.01 Ounces                                          |
| External Testing Certification | NSF                                                  |
| Product Benefits               | Removes Odor, Reduces Chlorine Taste, Inhibits Scale |
| Set Name                       | i2000(2)                                             |
| UPC                            | 807032973926, 054568559203, 054568554048             |
| Unit Count                     | 1.0 Count                                            |
| Number of Items                | 1                                                    |
| Manufacturer                   | Everpure                                             |
| Part Number                    | FPS-65583                                            |
| Style                          | Cartridge                                            |

## 7. WARRANTY AND SUPPORT

### 7.1 Warranty Information

The Everpure EV9612-22 i2000 2 Filter Cartridge comes with a **12 Months Parts** warranty. Please retain your proof of purchase for warranty claims.

## 7.2 Customer Support

For technical assistance, warranty inquiries, or further information, please contact Everpure customer support:

- **Manufacturer:** Everpure (a Pentair brand)
- **Worldwide Headquarters:** Hanover Park, IL, USA
- **Telephone:** 800.942.1153 or 630.307.3000
- **Email:** [cseverpure@pentair.com](mailto:cseverpure@pentair.com)
- **Website:** [www.everpure.com](http://www.everpure.com)
- **Cartridge Reorder Number:** EV9612-22

© 2025 Everpure. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question