

## Bush Furniture Segments Collection 37-Inch TV Stand

# Bush Furniture Segments Collection 37-Inch Bedroom TV Stand with Mount Instruction Manual

Model: Segments Collection 37-Inch TV Stand

Brand: Bush Furniture

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bush Furniture Segments Collection 37-Inch Bedroom TV Stand with Mount. This stand is designed to accommodate most flat-panel televisions up to 40 inches and 80 pounds, offering a stylish and functional solution for your home entertainment needs, particularly for convenient viewing from a bed.

## SAFETY INFORMATION

---

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 80 pounds for the TV mount and shelves. Overloading can cause instability and product failure.
- **Tip-Over Prevention:** This unit has been tip-tested to stringent UL1678 standards. For enhanced safety, always place the TV stand on a level, stable surface. Consider using wall anchor straps (not included) for additional tip-over prevention, especially in households with children or pets.
- **Assembly:** Assemble the unit according to the instructions provided. Ensure all fasteners are securely tightened before use. Do not use power tools for tightening screws unless specifically instructed, as this may strip threads or damage components.
- **Placement:** Position the TV stand away from direct sunlight, heat sources, and moisture.
- **Children:** Do not allow children to climb on or play with the TV stand.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included parts list (typically found in the product packaging) to ensure all components are accounted for. If any parts are missing or damaged, do not proceed with assembly. Contact Bush Furniture customer

support for assistance.

Typical components include:

- Wood frame segments and posts
- Tempered glass shelves
- TV mounting bracket and hardware
- Assembly hardware (screws, bolts, washers, etc.)
- Assembly tools (e.g., Allen wrench, if required)

## ASSEMBLY INSTRUCTIONS (SETUP)

---

Assembly is required for this TV stand. It is recommended that two adults perform the assembly. Clear a spacious area for assembly and keep all parts organized.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided parts list.
2. **Assemble Base Structure:** Begin by connecting the main vertical posts and horizontal supports as indicated in the detailed assembly diagram. Ensure all connections are firm but do not overtighten until the unit is fully assembled.
3. **Install Glass Shelves:** Carefully place the fixed, tempered glass shelves onto their designated supports. Ensure they are level and securely seated.
4. **Attach TV Mount:** Secure the TV mounting bracket to the main vertical post according to the instructions. This mount is designed to swivel 15 degrees left and right for optimal viewing angles.
5. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts. Do not overtighten.
6. **Cable Management:** Utilize the rear wire access and concealment features to route and organize your cables for a tidy appearance.



*Image: The Bush Furniture Segments Collection TV Stand, showcasing its structure and tempered glass shelves without electronic devices.*

## **OPERATING INSTRUCTIONS (USAGE)**

---

Once assembled, your TV stand is ready for use.

- **Placing Your TV:** Carefully attach your flat-panel TV to the mounting bracket. Ensure the TV is

securely fastened and centered. The mount allows for a 15-degree swivel to the left or right to adjust your viewing angle.

- **Organizing Devices:** Use the tempered glass shelves to place your media players, gaming consoles, soundbars, or other entertainment devices. Distribute weight evenly across the shelves.
- **Cable Management:** Utilize the integrated rear wire access points to route and conceal power cords and signal cables, maintaining a clean and organized appearance.



*Image: The Bush Furniture Segments Collection TV Stand, fully assembled and displaying various electronic devices on its shelves.*

## MAINTENANCE

---

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Dust regularly with a soft, dry cloth. For deeper cleaning, use a slightly damp cloth with a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the finish or glass.
- **Glass Care:** Clean tempered glass shelves with a standard glass cleaner and a soft cloth. Avoid impact to the glass edges.
- **Inspections:** Periodically check all fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Overloading:** Do not place items heavier than the specified weight limits on the shelves or TV

mount.

## TROUBLESHOOTING

---

If you encounter issues with your TV stand, refer to the following common solutions:

- **Stand is Wobbly:**
  - Ensure all assembly screws and bolts are securely tightened.
  - Verify the stand is placed on a level surface. Adjust furniture levelers if present.
- **TV Mount Not Swiveling Smoothly:**
  - Check for any obstructions around the swivel mechanism.
  - Ensure the TV is not exceeding the weight limit, which could strain the mechanism.
- **Missing or Damaged Parts:**
  - Do not attempt to assemble with missing or damaged parts. Contact Bush Furniture customer support immediately for replacements.

## SPECIFICATIONS

---

<b>Model Name</b>	Segments Collection 37-Inch TV Stand
<b>Brand</b>	Bush Furniture
<b>Color</b>	Rosebud Cherry
<b>Size</b>	37-Inch (accommodates TVs up to 40-inch)
<b>Item Dimensions (L x W x H)</b>	37 x 21.5 x 56.6 inches
<b>Item Weight</b>	92 Pounds
<b>Material Type</b>	Wood, Tempered Glass
<b>TV Weight Capacity</b>	Up to 80 Pounds
<b>TV Mount Swivel</b>	15 degrees left and right
<b>Required Assembly</b>	Yes
<b>Manufacturer</b>	Bush Industries

## WARRANTY AND SUPPORT

---

For warranty information, missing parts, or technical support, please contact Bush Furniture customer service. Refer to the contact information provided in your product packaging or visit the official Bush Furniture website.

Please have your model number (Segments Collection 37-Inch TV Stand) and purchase date available when contacting support.

