

[Manuals.plus](#) /

› [Quechua](#) /

› Quechua T62 Adult Tent User Manual

Quechua T62

Quechua T62 Adult Tent User Manual

MODEL: T62

1. Product Overview

The Quechua T62 Adult Tent is designed for 6 persons, offering a comfortable and spacious camping experience. It features two separate sleeping rooms and a large, high living area that can be fully opened, providing versatility for various weather conditions and activities. This tent is built for durability and ease of use, making it suitable for family camping and extended outdoor stays.



Figure 1: The Quechua T62 Adult Tent, a spacious beige tent designed for 6 persons, featuring a large living area and two separate sleeping compartments. The tent has a curved, tunnel-like structure with multiple windows and entry points.

Key Features:

- **Wind Resistance:** Validated in wind tunnels and on a rotating plate for enhanced stability.
- **Easy Transport & Setup:** Designed for convenient portability, opening, and closing.
- **Durable Poles:** Features 12.7mm diameter fibre poles for structural integrity.
- **Material Composition:** PU-coated polyester flysheet, breathable polyester inner tent, and polyethylene groundsheet.

- **Capacity:** Accommodates 6 persons comfortably.

2. Setup Instructions

Follow these steps for proper assembly of your Quechua T62 tent:

1. **Unpack and Lay Out:** Remove the tent from its bag and lay out the flysheet on a clean, flat surface. Identify the main entrance and the sleeping compartments.
2. **Assemble Poles:** Connect the sections of the fibre poles. Ensure all sections are fully inserted into each other.
3. **Insert Poles:** Slide the assembled poles through the designated sleeves on the flysheet. The T62 typically uses a tunnel design, so poles will arch over the tent.
4. **Raise the Tent:** Once all poles are in place, lift the tent structure and secure the pole ends into the pins or grommets at the base.
5. **Peg Down:** Secure the tent to the ground using pegs. Start with the corners, then peg out all guylines to ensure stability, especially in windy conditions.
6. **Attach Inner Tents:** Inside the flysheet, hook or clip the inner sleeping compartments into place. Ensure the groundsheets of the inner tents are flat.
7. **Adjust Ventilation:** Open or close vents as needed for airflow.

Note: It is recommended to practice setting up the tent in a calm environment before your first trip.

3. Operating the Tent

To maximize comfort and functionality during your camping trip:

- **Door Management:** Utilize the multiple entry points for convenient access. Zip doors fully closed to prevent insects and maintain warmth, or roll them up and secure them for ventilation.
- **Ventilation:** The tent is equipped with vents to reduce condensation. Keep them open when possible, especially during humid conditions, to ensure proper airflow.
- **Living Area Use:** The spacious living area can be used for dining, storing gear, or as a communal space. It can be fully opened for an outdoor feel or closed for protection.
- **Sleeping Compartments:** The two separate rooms offer privacy. Ensure inner tent doors are zipped to keep insects out.
- **Weather Considerations:** In strong winds, ensure all guylines are taut and pegged securely. In rain, ensure all zips are closed and the flysheet is properly tensioned to shed water.

4. Maintenance and Care

Proper maintenance extends the life of your tent:

- **Cleaning:** The tent should be cleaned by hand. Use a soft brush and clean water to remove dirt. Avoid harsh detergents or washing machines, as these can damage the waterproof coating.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a damp tent can lead to mildew,

odors, and damage to the fabric and coatings. Air dry in a shaded, well-ventilated area.

- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it loosely packed rather than tightly compressed for long periods to preserve fabric integrity.
- **Pole Care:** Inspect poles for any damage or bending after each use. Clean off any dirt and ensure elastic cords are in good condition.
- **Zipper Care:** Keep zippers clean and free of sand or dirt. Lubricate occasionally with a silicone-based spray if they become stiff.

5. Troubleshooting

Common issues and their solutions:

- **Condensation Inside Tent:**
Cause: Lack of ventilation, body heat, and moisture from breathing.
Solution: Ensure all vents are open. If possible, slightly open doors or windows (with mesh) to increase airflow. Avoid cooking inside the tent.
- **Tent Not Standing Firmly:**
Cause: Improper pegging or loose guylines.
Solution: Re-peg all points, ensuring pegs are driven firmly into the ground at a 45-degree angle away from the tent. Tighten all guylines until taut.
- **Water Leaking Through Fabric:**
Cause: Damaged waterproof coating, worn seams, or improper tensioning.
Solution: Inspect the flysheet for tears or worn areas. Apply seam sealer to leaky seams. Ensure the tent is pitched tautly so water runs off effectively.
- **Zipper Sticking:**
Cause: Dirt, sand, or lack of lubrication.
Solution: Clean the zipper teeth with a brush. Apply a silicone-based zipper lubricant. Avoid forcing the zipper.

6. Specifications

Feature	Detail
Brand	Quechua
Model	T62
Occupancy	6 Person
Item Weight	18 Kilograms
Recommended Uses	Camping & Hiking
Shape	Rectangular (Tunnel Design)
Seasons	3 Season

Material	Polyester (Flysheet), Polyethylene (Groundsheet)
Colour	Beige
Pole Material Type	Fibre (12.7mm diameter)
Dimensions (Packed)	60 x 36 x 36 Centimeters
Included Components	Tent (Flysheet, Inner Tents, Poles, Pegs, Guylines)

7. Warranty and Support

For specific warranty details and terms, please refer to the documentation provided at the time of purchase or contact your retailer. Quechua products typically come with a manufacturer's warranty covering defects in materials and workmanship.

If you require technical assistance, have questions about your tent, or need to report an issue, please contact Quechua customer support through their official website or the retailer from whom you purchased the product. When contacting support, please have your model number (T62) and purchase details readily available.

Manufacturer: Quechua

First Available: 21 January 2014

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question