

[Manuals.plus](#) /

› [CubicFun](#) /

› CubicFun The Capitol Hill 3D Puzzle Instruction Manual

CubicFun MC074H

CubicFun The Capitol Hill 3D Puzzle Instruction Manual

Model: MC074H

1. INTRODUCTION

This manual provides detailed instructions for the assembly and care of your CubicFun The Capitol Hill 3D Puzzle, model MC074H. This product allows for the construction of a detailed replica of the U.S. Capitol Building using pre-cut, reinforced foam cardboard pieces. The assembly process is designed to be engaging and educational, promoting concentration and problem-solving skills.



Image 1.1: The assembled CubicFun Capitol Hill 3D Puzzle, showcasing its iconic structure.

2. SAFETY INFORMATION

- **Small Parts Warning:** This product contains small parts and is not suitable for children under 3 years of age due to choking hazards.
- **Material Safety:** The puzzle pieces are made from cardboard. Avoid exposure to water or excessive humidity to prevent damage.
- **Supervision:** Adult supervision is recommended during assembly, especially for younger users (recommended age 8+).

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package for the CubicFun The Capitol Hill 3D Puzzle (MC074H) typically includes:

- Pre-cut reinforced foam cardboard puzzle sheets (132 pieces total).
- Instruction booklet with detailed assembly diagrams.



Image 3.1: The typical contents found within the product packaging, including puzzle sheets and the instruction manual.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your 3D puzzle. No scissors or glue are required; pieces are designed to slot together.

1. **Preparation:** Unpack all puzzle sheets and the instruction booklet. Familiarize yourself with the different sheets and the overall structure shown in the diagrams.
2. **Identify Pieces:** Each piece is numbered or corresponds to a specific section in the instruction booklet. Carefully punch out the pieces from the foam cardboard sheets.
3. **Follow Diagrams:** Refer to the step-by-step diagrams in the instruction booklet. Assemble sections according to the indicated sequence.

4. **Slotting Mechanism:** Connect pieces by aligning the tabs with the corresponding slots and gently pushing them together. Ensure a snug fit without forcing.
5. **Base Assembly:** Often, the base or lower sections are assembled first to provide a stable foundation for the structure.
6. **Dome and Details:** Proceed with the more intricate parts, such as the dome and architectural details, as guided by the instructions.
7. **Final Review:** Once all pieces are assembled, review the completed model to ensure all connections are secure and the structure is stable.



Image 4.1: Illustrates the assembly process, showing how individual pieces are connected following the provided diagrams.

A PERFECT OPPORTUNITY TO INTERACT WITH FAMILY & FRIENDS



Image 4.2: Demonstrates collaborative assembly, highlighting the interactive nature of the puzzle.

5. USAGE AND DISPLAY

Once assembled, your CubicFun Capitol Hill 3D Puzzle serves as a detailed model of the U.S. Capitol Building. It is suitable for display in various settings.

- **Educational Tool:** The model can be used as an educational aid to learn about the architecture and significance of the U.S. Capitol.
- **Decorative Item:** Its detailed design makes it a suitable decorative piece for home or office environments.

BEST DECORATION FOR HOME & OFFICE



Image 5.1: The completed puzzle displayed as a decorative item, showcasing its aesthetic appeal.

AUTHENTIC AND DETAILED

TRUE-TO-LIFE
COLOR DEPICTION



Image 5.2: A detailed view of the puzzle's architectural elements, emphasizing its authentic representation.

6. MAINTENANCE

To ensure the longevity and appearance of your 3D puzzle model, follow these maintenance guidelines:

- **Cleaning:** Gently dust the model with a soft, dry cloth or a soft brush. Avoid using liquid cleaners or abrasive materials, as they can damage the cardboard.
- **Storage/Display Environment:** Keep the model in a dry environment, away from direct sunlight, extreme temperatures, and high humidity. These conditions can cause warping, fading, or degradation of the material.
- **Handling:** Handle the assembled model with care to prevent pieces from detaching or the structure from collapsing.

7. TROUBLESHOOTING

If you encounter any issues during assembly or with the product, consider the following:

- **Missing Pieces:** Carefully check all packaging materials and puzzle sheets. If a piece is genuinely missing, contact CubicFun customer support (see Section 9).
- **Difficulty Connecting Pieces:** Ensure you are using the correct pieces for the current step as indicated in the instruction booklet. Apply gentle, even pressure when slotting pieces. Do not force them, as this can cause damage.
- **Unstable Structure:** Re-check connections for any loose pieces. Ensure all tabs are fully inserted into their corresponding slots.
- **Damaged Pieces:** If a piece is damaged upon opening the package, contact customer support for assistance.

8. SPECIFICATIONS

Product Specifications - CubicFun The Capitol Hill 3D Puzzle (MC074H)

Feature	Detail
Model Number	MC074H
Brand	CubicFun
Number of Pieces	132
Material	Reinforced Foam Cardboard
Assembled Dimensions (L x W x H)	52.5 x 23.5 x 20 cm (20.66 x 9.25 x 7.87 inches)
Recommended Age	8+ years
Approximate Assembly Time	120 minutes
Assembly Requirements	No scissors, no gluing required
Educational Objectives	Color Recognition, Creative Thinking, Memory Skill

PRODUCT DEMIIONSIONS

132

Pieces

8⁺

Ages

120

Minute




Image 8.1: Visual representation of the product's dimensions and key specifications.

9. WARRANTY AND SUPPORT

CubicFun products are manufactured to high-quality standards. For information regarding product warranty, returns, or technical support, please refer to the contact information provided on the product packaging or visit the official CubicFun website.

When contacting support, please have your product model number (MC074H) and purchase details readily available.

© 2025 CubicFun. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Could you send me the step-by-step assembly diagram for the CubicFun MC074H Capitol Hill 3D Puzzle?

The assembly for the CubicFun The Capitol Hill 3D Puzzle (Model MC074H) is designed to be completed without glue or scissors by following the numbered diagrams included in the instruction booklet. While we cannot...

[Read full answer](#)