

[Manuals.plus](#) /

› [Newport Brass](#) /

› Newport Brass 2040 Double Handle Widespread Bathroom Faucet User Manual

Newport Brass 2040/24S

Newport Brass 2040 Double Handle Widespread Bathroom Faucet User Manual

Model: 2040/24S

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Newport Brass 2040 Double Handle Widespread Bathroom Faucet. The Secant collection features a contemporary design with high arched spouts and sharp angled escutcheons, crafted from durable brass with a Satin Gold (PVD) finish. Please read this manual thoroughly before beginning installation or operation to ensure proper function and longevity of your faucet.



Image: The Newport Brass 2040 Double Handle Widespread Bathroom Faucet, showcasing its contemporary design with a high arched spout and two lever handles, all in a lustrous satin gold finish. The faucet is designed for widespread installation.

SAFETY INFORMATION

- Always turn off the main water supply before installing or servicing the faucet.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep small parts away from children.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Faucet Body (Spout)
- Hot Water Handle Assembly
- Cold Water Handle Assembly
- Pop-up Drain Assembly
- Mounting Hardware (washers, nuts, etc.)
- Installation Instructions (this manual)

SETUP AND INSTALLATION

This faucet is designed for widespread mounting on a 3-hole sink or countertop with 8-inch centers. The maximum deck thickness supported is 1-1/2 inches, and the required faucet hole size is 1-3/8 inches.

1. **Prepare the Sink/Countertop:** Ensure the three faucet holes are clean and free of debris. The center-to-center distance between the outer holes should be 8 inches.
2. **Install the Faucet Body (Spout):**
 - Insert the spout base through the center hole of the sink/countertop.
 - From underneath, secure the spout with the provided washer and mounting nut. Hand-tighten first, then use a wrench to snug it, ensuring the spout is properly aligned.
3. **Install the Handle Assemblies:**
 - Insert the hot and cold handle assemblies into their respective outer holes.
 - From underneath, secure each handle assembly with its washer and mounting nut. Ensure the handles are oriented correctly for operation.
4. **Connect Water Supply Lines:**
 - Connect the hot and cold water supply lines to the corresponding inlets on the faucet body and to your home's water supply valves. Use thread sealant tape on all threaded connections.
 - Ensure connections are tight but do not overtighten.
5. **Install Pop-up Drain Assembly:**
 - Follow the instructions provided with the pop-up drain assembly to install it into the sink drain hole. Ensure a watertight seal.
 - Connect the pop-up rod to the faucet's lift rod mechanism.
6. **Test for Leaks:**
 - Once all connections are made, slowly turn on the main water supply.
 - Check all connections for leaks. If leaks are present, tighten the connections as needed.
 - Run water through the faucet for a few minutes to flush out any debris from the lines.

OPERATING INSTRUCTIONS

Your Newport Brass 2040 faucet features two metal lever handles for precise control of water flow and temperature.

- **Turning On/Off:** Rotate the lever handles away from the spout to turn on the water. Rotate them back towards the spout to turn off the water.
- **Adjusting Water Flow:** The further you rotate the handles, the greater the water flow.
- **Adjusting Temperature:** The left handle typically controls hot water, and the right handle controls cold water. Adjust both handles simultaneously to achieve your desired water temperature.
- **Pop-up Drain Operation:** Push down on the lift rod located behind the spout to close the drain stopper. Pull up on the lift rod to open the drain stopper.

CARE AND MAINTENANCE

To maintain the beautiful Satin Gold (PVD) finish and ensure the longevity of your Newport Brass faucet, follow these care instructions:

- **Regular Cleaning:** Clean the faucet regularly with a soft, damp cloth and mild soap. Rinse thoroughly with clean

water and dry with a soft cloth to prevent water spots.

- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, harsh chemicals, ammonia-based products, or scouring pads, as these can damage the finish.
- **Protect the Finish:** Avoid direct contact with harsh chemicals found in some bathroom cleaners, hair dyes, or nail polish removers.
- **Aerator Cleaning:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the end of the spout, clean any debris, and reattach.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valves; debris in water lines.	Clean or replace aerator; fully open supply valves; flush water lines.
Leaks at Faucet Base	Loose mounting nuts; improper sealant.	Tighten mounting nuts; reapply sealant if necessary.
Leaks from Handles	Worn O-rings or cartridges.	Contact customer support for replacement parts or professional assistance.
Water Temperature Issues	Incorrect hot/cold supply connections; water heater issues.	Verify supply line connections; check water heater settings.

SPECIFICATIONS

Model Number	2040/24S
Brand	Newport Brass
Material	Brass
Finish	Satin Gold (PVD)
Mounting Type	Widespread (Deck Mount)
Number of Faucet Holes	3
Faucet Centers	8 inches
Maximum Deck Thickness	1-1/2 inches
Faucet Hole Size	1-3/8 inches
Height (Deck to Top of Faucet)	9-13/16 inches
Spout Height (Deck to Spout Outlet)	6-3/4 inches
Spout Reach (Faucet Base to Spout Outlet)	5-13/16 inches
Flow Rate	1.2 gallons-per-minute
Number of Handles	2

Handle Type	Lever
Item Weight	4.72 pounds
Product Dimensions	1 x 1 x 1 inches (packaging/shipping dimensions may vary)

WARRANTY AND CUSTOMER SUPPORT

Newport Brass products are covered by a limited warranty. For specific details regarding your warranty coverage, please refer to the warranty card included with your product or visit the official Newport Brass website. If you encounter any issues or have questions that are not addressed in this manual, please contact Newport Brass customer support:

- **Website:** www.newportbrass.com (for product registration, FAQs, and contact information)
- **Phone:** Refer to the Newport Brass website or product packaging for the most current customer service phone number.
- When contacting support, please have your model number (2040/24S) and purchase date available.

