Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 8009

Whirlpool 8009 Universal Appliance Light Bulb Instruction Manual

Model: 8009 | Brand: Whirlpool

Introduction

This manual provides essential information for the safe and effective use of your Whirlpool 8009 Genuine OEM Universal Appliance Light Bulb. This bulb is designed to replace various appliance light bulbs and offers reliable illumination for your appliance.



Figure 1: The Whirlpool 8009 Universal Appliance Light Bulb, a clear incandescent bulb with a standard medium base.

Safety Information

Always prioritize safety when handling electrical components. Follow these guidelines:

- Before replacing any light bulb, ensure the appliance is completely disconnected from its power source to prevent electrical shock.
- Allow the old bulb to cool down completely before touching it, as it may be hot.
- Handle the new bulb by its base to avoid touching the glass, which can reduce its lifespan.
- Do not overtighten the bulb into the socket.
- Ensure the replacement bulb's specifications match the appliance's requirements.
- Dispose of old bulbs responsibly according to local regulations.

What's in the Box

Your package contains the following item:

- 1 x Whirlpool 8009 Genuine OEM Universal Appliance Light Bulb

Setup and Installation

The Whirlpool 8009 light bulb is designed for straightforward installation, requiring no specialized tools or repair experience. Follow these steps:

1. **Disconnect Power:** Locate the power supply for your appliance (e.g., refrigerator, oven, microwave) and unplug it from the wall outlet. If direct unplugging is not possible, turn off the corresponding circuit breaker.
2. **Access Bulb:** Open the appliance door or access panel to expose the light bulb. Some appliances may have a protective cover over the bulb that needs to be removed.
3. **Remove Old Bulb:** Carefully unscrew the old light bulb counter-clockwise. If the bulb is broken, use pliers or a potato to grip the base and twist it out.
4. **Insert New Bulb:** Screw the new Whirlpool 8009 light bulb clockwise into the socket until it is snug. Do not overtighten.
5. **Replace Cover (if applicable):** Reattach any protective covers or panels that were removed.
6. **Restore Power:** Plug the appliance back into the wall outlet or turn the circuit breaker back on.




Figure 2: The compact size of the Whirlpool 8009 light bulb, measuring approximately 3.4 inches (8 cm) in length, demonstrating its universal fit for various appliance models.

Operating Instructions

Once installed, the Whirlpool 8009 light bulb operates automatically with your appliance's existing lighting system. It will illuminate when the appliance door is opened or when the light function is activated, depending on the appliance type.

- For refrigerators, the light will turn on when the door is opened and off when closed.
- For ovens, the light typically activates via a dedicated light button on the control panel.

- For microwaves, the light usually turns on when the door is opened and during operation.

Maintenance

The Whirlpool 8009 light bulb requires minimal maintenance. To ensure optimal performance and longevity:

- **Cleaning:** If the bulb becomes dusty, ensure the appliance is unplugged and the bulb is cool. Gently wipe the glass with a soft, dry cloth. Do not use liquid cleaners directly on the bulb.
- **Replacement:** This bulb is rated for 1000 hours of use. Replace the bulb when it burns out or its brightness significantly diminishes. Always use genuine Whirlpool replacement parts for best results.

Troubleshooting

If your new light bulb does not illuminate after installation, consider the following:

Problem	Possible Cause	Solution
Bulb does not light up.	1. Appliance not plugged in or circuit breaker tripped. 2. Bulb not screwed in properly. 3. Bulb is faulty. 4. Appliance's light socket or wiring issue.	1. Ensure appliance is plugged in and circuit breaker is on. 2. Unscrew and re-screw the bulb, ensuring it's snug. 3. Test the bulb in another working socket or try a different new bulb. 4. If other solutions fail, contact a qualified service technician.

Specifications

Key technical details for the Whirlpool 8009 Universal Appliance Light Bulb:

- **Model:** 8009
- **Light Type:** Incandescent
- **Wattage:** 40 watts
- **Voltage:** 120 volts
- **Bulb Shape Size:** A15
- **Bulb Base:** E26 (Medium Base)
- **Brightness:** 415 Lumens
- **Rated Life:** 1000 hours
- **Special Feature:** Frosted
- **Material:** Glass
- **Product Dimensions:** 3.37 x 2 x 2 inches
- **Item Weight:** 1.44 ounces

Warranty and Support

Whirlpool Genuine OEM Parts & Accessories are designed specifically for your appliance, meet tested engineering standards, and are crafted to ensure the quality and longevity of your appliance. For over 100 years, Whirlpool has been committed to providing reliable products and replacement parts.
If you encounter any issues or require further assistance, please contact Whirlpool Customer Support or visit the official

Whirlpool website for service and parts information. Always insist on genuine OEM parts to maintain the performance and validity of your appliance's warranty.
For more information, you may visit the Whirlpool Store on Amazon.

© 2024 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0049IG4ZE

More documents and user manuals: **https://manuals.plus/**