

[Manuals.plus](#) /

› [Nautica](#) /

› Nautica Men's N20062G NST 500 Watch User Manual

Nautica N20062G

Nautica Men's N20062G NST 500 Watch User Manual

Model: N20062G

INTRODUCTION

Welcome to the user manual for your Nautica Men's N20062G NST 500 watch. This timepiece combines a sporty design with functional features, suitable for various activities. It features a durable stainless steel case, a comfortable polyurethane strap, and a chronograph movement for precise timekeeping. This manual will guide you through the setup, operation, and maintenance of your watch to ensure its longevity and optimal performance.



Figure 1: The Nautica N20062G NST 500 watch displayed on a wrist, showcasing its design and fit.

Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown out to the first or second click position (refer to specific watch movement instructions if available, typically the second click for time setting).
3. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement and ensure water resistance.

Battery Installation

This watch operates on a quartz movement powered by a single CR2 type battery. Battery installation or replacement should ideally be performed by a qualified watch technician to maintain the watch's water resistance and prevent damage.

OPERATING THE CHRONOGRAPH

The Nautica N20062G NST 500 features a chronograph movement, allowing you to measure elapsed time.

1. **Start:** Press the upper pusher (button) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the lower pusher to reset all chronograph hands to their zero positions.

Note: The watch also includes a 24-hour indicator, typically located on a sub-dial, which synchronizes with the main time display.



Figure 2: A detailed view of the watch dial, highlighting the chronograph sub-dials and pushers.

Cleaning Your Watch

To maintain the appearance of your Nautica watch, regularly wipe the case and strap with a soft, damp cloth. For the polyurethane strap, mild soap and water can be used, followed by thorough rinsing and drying. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

Water Resistance

Your Nautica N20062G NST 500 watch is water resistant up to 330 feet (100 meters). This makes it suitable for snorkeling and swimming. However, it is **not recommended for scuba diving**. Always ensure the crown is fully pushed in before exposing the watch to water. Avoid operating the pushers or crown while the watch is wet or submerged.

Battery Replacement

When the battery needs replacement, it is highly recommended to take your watch to an authorized Nautica service center or a reputable watchmaker. This ensures that the watch is opened and sealed correctly, preserving its water resistance and preventing internal damage.

TROUBLESHOOTING

- Watch Not Running:**
Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement. Refer to the "Battery Replacement" section.
- Chronograph Hands Not Resetting to Zero:**
Ensure the chronograph is stopped before attempting to reset. If the issue persists, a recalibration or service may be required. Consult a professional watch technician.
- Condensation Under Crystal:**
This indicates a potential breach in water resistance. Avoid further exposure to water and have the watch inspected by a professional immediately.

SPECIFICATIONS

Feature	Detail
Model Number	N20062G
Brand	Nautica
Movement Type	Japanese Quartz, Chronograph
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	48.4 mm
Case Thickness	12 mm
Crystal Material	Mineral
Band Material	Polyurethane

Feature	Detail
Band Width	22.1 mm
Clasp Type	Buckle
Water Resistance	100 meters (330 feet)
Battery Type	1 CR2
Product Dimensions	1.5 x 1.5 x 1.5 cm; 340.19 g
UPC	656086042252




Figure 3: A visual guide illustrating various watch case sizes, including the 48.4mm diameter of this model.

WARRANTY INFORMATION

For specific warranty details regarding your Nautica N20062G NST 500 watch, please **contact the seller of record** from whom you purchased the product. Warranty terms and conditions may vary based on the point of purchase.

CUSTOMER SUPPORT

Should you require further assistance, have questions not covered in this manual, or need service for your Nautica N20062G NST 500 watch, please reach out to the retailer or the official Nautica customer support channels.



Figure 4: The Nautica watch presented in its original packaging box.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0049N9FPU>

More documents and user manuals: <https://manuals.plus/>