

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PWR+](#) /

› [PWR+ AC Adapter User Manual for Portable DVD Players](#)

## PWR+ PWR-TAH12020N

# PWR+ AC Adapter User Manual

Model: PWR-TAH12020N

## 1. INTRODUCTION

This manual provides instructions for the safe and effective use of your PWR+ AC Adapter. This adapter is designed as a replacement power supply for various portable DVD players, ensuring reliable power delivery.

## 2. SAFETY INFORMATION

Your PWR+ AC Adapter is UL Listed, indicating it has been tested and certified by Underwriters Laboratories for safety standards. Adherence to these guidelines is crucial for safe operation.

- Do not expose the adapter to liquids, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter.
- Ensure the power outlet is easily accessible and not overloaded.
- Unplug the adapter during lightning storms or when unused for extended periods.



Image: The UL Listed certification logo, signifying that the product meets recognized safety standards.  
The adapter incorporates built-in safety protections:


- **SCP (Short Circuit Protection):** Prevents damage from short circuits.
- **OCP (Over Current Protection):** Safeguards against excessive current flow.
- **OVP (Over Voltage Protection):** Protects against voltage surges.
- **OTP (Over Temperature Protection):** Prevents overheating.

# Power Fast With **PWR+**



## Safe & Reliable

Made with high quality materials



## Extra Long Power Cord

**6.5 FT Total Cord Length** keeps you plugged-in at any work environment



## Reinforced Stress Points

Withstand more wear and tear



## Built-In Safety Protections

Designed with Safety in mind



Short Circuit Protection



Over Current Protection



Over Voltage Protection



Over Temperature Protection



Image: An illustration detailing the internal construction of the power cord, highlighting high-grade copper, wire insulation, aluminum foil shield, protective tinned copper braid, and PVC cable jacket. It also shows the adapter with icons for Short Circuit Protection (SCP), Over Current Protection (OCP), Over Voltage Protection (OVP), and Over Temperature Protection (OTP).

## 3. PRODUCT OVERVIEW

The PWR+ AC Adapter is a reliable power solution for compatible portable DVD players. It features an extra-long 6.5 ft (approximately 2 meters) power cord for flexible placement and a barrel connector for device compatibility.



Image: The PWR+ AC Adapter unit with its attached power cord and barrel connector.

## Compatibility

This adapter is compatible with various portable DVD players, including models from Philips, Craig (e.g., CTFT713, CTFT716N), DBPOWER (e.g., 9.5" THX-120100KE PD928), and Ematic (e.g., EPD116BL, EPD116BU, JB901PR). **Note: This adapter is not designed for laptops.**

## NOT USB Charger



Image: A visual warning indicating that the product is not a USB charger, specifically showing a micro USB connector with a red cross over it.

## 4. SETUP

1. Identify the power input port on your portable DVD player. It should be a circular port designed for a barrel connector.
2. Insert the barrel connector of the PWR+ AC Adapter firmly into the power input port of your DVD player.
3. Plug the AC end of the adapter into a standard wall power outlet (100-240V).
4. Ensure all connections are secure.

## 5. OPERATING INSTRUCTIONS

Once the adapter is properly connected to both the portable DVD player and a power outlet, your device should begin to power on or charge its internal battery. Refer to your portable DVD player's manual for specific power-on procedures or charging indicators.

## 6. MAINTENANCE

- Keep the adapter clean and free from dust. Use a dry, soft cloth for cleaning.

- Store the adapter in a cool, dry place when not in use.
- Avoid wrapping the cord too tightly around the adapter, as this can damage the cable over time.
- Regularly inspect the cord and connector for any signs of wear or damage. If damage is observed, discontinue use and replace the adapter.

## 7. TROUBLESHOOTING

### Device Not Powering On/Charging

- **Check Connections:** Ensure the barrel connector is fully inserted into the DVD player and the AC plug is securely in the wall outlet.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Inspect Adapter:** Look for any visible damage to the adapter or cord. If damaged, do not use.
- **Compatibility:** Confirm that your portable DVD player model is listed as compatible with this PWR+ adapter.

If the issue persists after performing these checks, contact PWR+ customer support for assistance.

## 8. SPECIFICATIONS

<b>Model Number</b>	PWR-TAH12020N
<b>Input Voltage</b>	100-240V AC
<b>Output Voltage</b>	12V DC
<b>Output Current</b>	2A (1.5-2A compatible)
<b>Power Cord Length</b>	6.5 feet (approx. 2 meters)
<b>Connector Type</b>	Barrel Connector
<b>Safety Certifications</b>	UL Listed, CE, FCC
<b>Item Weight</b>	6.4 ounces

## 9. WARRANTY AND SUPPORT

PWR+ offers a **30-day refund policy** and a **24-month exchange warranty** for this product. For any questions, concerns, or warranty claims, please contact PWR+ customer support. PWR+ is a WA, USA based company committed to providing reliable products and friendly customer support.

For more information or to contact support, please visit the [PWR+ Store on Amazon](#).

© 2026 PWR+. All rights reserved.