



[Manuals.plus](#) /

› [Samsonite](#) /

› Samsonite Casual Wheeled Laptop Overnighter Instruction Manual (Model 43876-1041)

Samsonite 43876-1041

Samsonite Casual Wheeled Laptop Overnighter Instruction Manual

Model: 43876-1041 | Brand: Samsonite

INTRODUCTION

This manual provides essential instructions for the proper use, care, and maintenance of your Samsonite Casual Wheeled Laptop Overnighter. Designed for convenience and durability, this bag features a padded laptop compartment, adjustable handle, and smooth-rolling wheels, making it ideal for business travel and daily use. Please read this manual thoroughly to ensure optimal performance and longevity of your product.

KEY FEATURES

- **Durable Construction:** Constructed of rugged 1680 Ballistic fabric for enhanced durability.
- **Padded Laptop Compartment:** Securely fits laptops up to 15.6 inches.
- **Adjustable Handle:** Features an adjustable push-button locking handle for comfortable maneuvering.
- **Overnighter Capacity:** Provides ample space for overnight essentials.
- **Organized Storage:** Includes a separate pocket with divided file organization.
- **Smooth Mobility:** Equipped with smooth-rolling, in-line skate wheels for effortless transport.
- **Comfortable Carrying:** Wrapped bale handles offer comfort when carrying the bag.

SETUP AND INITIAL USE

1. **Unpacking:** Remove all packaging materials and tags from the bag.
2. **Handle Extension:** To extend the telescoping handle, locate the button on the handle grip. Press the button and pull the handle upwards until it locks into your desired height.
3. **Handle Retraction:** To retract the handle, press the button on the grip and push the handle downwards until it is fully collapsed. Ensure the handle is fully retracted before storing or carrying the bag by its bale handles.
4. **First Inspection:** Inspect all zippers, seams, and wheels to ensure they are in proper working order.



Figure 1: Samsonite Wheeled Laptop Overnighter with its adjustable handle extended.

STORAGE AND ORGANIZATION

Your Samsonite Wheeled Laptop Overnighter is designed with multiple compartments to keep your belongings organized and secure.

- **Main Compartment:** This large section offers overnighter capacity for clothing and larger items.
- **Padded Laptop Sleeve:** A dedicated padded compartment is designed to protect laptops up to 15.6 inches. Secure your laptop using the internal strap if available.
- **Front Organizer Pocket:** Features divided sections for files, documents, pens, business cards, and other small accessories.

- **Additional Pockets:** Utilize smaller zippered pockets for quick access items like keys, phones, or travel documents.



Figure 2: Interior view of the bag, highlighting the padded laptop compartment and organized front pocket.

OPERATING THE BAG

Your Samsonite Overnighter offers versatile carrying options:

- **Rolling:** Extend the adjustable handle and tilt the bag slightly to engage the smooth-rolling in-line skate wheels. Pull the bag behind you for effortless mobility.
- **Carrying:** For shorter distances or when navigating stairs, use the wrapped bale handles. Ensure the telescoping handle is fully retracted and zipped away for comfortable carrying.



Figure 3: Detail of the comfortable wrapped bale handles for hand carrying.

MAINTENANCE

- **Cleaning:** For general cleaning, wipe the exterior ballistic fabric with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Zipper Care:** Keep zippers free from debris. If zippers become stiff, apply a small amount of silicone lubricant or wax.
- **Wheel Care:** Periodically check wheels for debris and clean as necessary to ensure smooth rolling.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Stuck Zipper:** Do not force a stuck zipper. Try gently moving the slider back and forth while applying slight pressure. Ensure no fabric is caught in the zipper teeth.

- **Wobbly Handle:** If the telescoping handle feels wobbly, ensure it is fully extended and locked into place. Avoid excessive force when pulling or pushing the handle.
- **Wheels Not Rolling Smoothly:** Check the wheels for any trapped debris (e.g., hair, lint). Clean the wheel axles if necessary.

SPECIFICATIONS

Model Number	43876-1041
Product Dimensions	17.25 x 14.75 x 10 inches
Item Weight	7.3 Pounds
Fabric Type	100% Polyester (1680 Ballistic fabric)
Laptop Compatibility	Fits up to 15.6 inch laptops
Wheels	Smooth rolling, in-line skate wheels

SAFETY INFORMATION

WARNING: This product can expose you to Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause Cancer and Birth Defect/Reproductive Harm. For more information go to www.P65Warnings.ca.gov.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Samsonite website or contact Samsonite customer service directly. Keep your purchase receipt as proof of purchase.

Legal Disclaimer: The padded laptop compartment and front organizer pocket are designed for business essentials. The bag features locking upright handles and a top carry handle. A padded, removable, and adjustable shoulder strap is also included. It fits laptops up to 15.6 inches. The material is Ballistic Nylon.