



Manuals.plus /

› GOgroove /

› GOgroove BassPULSE 2.1 Computer Speakers Instruction Manual

GOgroove GGBP000100BKUS

GOgroove BassPULSE 2.1 Computer Speakers Instruction Manual

Model: GGBP000100BKUS

INTRODUCTION

Thank you for choosing the GOgroove BassPULSE 2.1 Computer Speakers. This system is designed to provide powerful 2.1 channel audio with a booming subwoofer and distinctive blue LED glow lights. This manual will guide you through the setup, operation, and maintenance of your new speaker system to ensure optimal performance and longevity.

The GOgroove BassPULSE speakers feature full-range 5-watt satellite speakers and a side-firing 10-watt subwoofer, delivering 40 watts of peak power. The blue LED accent lights pulse to the beat of the music when the bass equalizer is turned up past 80%, adding a dynamic visual element to your audio experience. This system connects to any device using a standard 3.5mm AUX input or headphone port, making it versatile for use with desktops, laptops, PCs, smartphones, and tablets.



Image: The GOgroove BassPULSE 2.1 Computer Speaker system, featuring a subwoofer and two satellite speakers with blue LED accents.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x Powered Subwoofer
- 2 x Satellite Channel Speakers
- 1 x Power Cord
- 1 x 3.5mm Audio Cable

SETUP

Follow these steps to set up your GOgroove BassPULSE 2.1 Computer Speakers:

1. **Position the Speakers:** Place the subwoofer on the floor or a sturdy surface near your computer. Position the two satellite speakers on either side of your monitor for optimal stereo separation.
2. **Connect Satellite Speakers:** Connect the left and right satellite speakers to the "SPEAKER OUT" ports on the back of the subwoofer. Ensure the cables are securely inserted.
3. **Connect Audio Source:** Connect one end of the included 3.5mm audio cable to the "AUDIO IN" port on the back of the subwoofer. Connect the other end to the headphone jack or audio output port of your computer, smartphone, or tablet.

4. **Connect Power:** Plug the power cord into the "POWER IN" port on the back of the subwoofer, then plug the other end into a standard AC wall outlet.
5. **Power On:** Flip the "ON/OFF" switch on the back of the subwoofer to the "ON" position. The blue LED lights on the subwoofer and satellite speakers will illuminate.



Image: The GOgroove BassPULSE 2.1 speaker system arranged on a desk, showcasing the blue LED illumination.



Image: Detailed view of the subwoofer's rear panel, highlighting the connections for satellite speakers, audio input, and power.



CONNECT TO ANY 3.5 MM AUDIO DEVICE




Image: A visual guide demonstrating the connection process for the speaker system with different compatible devices.

OPERATING INSTRUCTIONS

Once your speakers are set up and powered on, you can begin using them:

1. **Adjust Volume:** Use the "VOLUME" knob on the front of the subwoofer to increase or decrease the overall sound level.
2. **Adjust Bass:** Use the "BASS" knob on the front of the subwoofer to control the intensity of the bass output. Turning this knob up past 80% will activate the pulsing blue LED lights.
3. **LED Pulse Feature:** The blue LED accent lights will pulse to the beat of the music when the bass level is sufficiently high. To disable this feature, press the "PULSE" button on the front of the subwoofer. Press it again to re-enable.



Image: Front panel controls of the subwoofer, including volume, bass, and LED pulse button.

Your browser does not support the video tag.

Video: An official overview of the GOgroove BassPULSE Computer Speakers, demonstrating their features and sound capabilities.

CONTROLS OVERVIEW

- **Volume Knob:** Adjusts the master volume level of the entire speaker system. Turn clockwise to increase volume, counter-clockwise to decrease.
- **Bass Knob:** Controls the intensity of the subwoofer's bass output. Increasing the bass past approximately 80% will activate the pulsing LED lights.
- **Pulse Button:** Toggles the blue LED light pulsing effect on and off. When active, the lights will pulse in sync with the bass.
- **Power Switch (Rear):** Turns the entire speaker system on or off.

MAINTENANCE

To ensure the longevity and optimal performance of your speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Do not use liquid cleaners or abrasive materials, as they may damage the finish or electronic components.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Keep cables tidy and untangled to prevent damage and ensure a stable connection.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your speakers, refer to the following common problems and solutions:

Problem	Solution
No sound from speakers.	<ul style="list-style-type: none"> ◦ Ensure the power switch on the subwoofer is ON. ◦ Check all cable connections (audio source, satellite speakers, power). ◦ Increase the volume on both the speakers and your audio source device. ◦ Test with a different audio source or cable.
Sound is distorted or unclear.	<ul style="list-style-type: none"> ◦ Reduce the volume on both the speakers and your audio source. ◦ Adjust the bass level. ◦ Ensure audio cables are fully inserted and not damaged.
Blue LED lights are not pulsing.	<ul style="list-style-type: none"> ◦ Ensure the "PULSE" button is activated. ◦ Increase the bass level using the "BASS" knob (must be above 80% for pulsing). ◦ Ensure music is playing with sufficient bass content.
LED lights are not illuminating at all.	<ul style="list-style-type: none"> ◦ Verify the power connection and that the speakers are turned ON. ◦ If the speakers are working but LEDs are not, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	GOgroove
Model Number	GGBP000100BKUS
Speaker Maximum Output Power	40 Watts (Peak)
Audio Output Mode	Stereo (2.1 Channel)
Connectivity Technology	Wired (3.5mm Auxiliary)
Input Voltage	120 Volts AC
Speaker Type	Subwoofer with Satellite Speakers
Control Method	Knobs (Volume, Bass), Button (Pulse)
Color	Blue and Black
Item Dimensions (D x W x H)	10.63" x 16.38" x 5.63"
Item Weight	0.3 Pounds
Compatible Devices	Laptop, Personal Computer, Smartphone, Tablet

WARRANTY AND SUPPORT

The GOgroove BassPULSE 2.1 Computer Speakers are backed by a **3-Year Manufacturer's Warranty**. For warranty claims, technical support, or any questions regarding your product, please contact GOgroove customer service.

Please retain your proof of purchase for warranty validation.



Image: The GOgroove BassPULSE 2.1 speaker system, highlighting the 3-year limited warranty.