



Manuals.plus /

- › Rev-A-Shelf /
- › Rev-A-Shelf 57 in Swing Out Pantry Kit Instruction Manual

Rev-A-Shelf 4WP18-57-KIT

Rev-A-Shelf 57 in Swing Out Pantry Kit Instruction Manual

Model: 4WP18-57-KIT

Brand: Rev-A-Shelf

PRODUCT OVERVIEW

The Rev-A-Shelf 4WP Series Swing-Out Wood Pantry System is designed to enhance organization within your kitchen cabinets. This system is suitable for both base and tall 36-inch pantry cabinets, offering features such as an industrial piano hinge, adjustable inside door and pantry shelves with chrome rails, and the flexibility to add or remove stylish chrome bars for additional shelf space. The construction utilizes 1/2-inch Maple with a UV cured, clear finish for durability and aesthetic appeal. The complete kit includes two swing-out units and two door storage units with adjustable mounting brackets.



Figure 1: Components of the Rev-A-Shelf Swing Out Pantry Kit.

SETUP AND INSTALLATION

Proper measurement of your cabinet opening is critical for successful installation and optimal functionality of your Rev-A-Shelf pantry system. This kit is designed for cabinet heights of at least 57-3/4 inches without top rails. Most tall pantry cabinets may require the customer to provide a wood divider piece.

Measuring Your Cabinet Opening

Before installation, accurately measure the width, height, and depth of your cabinet opening. Consider the type of cabinet you have (face frame or frameless) as this affects how measurements are taken and how the product fits.

- **Width:** Measure the minimum opening width of your cabinet. Account for any cabinet door hinges, as the product needs to slide in and out without interference. If your product requires the cabinet door to be mounted directly to it, hinge interference is not a concern.
- **Height:** Measure the minimum opening height of your cabinet.
- **Depth:** Measure the interior depth of the cabinet. This is measured from the outside front edge of the cabinet

to the back wall.




Figure 2: Cabinet Measurement Diagram. Ensure sufficient clearance for swing-out mechanisms.

The kit includes two wood swing-out pantries and two door mount units with six adjustable shelves and mounting hardware. Due to the size and weight, this item normally ships via LTL carrier.



Figure 3: Installed Rev-A-Shelf Pantry Kit with units extended.



Figure 4: Pantry Kit in use, demonstrating storage capacity.

SPECIFICATIONS

Brand	Rev-A-Shelf
Model Number	4WP18-57-KIT
Color	Natural
Product Dimensions	7.5"D x 12"W x 57"H
Minimum Cabinet Height (without top rails)	57-3/4"
Mounting Type	Door Mount, Cabinet Floor/Side Mounted
Number of Shelves	6 (adjustable)
Material	Maple Wood
Item Weight	89.9 Pounds
Assembly Required	Yes

MAINTENANCE

To ensure the longevity and smooth operation of your Rev-A-Shelf pantry kit, regular maintenance is recommended:

- **Cleaning:** Wipe down wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the UV cured finish. For chrome rails, use a mild cleaner and dry thoroughly to prevent water spots.
- **Hinges and Slides:** Periodically check the industrial piano hinges and slide mechanisms for smooth operation. If any stiffness is noted, a small amount of silicone-based lubricant can be applied to the moving parts, avoiding contact with wood surfaces.
- **Adjustable Shelves:** Ensure all adjustable shelves are securely seated in their desired positions. Re-adjust as needed for optimal storage.
- **Weight Distribution:** Distribute items evenly across shelves to prevent undue stress on the system.

TROUBLESHOOTING

If you encounter issues with your pantry kit, consider the following common solutions:

- **Units not sliding smoothly:** Check for any obstructions in the cabinet or along the slide tracks. Ensure the tracks are clean and free of debris. Verify that the mounting hardware is tight and properly aligned.
- **Door alignment issues:** If the door-mounted units do not align correctly, re-check the mounting brackets and ensure they are level and securely fastened. Slight adjustments to the mounting can often resolve alignment problems.
- **Hinge orientation (for swing-out units):** Some users have noted that the swing-out units might appear to have hinges on the same side. If this occurs, try rotating one unit 180 degrees and reversing the shelves to achieve a mirror image configuration, allowing for proper swing-out functionality.
- **Missing parts or manufacturing errors:** While rare, if you believe parts are missing or there's a manufacturing defect, refer to the "Support" section for contact information.

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Rev-A-Shelf documentation or contact their customer service directly.

- **Official User Manual (PDF):** For comprehensive instructions and diagrams, you can download the official user manual [here](#).
- **Manufacturer Support:** For specific questions, technical assistance, or to inquire about replacement parts, please visit the [Rev-A-Shelf Store on Amazon](#) or their official website.