

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Topeak](#) /

› [Topeak Prepstand Bicycle Handlebar Stabiliser User Manual](#)

Topeak Prepstand - H/Bar Stabilizer

Topeak Prepstand Bicycle Handlebar Stabiliser User Manual

Model: Prepstand - H/Bar Stabilizer

INTRODUCTION

The Topeak Prepstand Bicycle Handlebar Stabiliser is designed to secure your bicycle's front wheel and handlebar when the bike is mounted in a workstand. This accessory helps prevent the handlebar from turning, providing a stable platform for maintenance and repairs. It is compatible with most mountain and road bikes.

SETUP INSTRUCTIONS

Follow these steps to properly set up your handlebar stabiliser:

1. **Prepare your bicycle:** Ensure your bicycle is securely mounted in a compatible workstand.
2. **Position the stabiliser:** Place the main body of the stabiliser over the bicycle's top tube.
3. **Attach to top tube:** Use the integrated strap mechanism to firmly attach the stabiliser to the top tube. Ensure it is snug but not overtightened, allowing for minor adjustments.
4. **Secure the handlebar:** Extend the stabiliser arm and hook it around the handlebar. Adjust the length as needed to hold the handlebar in a fixed position, preventing it from rotating.
5. **Verify stability:** Gently attempt to turn the handlebar to confirm it is securely held by the stabiliser.



Image 1: The Topeak Prepstand Bicycle Handlebar Stabiliser shown attached to a bicycle's top tube and handlebar, providing stability during maintenance.

OPERATING INSTRUCTIONS

Once the stabiliser is set up, it will maintain the front wheel and handlebar in a straight position. This allows for easier access to components for cleaning, adjustment, and repair without the handlebar swinging freely.

- The stabiliser is designed for use with all mountain and road bikes.
- Ensure the stabiliser is always securely fastened before beginning any work on the bicycle.
- Adjust the stabiliser's length to accommodate different handlebar widths and bike geometries.

MAINTENANCE

To ensure the longevity and proper function of your Topeak Prepstand Bicycle Handlebar Stabiliser, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the stabiliser with a damp cloth after use to remove dirt and grime. Avoid harsh chemicals.
- **Inspection:** Periodically check all components, especially the strap and hooks, for signs of wear or damage.
- **Storage:** Store the stabiliser in a dry place away from direct sunlight when not in use.

TROUBLESHOOTING

If you encounter issues with your handlebar stabiliser, consider the following:

- **Stabiliser not holding handlebar securely:** Ensure the strap on the top tube is tight and the handlebar hook is

properly engaged and adjusted to the correct length.

- **Difficulty fitting:** Verify that the stabiliser is compatible with your bicycle's top tube and handlebar design. Some unusually shaped handlebars or very thick top tubes may require careful positioning.

SPECIFICATIONS

Feature	Detail
Brand	Topeak
Model Name	Prepstand - H/Bar Stabilizer
Part Number	TW001-SP03
Material	Aluminum / Plastic
Color	Black
Item Weight	100 Grams
Product Dimensions (LxW)	13.39"L x 3.94"W (34x9.4 cm x10 cm)
Included Components	Stabilizer
Suggested Users	Unisex-adult
Sport Type	Cycling

SUPPORT INFORMATION

For further assistance, product inquiries, or warranty information, please visit the official Topeak brand store or contact their customer support.

Official Brand Store: [Topeak Store on Amazon](#)

