

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Barbie](#) /

› [Barbie Pink Color Change Mermaid Doll Instruction Manual T7404](#)

## Barbie T7404

# Barbie Pink Color Change Mermaid Doll Instruction Manual

Model: T7404

[Safety Information](#)   [Product Overview](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

**WARNING: CHOKING HAZARD - Small parts.** Not for children under 3 years of age. This product contains small components that may pose a choking risk to young children. Adult supervision is recommended during play.

## 2. PRODUCT OVERVIEW

The Barbie Pink Color Change Mermaid Doll is designed for interactive water play. This doll features a mermaid tail and hair that change color when exposed to cold water. The doll includes a sculpted bodice and a detailed mermaid tail.



Image 1: Barbie Pink Color Change Mermaid Doll. This image displays the doll in its primary pink color scheme, highlighting its mermaid tail and hair.

### Key Features:

- Color-changing hair and tail when exposed to icy cold water.
- Sculpted glittery bodice.
- Highly styled mermaid tail.
- Designed for water play.

### 3. SETUP

- Unboxing:** Carefully remove the doll from its packaging. Retain packaging for future reference if needed.
- Initial Inspection:** Examine the doll for any visible damage or manufacturing defects.
- Preparation for Play:** Ensure the doll is clean and dry before its first use in water.

## 4. OPERATING INSTRUCTIONS

The primary feature of this doll is its color-changing ability. Follow these steps to activate the color change:

- Prepare Water:** Fill a container or bathtub with **icy cold water**. The colder the water, the more pronounced and effective the color change will be.
- Submerge Doll:** Gently submerge the doll's hair and tail into the icy cold water.
- Observe Color Change:** The doll's hair and tail are designed to change color upon contact with cold water. The color will revert to its original shade as the doll warms up.
- Repeat:** For repeated color changes, ensure the doll returns to its original temperature before re-submerging in cold water.

*Note: Warm or hot water will not activate the color change feature. Only icy cold water will produce the desired effect.*

## 5. MAINTENANCE

- Cleaning:** After water play, rinse the doll with clean, fresh water to remove any soap residue or impurities.
- Drying:** Thoroughly dry the doll after each use. Pay special attention to areas where water might collect, such as joints or where the tail meets the body, to prevent mold growth. Air dry completely before storing.
- Storage:** Store the doll in a clean, dry place away from direct sunlight and extreme temperatures.
- Hair Care:** The doll's hair is designed to resist tangling. If tangles occur, gently comb with a wide-tooth comb while wet.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Color change not occurring or is faint.	Water is not cold enough. Doll has not returned to original temperature.	Ensure water is <b>icy cold</b> . Allow the doll to warm up completely before re-attempting color change with cold water.
Mold or discoloration appearing on the doll.	Improper drying after water play. Water trapped in crevices.	Thoroughly dry the doll after each use, especially in joints and seams. Ensure complete air drying before storage.
Hair tangling.	Rough handling or prolonged exposure to harsh conditions.	Gently comb the doll's hair with a wide-tooth comb while wet. Avoid excessive pulling.

## 7. SPECIFICATIONS

**Model Number:** T7404

**Product Dimensions:** 5 x 2.38 x 12.75 inches

**Item Weight:** 6.4 ounces

**Manufacturer:** Mattel

**Recommended Age:** 36 months - 7 years

**ASIN:** B004CFBYHW

## 8. WARRANTY AND SUPPORT

For warranty information and customer support regarding your Barbie Pink Color Change Mermaid Doll (Model T7404), please refer to the official Mattel website or contact their customer service department directly. Contact details are typically provided on the product packaging or on the manufacturer's official website.

**Manufacturer:** Mattel

**Website:** [www.mattel.com](http://www.mattel.com) (Please check the official website for the most current contact information and support resources.)