

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rohl](#) /

› [Rohl Perrin and Rowe Provence Lever Handle Bridge Kitchen Faucet U.4756L-STN-2 Instruction Manual](#)

Rohl U.4756L-STN-2

Rohl Perrin and Rowe Provence Bridge Kitchen Faucet Instruction Manual

MODEL: U.4756L-STN-2

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Rohl Perrin and Rowe Provence Lever Handle Bridge Kitchen Faucet with Sidespray Rinse, model U.4756L-STN-2. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product.

Key features of this faucet include:

- Durable brass construction
- Reliable ceramic disc control cartridge
- 9-inch reach swivel spout for versatile use
- Insulated brass side spray for convenient rinsing
- Designed for deck mounting with a maximum installation depth of 2 3/8 inches

Product Overview



This image displays the Rohl Perrin and Rowe Provence Bridge Kitchen Faucet in a satin nickel finish. It features two lever handles, a high-arc swivel spout, and a separate sidespray unit. The design is traditional, with decorative elements on the base and handles.

Setup and Installation

Professional installation is recommended for this product. Ensure all local plumbing codes are followed.

- Preparation:** Turn off the main water supply to your kitchen. Clear the area under the sink and ensure you have all necessary tools and components.
- Mounting Surface:** This faucet is designed for deck mounting and requires three holes. Ensure your sink or countertop has the appropriate hole configuration. The maximum installation depth on the deck is 2 3/8 inches.
- Faucet Placement:** Position the faucet body and handles into the pre-drilled holes on your sink or countertop.
- Secure Faucet:** From underneath the sink, secure the faucet assembly using the provided mounting hardware. Tighten nuts evenly to prevent wobbling.
- Connect Water Lines:** Connect the hot and cold water supply lines to the corresponding inlets on the faucet. Use

thread sealant tape on all threaded connections to prevent leaks.

6. **Install Sidespray:** Insert the sidespray hose through its designated hole and connect it to the faucet's sidespray port. Secure the sidespray base from underneath.
7. **Test:** Once all connections are secure, slowly turn on the main water supply and check for any leaks. Operate the faucet and sidespray to ensure proper function.

Operating Instructions

Your Rohl Provence Bridge Kitchen Faucet features two lever handles for precise control of water temperature and flow.

- **Water Flow:** Lift either lever handle to initiate water flow. The further the handle is lifted, the greater the flow.
- **Temperature Control:** The left handle typically controls hot water, and the right handle controls cold water. Adjust both handles to achieve your desired water temperature.
- **Sidespray:** To use the sidespray, simply lift it from its holder and press the trigger. Release the trigger to stop the spray. Ensure the main faucet handles are open for water to flow to the sidespray.
- **Spout Swivel:** The high-arc spout can swivel 360 degrees, allowing for flexible use across multiple sink basins.

The maximum flow rate for this faucet is 1.8 gallons per minute (GPM).

Maintenance

Regular maintenance will help preserve the finish and functionality of your faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the satin nickel finish.
- **Aerator:** Periodically unscrew and clean the aerator at the tip of the spout to remove any mineral buildup that may restrict water flow.
- **Leaks:** If you notice any drips or leaks, check all connections and ensure they are tight. If the issue persists, the ceramic disc control cartridge may need inspection or replacement.
- **Sidespray:** Ensure the sidespray hose moves freely and is not kinked. Clean the spray nozzles if water flow becomes uneven.

Troubleshooting

Problem	Possible Cause	Solution
Low water flow	Clogged aerator; partially closed shut-off valve; debris in water lines.	Clean or replace aerator; ensure shut-off valves are fully open; flush water lines.
Faucet drips or leaks	Loose connections; worn ceramic disc cartridge.	Tighten all connections; inspect and replace cartridge if necessary.
Sidespray not working or weak spray	Main faucet handles not open; clogged spray nozzles; kinked hose.	Ensure main faucet is on; clean spray nozzles; straighten hose.
Water temperature inconsistent	Improper adjustment of hot/cold handles; issues with water heater.	Adjust handles carefully; consult a plumber for water heater issues.

Specifications

- **Brand:** Rohl
- **Model Name:** U.4756L-STN-2
- **Material:** Brass (faucet), Metal (general)
- **Finish Type:** Satin Nickel
- **Number of Handles:** 2
- **Spout Reach:** 9 Inches
- **Maximum Flow Rate:** 1.8 Gallons Per Minute
- **Mounting Type:** Deck Mount
- **Hole Count:** 3
- **Product Dimensions:** 9 x 8 x 10.5 inches
- **Item Weight:** 10 Pounds
- **Special Features:** Pull Down Sprayer, Rust Resistant, Water Saving

Warranty Information

This Rohl faucet is covered by a **Limited Lifetime Warranty**. Please refer to the official Rohl warranty documentation for complete details regarding coverage, terms, and conditions. Keep your proof of purchase for warranty claims.




Support

For further assistance, technical support, or to inquire about replacement parts, please contact Rohl customer service. Contact information can typically be found on the official Rohl website or included in the product packaging.



Related Documents - U.4756L-STN-2

	<p><u>ROHL Bar/Food Prep Kitchen Faucet Installation Manual</u></p> <p>Official installation instructions and parts list for the ROHL Bar/Food Prep Kitchen Faucet. Includes helpful tools, step-by-step assembly, and contact information for warranty and support.</p>
	<p><u>Rohl Volume Control or Diverter Trim Installation Manual</u></p> <p>Detailed installation instructions for Rohl Volume Control or Diverter Trim (Model INS12615A, Rev. 10/22). Includes parts list, helpful tools, and contact information for Rohl, Riobel, Perrin & Rowe, Shaws, and Victoria + Albert brands in the US and Canada.</p>

	<p>ROHL R1040R & R1062BO Installation Guide, Care, and Warranty</p> <p>Comprehensive installation instructions, care and maintenance guidelines, and warranty details for ROHL R1040R rough-in valves and R1062BO three-way diverter valves. Includes product specifications, parts lists, and finish care advice.</p>
	<p>ROHL Edwardian™ Thermostatic & Pressure Balance Valve Trim - Installation, Specifications, and Product Catalog</p> <p>Comprehensive guide for ROHL plumbing fixtures, including the Edwardian™ U.TEW44W1 valve trim, 2-Way Type T/P Coaxial Valve Rough, handshowers, showerheads, and accessories. Features installation instructions, parts lists, product specifications, finishes, warranty information, and customer support.</p>
	<p>Rohl TTD06HF1LM Series Traditional Single Hole Floor Mount Tub Filler Trim - Illustrated Parts</p> <p>Comprehensive illustrated parts list for the Rohl TTD06HF1LM Series Traditional Single Hole Floor Mount Tub Filler Trim. Includes detailed part numbers, available finishes (Antique Gold, Matte Black, Polished Chrome, Polished Nickel, Satin Nickel, Unlacquered Brass), and contact information for warranty and support from Rohl.</p>
	<p>ROHL R2012D Pressure Balance Rough Without Diverter Installation Guide</p> <p>Explore the ROHL R2012D Pressure Balance Rough Without Diverter, a key component for luxurious showers. This guide details features, specifications, installation, and warranty information from ROHL.</p>