

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fossil](#) /
- › [Fossil Women's Riley Quartz Stainless Steel Multifunction Watch - Instruction Manual](#)

Fossil ES2811

Fossil Women's Riley Quartz Stainless Steel Multifunction Watch - Instruction Manual

Model: ES2811 | Brand: Fossil

1. INTRODUCTION

Welcome to the world of Fossil watches. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new Fossil Women's Riley Quartz Stainless Steel Multifunction Watch (Model ES2811). Designed for elegance and functionality, this timepiece features a rose gold-tone finish, a textured rose dial, and multifunction capabilities. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.





Figure 1: Front view of the Fossil Women's Riley Quartz Stainless Steel Multifunction Watch in Rose Gold.

2. KEY FEATURES

- **Signature Riley Style:** Features a 45-stone topping with a rose gold-tone finish and a textured rose dial.
- **Multifunction Movement:** Accurate Quartz movement with multifunction analog display, including day, date, and 24-hour time functions.
- **Durable Construction:** 38mm rose gold stainless steel case with a hardened mineral crystal lens that resists scratches.
- **Comfortable Band:** Rose gold, durable stainless steel bracelet band with a secure fold-over clasp closure. Links can be removed for a customized fit.
- **Water Resistance:** Water resistant up to 100 meters (330 feet) or 10 ATM. Suitable for bathing, swimming, or snorkeling, but not for scuba diving.



Figure 2: The Fossil Riley watch worn on a wrist, showcasing its elegant design.

3. SETUP

3.1 Initial Setup: Setting Time and Date

Your Fossil Riley watch is equipped with a quartz multifunction movement. To set the time and date:

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch) to position 2 for time setting.
2. **Set the time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. **Set the date/day:** For multifunction dials, refer to the specific instructions for your watch model. Typically, a slight pull or push of the crown to an intermediate position (position 1) allows for quick date/day adjustment. Rotate the crown until the correct date and day are displayed.
4. **Push in the crown:** Once set, push the crown back into its original position (position 0) to start the watch.





Figure 3: Side view of the watch, highlighting the crown for time and date adjustments.

3.2 Adjusting the Bracelet

The stainless steel bracelet can be adjusted by removing or adding links to achieve a comfortable fit. It is recommended to have this done by a professional jeweler to avoid damaging the watch or bracelet.



FOSSIL

ES 2811 251010

ALL STAINLESS



Figure 4: Close-up of the watch clasp and bracelet, showing the secure fold-over closure.

4. OPERATING YOUR WATCH

4.1 Multifunction Dials

Your Riley watch features three sub-dials that provide additional functionality:

- One sub-dial displays the **day of the week**.
- Another sub-dial indicates the **date**.
- The third sub-dial shows **24-hour time**.

These functions are automatically synchronized with the main time setting once properly adjusted.

4.2 Water Resistance

The watch has a water resistance rating of 10 ATM (Atmospheres), equivalent to 100 meters (330 feet). This means it is suitable for:

- Accidental splashes
- Rain
- Bathing
- Swimming
- Snorkeling

Important: It is **not** suitable for scuba diving. Avoid operating the crown or pushers while the watch is wet or submerged to prevent water ingress.

4.3 Product Overview Video

Video 1: An official product video showcasing the Fossil Women's Riley Quartz Stainless Steel Chronograph Watch in Rose Gold (Model: ES2811), highlighting its features and design.

Video 2: An official product video demonstrating the Fossil Women's Riley Stainless Steel Crystal-Accented Multifunction Quartz Watch, providing a detailed view of its appearance and functions.

5. CARE AND MAINTENANCE

Proper care will help maintain the appearance and functionality of your Fossil watch:

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by thorough rinsing and drying.
- **Avoid Chemicals:** Do not expose your watch to harsh chemicals, solvents, or detergents, as these can damage the finish and internal components.
- **Battery Replacement:** The watch uses 1 Lithium Metal battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by an authorized Fossil service center or a professional watchmaker to ensure proper sealing and water resistance.
- **Storage:** When not in use, store your watch in its original Fossil collector tin box to protect it from dust, moisture, and scratches.



Figure 5: The Fossil collector tin box, ideal for storing and protecting your watch.

6. TROUBLESHOOTING

If you encounter any issues with your watch, try the following basic troubleshooting steps:

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time/Date incorrect:** Refer to section 3.1 for instructions on how to properly set the time and date.
- **Condensation under crystal:** This may indicate a loss of water resistance. Avoid further exposure to water and seek professional service immediately.
- **Bracelet discomfort:** Ensure the bracelet is properly adjusted. If it's too tight or too loose, consider having links added or removed by a professional.

For more complex issues or repairs, please contact Fossil customer support or an authorized service center.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	ES2811
Brand	Fossil
Material	Stainless Steel
Case Diameter	38mm

Feature	Detail
Band Width	18mm
Movement	Quartz Multifunction
Water Resistance	10 ATM (100 meters / 330 feet)
Battery	1 Lithium Metal battery (included)
Product Dimensions	0.59 x 0.59 x 0.59 inches; 4.07 ounces
Country of Origin	China

8. WARRANTY AND SUPPORT

Fossil watches typically come with a limited warranty covering manufacturing defects. Please refer to the warranty card included with your purchase for specific terms and conditions, or visit the official Fossil website for detailed warranty information.

For additional support, including detailed user guides or service inquiries, you can visit the official Fossil website or contact their customer service. A digital version of the user guide may also be available:

[Download User Manual
\(PDF\)](#)

[Visit the Fossil Brand
Store](#)