

[manuals.plus](#) /

› [Invicta](#) /

› [Invicta Men's Chronograph Watch Model IBI90242-003 Instruction Manual](#)

Invicta IBI90242-003

Invicta Men's Chronograph Watch Model IBI90242-003 Instruction Manual

Your guide to setting up, operating, and maintaining your Invicta timepiece.

1. INTRODUCTION

This manual provides detailed instructions for the proper use and care of your Invicta Men's Chronograph Watch, Model IBI90242-003. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.



Image 1: Front view of the Invicta Men's Chronograph Watch Model IBI90242-003, showcasing its black dial, gold-tone case, and black leather band.

2. PRODUCT OVERVIEW

The Invicta Men's Chronograph Watch IBI90242-003 features a sophisticated design with practical functionalities. Key components include:

- **Case:** Gold-tone stainless steel, 44mm diameter x 12.5mm thick.

- **Dial:** Black dial with luminous hands and Roman numeral hour markers.
- **Movement:** Japanese quartz movement (VD53 Caliber), assembled in Japan.
- **Band:** Black leather band, 230mm L x 22mm W, with a buckle clasp.
- **Crystal:** Mineral crystal for durability.
- **Crown:** Push/pull crown.
- **Bezel:** Stationary stainless steel bezel.
- **Subdials:** Functional subdials for 60-minute, 60-second, and 24-hour measurements.
- **Water Resistance:** 50 meters (165 feet), suitable for washing hands, light splashes, and swimming in shallow depths.



Image 2: Exploded view highlighting the watch's crown, bezel, case size (44mm), and mineral crystal type.




Image 3: Close-up of the black leather band and buckle clasp, designed for easy size adjustment.

MOVEMENT

QUARTZ CHRONOGRAPH
To measure and keep track of different sets of time in addition to the current time on a dial. A true celebration of traditional watchmaking.



TIMEKEEPING

Second, Minute and 24 hour subdial; for more precise timekeeping.

DATE-DISPLAY

Accurately keep track of the date with easily visible date display

Image 4: The watch dial illustrating the quartz chronograph movement with subdials for precise timekeeping and a date display.

3. SETUP INSTRUCTIONS

3.1 Setting the Time

1. Pull the crown out to position 2.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Push the crown back into position 1 to start the watch.

3.2 Setting the Date

1. Pull the crown out to position 1.
2. Turn the crown clockwise to set the date.
3. Push the crown back into its normal position.

3.3 Chronograph Operation

The chronograph function allows for precise timing of events.

1. **Start/Stop:** Press the upper pusher button to start and stop the chronograph.
2. **Reset:** While the chronograph is stopped, press the lower pusher button to reset all chronograph hands to their zero positions.

4. OPERATING GUIDELINES

4.1 Water Resistance

Your watch is water resistant up to 50 meters (5 ATM). This means it is suitable for:

- Washing hands
- Light splashes
- Swimming in shallow depths

Important: Do not operate the crown or pushers while the watch is wet or submerged in water. This can compromise the water resistance seal.



Image 5: Water resistance chart indicating the 50-meter rating for this watch, suitable for activities like hand washing and shallow swimming.

4.2 General Use

Avoid exposing your watch to extreme temperatures, strong magnetic fields, or harsh chemicals, as these can affect its accuracy and appearance.

5. MAINTENANCE

5.1 Cleaning

Wipe the watch case and crystal with a soft, dry cloth. For the leather band, avoid excessive moisture and clean with a specialized leather cleaner if necessary.

5.2 Battery Replacement

This watch uses an SR920SW battery. When the watch stops or the second hand moves erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to maintain water resistance and ensure proper function.

5.3 Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. The original packaging or a watch box is ideal for protection.

6. TROUBLESHOOTING

- **Watch not running:** Check if the crown is pushed in completely to position 0. If it is, the battery may need replacement.
- **Incorrect time/date:** Refer to Section 3 for instructions on setting the time and date.
- **Chronograph not resetting to zero:** This may require a professional adjustment.

For issues not covered here, please contact Invicta customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	IBI90242-003
Case Material	Gold-tone Stainless Steel
Case Diameter	44mm
Case Thickness	12.5mm
Dial Color	Black
Movement	Japanese Quartz (VD53 Caliber)
Band Material	Leather
Band Length	230mm
Band Width	22mm
Crystal Type	Mineral
Water Resistance	50 meters (5 ATM)
Battery Type	SR920SW (included)
Product Dimensions	5.91 x 5.91 x 5.91 inches; 5.6 ounces

8. WARRANTY AND SUPPORT

Invicta watches typically come with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, service, or warranty claims, please contact Invicta customer service directly or visit their official website.

Online Resources: For additional information and support, visit the [Invicta Store on Amazon](#).

9. PRODUCT VIDEOS

9.1 Invicta Men's 90242-003 Watch Overview

Your browser does not support the video tag.

Video 1: An official merchant video providing a general overview of the Invicta Men's 90242-003 watch, showcasing its design and features.