

[Manuals.plus](#) /

- › [Honeywell Safes & Door Locks](#) /
- › Honeywell LHLP1103G 30-Minute Fire Safe Waterproof Chest User Manual

## Honeywell Safes & Door Locks 1103

# Honeywell LHLP1103G 30-Minute Fire Safe Waterproof Chest User Manual

Model: 1103 | Brand: Honeywell Safes & Door Locks

## INTRODUCTION

This manual provides essential information for the safe and effective use of your Honeywell LHLP1103G 30-Minute Fire Safe Waterproof Chest. Please read all instructions carefully before setup and operation to ensure optimal protection for your valuables.



Image: The Honeywell LHLP1103G Fire Safe Waterproof Chest in its closed position, showcasing its

*compact and portable design.*

## SAFETY INFORMATION

---

- Always keep keys in a secure location away from the safe.
- Do not store flammable liquids or pressurized containers inside the safe.
- Ensure the safe is properly latched and locked to maintain fire and water resistance.
- Regularly inspect the safe for any signs of damage to the seals or locking mechanism.

## SETUP

---

1. **Unpacking:** Carefully remove the safe from its packaging. Inspect for any shipping damage.
2. **Key Identification:** Your safe comes with two keys. Identify and store one key in a safe, separate location as a backup.
3. **Initial Airing:** It is recommended to open the safe for at least 30 minutes weekly to allow for air circulation and prevent potential moisture buildup. This is crucial for maintaining the integrity of stored documents.
4. **Placement:** Place the safe in a location that is easily accessible in case of an emergency, yet secure from unauthorized access. The integrated carry handle facilitates transport.

**Honeywell** | SAFES & DOOR LOCKS

# A Security **Solution**

for homes, offices, dorm rooms, travel, and more.



*Image: The Honeywell LHL1103G safe with its exterior dimensions labeled, indicating its compact size for various placements.*

## OPERATING INSTRUCTIONS

### 1. Opening the Safe:

- Insert the key into the lock and turn it to the unlocked position.
- Press the two side latches inward to release the lid.
- Lift the lid to open the safe.

### 2. Placing Items:

- The interior is designed to accommodate important letter and A4-sized documents, digital media (USB drives, CDs, DVDs), and other small valuables.
- Documents may require a slight bend to fit perfectly flat due to the interior dimensions.

### 3. Closing and Locking:

- Lower the lid until it is fully seated.
- Engage both side latches by pushing them outwards until they click securely into place.

- Turn the key to the locked position and remove it. Ensure the key is removed to prevent it from getting stuck.



*Image: The safe open, revealing various documents, a passport, and cash stored inside, demonstrating its capacity for important items.*

*Video: An official overview of the Honeywell Security Chest Fire & Water Series, demonstrating its features and ease of use for protecting valuables.*

## MAINTENANCE

- **Regular Airing:** To prevent moisture and mildew, open the safe for 30 minutes every week. This allows any trapped humidity to escape.
- **Cleaning:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the interior is dry before closing.
- **Seal Inspection:** Periodically check the waterproof seal around the lid for any cracks or damage. A compromised seal can affect water resistance.
- **Key Care:** Keep keys clean and dry. Avoid forcing the key if it feels stiff; a small amount of graphite lubricant can be applied to the lock if necessary.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Key is stuck or broken in the lock.	Forcing the key, misalignment, or internal lock issue.	Do not force the key. If stuck, try gently wiggling it while applying slight pressure. If broken, contact customer support for assistance.
Moisture or mildew inside the safe.	Insufficient air circulation.	Ensure weekly airing of the safe for 30 minutes. Place desiccant packets inside if humidity is a persistent issue.
Lid does not close or latch properly.	Obstruction, misaligned lid, or damaged latch.	Check for any items blocking the lid. Ensure the lid is aligned correctly before pressing the latches. Inspect latches for damage.

## SPECIFICATIONS

- **Model:** 1103
- **Exterior Dimensions:** 12.6"D x 15.98"W x 6.57"H
- **Interior Dimensions:** 3.7"H x 13.1"W x 8.5"D
- **Capacity:** 0.24 Cubic Feet (7.3 Liters)
- **Item Weight:** 27.4 Pounds
- **Fire Protection:** UL Certified 30-minute fire protection up to 1550°F (843°C)
- **Water Protection:** Certified 100-hour waterproof protection, even when fully submerged up to 39 inches (1 meter)
- **Lock Type:** Key Lock (2 keys included)
- **Material:** ABS Plastic
- **Special Features:** Fireproof, Waterproof, Carry Handle

# Fire & Waterproof **Protection**

for small valuables, essential papers, cash, electronics, & more



## **FIREPROOF** PROTECTION

UL Certified 30-minute fireproof protection at temperatures up to 1550°F / 843°C (has insulated walls); **lifetime after-fire replacement guarantee**



## **WATERPROOF** PROTECTION

Certified 100-hour waterproof protection up to 1 meter or 3.28 feet; **waterproof even when fully submerged** (up to 1M above top of chest)



*Image: Visual representation of the safe's fire and waterproof capabilities, highlighting its protective features.*

## **WARRANTY**

This Honeywell safe comes with a **Lifetime After-fire Guarantee**. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official Honeywell Safes & Door Locks website.

## **SUPPORT**

For further assistance, technical support, or warranty claims, please contact Honeywell Safes & Door Locks customer service. Refer to the contact information provided in your product packaging or on the official brand website.