

[manuals.plus](#) /

› [Disney](#) /

› [Disney Tangled DVD User Guide WD10633400DVD](#)

Disney WD10633400DVD

Disney Tangled DVD User Guide

Model: WD10633400DVD

1. INTRODUCTION

This user guide provides essential information for the operation and care of your Disney Tangled DVD. This DVD contains the animated feature film 'Tangled', released in 2010, and is designed for playback on standard DVD players.




Image 1.1: Front cover of the Disney Tangled DVD. The cover features Rapunzel, Flynn Rider, and Maximus the horse.

2. SETUP

To begin viewing the Disney Tangled DVD, follow these steps:

1. Ensure your DVD player is properly connected to your television or display device. Refer to your DVD player's instruction manual for connection details.

2. Open the DVD tray or slot on your DVD player.
3. Carefully place the Tangled DVD disc into the tray or slot with the label side facing up.
4. Close the DVD tray or allow the player to automatically load the disc.



Image 2.1: The Tangled DVD disc shown inside its protective case, illustrating the disc's appearance.

3. OPERATING

Once the DVD is loaded, the main menu should appear on your screen. Use your DVD player's remote control to navigate.

- **Play Movie:** Select 'Play' or 'Start Movie' from the main menu to begin playback of the film.
- **Scene Selection:** Navigate to 'Scene Selection' or 'Chapters' to choose a specific part of the movie to watch.
- **Audio/Subtitles:** Access the 'Audio' or 'Subtitles' menu to select your preferred language for audio (English, Spanish, French) or subtitles (English, Spanish).
- **Special Features:** If available, select 'Special Features' to view bonus content.
- **Basic Controls:** Use the Play, Pause, Stop, Fast Forward, Rewind, and Skip (Chapter Next/Previous) buttons on your remote control during playback.

4. MAINTENANCE

Proper care of your DVD will ensure its longevity and optimal performance.

- **Cleaning:** If the disc becomes dirty or smudged, gently wipe the playback side (silver side) with a soft, lint-free cloth. Wipe from the center of the disc outwards in a straight line. Do not use abrasive materials or harsh cleaning chemicals.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity. Avoid stacking discs without their cases, as this can lead to scratches.
- **Handling:** Always hold the disc by its edges or by placing a finger through the center hole to avoid touching the

playback surface.

5. TROUBLESHOOTING

If you encounter issues while playing your DVD, consider the following common solutions:

- **Disc Not Playing/Reading:**

- Ensure the disc is inserted correctly with the label side facing up.
- Check the disc for visible scratches or smudges. Clean the disc as described in the Maintenance section.
- Try playing another DVD to determine if the issue is with the player or the disc.
- Restart your DVD player.

- **Skipping or Freezing:**

- Clean the disc thoroughly.
- Ensure the DVD player is on a stable surface to prevent vibrations.

- **No Audio/Video:**

- Verify that your DVD player is correctly connected to your TV/display and audio system.
- Check the audio and video input selections on your TV.
- Ensure the correct audio track is selected from the DVD menu.

6. SPECIFICATIONS

Detailed technical specifications for the Disney Tangled DVD (Model WD10633400DVD).

Feature	Detail
Title	Tangled
Brand	Disney
Model Number	WD10633400DVD
ASIN	B004G600A4
UPC	0786936810608
Media Format	NTSC, Subtitled
Number of Discs	1
Aspect Ratio	1.78:1
Run Time	1 hour and 40 minutes
MPAA Rating	PG (Parental Guidance Suggested)
Languages (Audio)	English (Dolby Digital 5.1), Spanish (Dolby Digital 5.1), French (Dolby Digital 5.1)
Subtitles	English, Spanish
Release Date	March 29, 2011
Product Dimensions	0.6 x 5.4 x 7.5 inches; 2.72 ounces
Director(s)	Byron Howard, Nathan Greno

Writer(s)	Dan Fogelman
Studio	WALT DISNEY ANIMATION



Image 6.1: Back cover of the Disney Tangled DVD, displaying the film's synopsis, technical specifications, and UPC barcode.

7. SUPPORT

For further assistance or inquiries regarding your Disney Tangled DVD, please refer to the contact information provided by the retailer or the official Disney customer support channels. Specific warranty information for this media product is typically covered under general consumer electronics policies or retailer return policies.

Related Documents - WD10633400DVD

	<p><u>Disney DVD Bingo Game: How to Play and Game Features</u></p> <p>A guide to playing Disney DVD Bingo, a family-friendly interactive game featuring Disney characters. Learn the rules for standard, blackout, and pattern bingo, understand the bingo caller options, and discover how film clips function as wild cards.</p>
	<p><u>Setting Up a Disney MagicMobile Pass for iPhone, Apple Watch, and Android Devices</u></p> <p>Learn how to set up and use your Disney MagicMobile Pass on iPhone, Apple Watch, and Android smartphones with Google Wallet for seamless access to theme parks, Lightning Lane entrances, and more.</p>
	<p><u>Disney's Animal Kingdom Guide for Guests with Disabilities</u></p> <p>A comprehensive guide for guests with disabilities visiting Disney's Animal Kingdom Theme Park, detailing accessibility services, amenities, attractions, dining, and park policies to ensure a safe and enjoyable experience.</p>
	<p><u>The Little Mermaid Twinkle Trove Activity Gym - Assembly and Care Instructions</u></p> <p>Comprehensive guide for the Disney's The Little Mermaid Twinkle Trove Activity Gym, including safety warnings, assembly instructions, care and cleaning tips, and battery information. Features multilingual support.</p>
	<p><u>Disney Princess Dream Journey Instructions - Game Guide</u></p> <p>Official instructions for playing the Disney Princess Dream Journey DVD game. Learn how to set up the board, play puzzles, and win the game.</p>
	<p><u>Disney's Hollywood Studios Guide for Guests with Disabilities</u></p> <p>A comprehensive guide for guests with disabilities visiting Disney's Hollywood Studios, detailing accessibility services, amenities, transportation, dining, shopping, and attraction information.</p>