

CLP Saddle

CLP Saddle Bar Stool Instruction Manual

Model: Saddle (B004G9AE5C)

1. INTRODUCTION

Thank you for purchasing the CLP Saddle Bar Stool. This manual provides essential information for the safe assembly, setup, operation, and maintenance of your new bar stool. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the bar stool on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the components.
- The maximum weight capacity for this bar stool is **120 kg (264 lbs)**. Do not exceed this limit.
- Keep children away from the assembly area. Small parts may pose a choking hazard.
- Always ensure the stool is stable before sitting.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all the following components are included in your package:

- Seat (Plastic)
- Gas Lift Cylinder
- Footrest Ring (Chrome Metal)
- Base Plate (Chrome Metal with Rubber Ring)
- Assembly Hardware (Screws, Washers, Allen Key)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your CLP Saddle Bar Stool:

1. **Attach the Gas Lift to the Base:** Carefully insert the wider end of the gas lift cylinder into the central hole of the chrome base plate. Ensure it is seated firmly.
2. **Install the Footrest:** Slide the chrome footrest ring over the gas lift cylinder. The footrest should rest on the support ring on the gas lift.
3. **Connect the Seat:** Align the mounting plate under the plastic seat with the top of the gas lift cylinder. Secure the seat to the gas lift using the provided screws and washers. Use the Allen key to tighten them securely, but do not overtighten.
4. **Final Check:** Once assembled, gently test the stability of the stool before use. Ensure all connections are secure.





Image: An assembled CLP Saddle Bar Stool, showing the seat, gas lift, footrest, and base.

5. SETUP

Place the assembled bar stool on a flat, stable surface. The rubber ring on the base is designed to prevent scratches on your floor. Ensure there is adequate space around the stool for comfortable use and swiveling.



Image: A CLP Saddle Bar Stool with key dimensions indicated: total height (87 cm), adjustable seat height (60-81 cm), seat width (37 cm), seat depth (37 cm), and base diameter (39 cm). The stool weighs 6 kg and has a maximum load of 120 kg.

6. OPERATING INSTRUCTIONS

6.1. Height Adjustment

The CLP Saddle Bar Stool features a gas lift mechanism for easy height adjustment:

- **To raise the seat:** Stand up from the stool and pull the lever located under the seat upwards. The seat will automatically rise. Release the lever when the desired height is reached.
- **To lower the seat:** Sit on the stool and pull the lever upwards. The seat will lower under your weight. Release the lever when the desired height is reached.

6.2. Swivel Function

The seat of the bar stool can rotate 360 degrees. Simply turn the seat in the desired direction while seated or standing.



Image: Side view of the CLP Saddle Bar Stool, highlighting the lever for height adjustment located beneath the seat.

7. MAINTENANCE

7.1. Cleaning

- **Plastic Seat:** Wipe the plastic seat surface with a soft, damp cloth and a mild detergent. Avoid

abrasive cleaners or solvents, as these can damage the plastic.

- **Chrome Parts:** Clean chrome metal parts with a soft, dry cloth. For stubborn marks, use a chrome-specific cleaner and polish gently.
- Do not immerse any part of the stool in water.

7.2. General Care

- Regularly check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid exposing the stool to direct sunlight or extreme temperatures for prolonged periods, as this may affect the material's durability and color.
- Do not stand on the stool or use it as a ladder.

8. TROUBLESHOOTING

- **Stool is wobbly:** Check that all assembly screws are securely tightened. Ensure the stool is placed on a flat, even surface.
- **Height adjustment not working:** Ensure the gas lift lever is fully engaged when attempting to adjust. If the gas lift is faulty, it may need replacement. Contact customer support.
- **Squeaking noise:** A small amount of lubricant (e.g., silicone spray) can be applied to moving parts like the gas lift or swivel mechanism if a squeak develops.

9. SPECIFICATIONS

Brand	CLP
Model	Saddle
Color	White
Seat Material	Plastic
Frame Material	Metal (Chrome Finish)
Style	Modern
Total Height (Adjustable)	87 cm
Seat Height (Adjustable)	60 - 81 cm
Seat Width	37 cm
Total Depth	37 cm
Item Weight	6 kg
Maximum Weight Recommendation	120 kg

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact CLP customer service directly. Keep your purchase receipt as proof of purchase.

