

## Safety 1st HS133

# Safety 1st Magnetic Locking System (1 Key and 8 Locks) Instruction Manual

Model: HS133

## 1. INTRODUCTION

---

The Safety 1st Magnetic Locking System is designed to help secure cabinets and drawers from curious children. This system provides a discreet and effective solution for childproofing your home, keeping potentially hazardous items out of reach. The locks are installed inside your cabinets and drawers, remaining invisible from the outside.

## 2. SAFETY INFORMATION

---

**WARNING: This product is intended to help reduce the risk of injury. It is not a substitute for adult supervision. Never leave children unattended.**

IN NO EVENT, REGARDLESS OF CAUSE, SHALL Safety 1st BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER ARISING UNDER BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, AND WHETHER BASED ON THIS AGREEMENT OR OTHERWISE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## 3. PACKAGE CONTENTS

---

Your Safety 1st Magnetic Locking System includes the following items:

- 8 x Magnetic Locks
- 1 x Magnetic Key



Image: All components of the Safety 1st Magnetic Locking System, showing the 8 individual locks, the magnetic key, and mounting screws.

## 4. FEATURES

---

- **Keep cabinets & drawers off limits:** Provides peace of mind for parents while children are exploring in the home.
- **Toddler tested. Proven stronger:** Locks outperform the competition both in home and mechanical pull force lab testing.
- **Invisible from the outside:** Installs inside of your cabinets and drawers, concealed from children and guests.
- **Unlock mode:** Option to keep the lock in "unlock mode" when you need more frequent access to your cabinets.

## 5. SETUP AND INSTALLATION

---

The Safety 1st Magnetic Locking System is designed for easy installation inside most cabinets and drawers. Follow these steps for proper setup:

1. **Prepare the Surface:** Ensure the inside surfaces of your cabinet or drawer and the cabinet door/drawer

front are clean and dry.

2. **Determine Placement:** Identify the optimal location for the lock and latch. The lock should be positioned so that the latch mechanism aligns with the cabinet frame when the door is closed. Ensure there is enough clearance for the latch to engage and disengage.
3. **Use the Installation Cradle (if included):** Some kits include an installation cradle or template to assist with precise placement. If available, follow its instructions to mark screw holes accurately.
4. **Pre-drill Pilot Holes:** Using a small drill bit (e.g., 1/16 inch), carefully pre-drill pilot holes for the screws. This prevents wood splitting and ensures a secure fit. Do not drill too deep to avoid going through the cabinet material.
5. **Mount the Lock:** Secure the main lock unit to the inside of the cabinet door or drawer front using the provided screws. Ensure it is aligned correctly.
6. **Mount the Latch:** Secure the latch mechanism to the cabinet frame or drawer interior, aligning it with the lock unit. Test the alignment by gently closing the door/drawer to ensure the lock and latch engage properly. Adjust as needed before fully tightening screws.
7. **Final Tightening:** Once satisfied with the alignment, securely tighten all screws.



Image: A Safety 1st magnetic lock is shown installed inside a cabinet, demonstrating its discreet placement and how the magnetic key interacts with it from the outside.

## Installation Videos:

Video: Safety 1st Magnetic Locking System Kids Baby Childproofing. This video provides a general overview of the product and its installation process.

Video: How to PROPERLY Install Safety 1st Cabinet Magnetic Locks. This video offers detailed instructions on correctly installing the magnetic cabinet locks.

Video: Super cool installation cradle helps you install in minutes. This video demonstrates how to use an installation cradle for quick and easy setup.

## 6. OPERATING INSTRUCTIONS

---

Using your Safety 1st Magnetic Locking System is simple and intuitive:

1. **Locking:** When the cabinet or drawer is closed, the magnetic lock automatically engages, preventing it from being opened by children.
2. **Unlocking with Magnetic Key:** To open a locked cabinet or drawer, place the magnetic key on the outside surface of the cabinet/drawer, directly over the installed lock. The magnet will disengage the lock, allowing you to open the door/drawer. Remove the key once opened.
3. **Unlock Mode:** For periods when childproofing is not needed (e.g., when children are not present, or for frequent access), you can set the lock to "unlock mode." This typically involves a small switch on the lock unit that keeps the latch disengaged. Refer to the specific lock unit for the exact mechanism.



Image: A magnetic key is used to unlock a cabinet, demonstrating the simple operation of the system.

## Operation Videos:

Video: Mag Lock System - 1 key 8 locks. This video demonstrates the basic operation of the magnetic locking system, showing how to use the key to open the locks.

Video: Love these locks! Hidden and easy to use. Very effective lock for toddlers! This video showcases the effectiveness and ease of use of the hidden magnetic locks.

Video: The best magnetic child safety locks! This video highlights the benefits and functionality of the magnetic child safety locks.

Video: These are a must have if you have toddlers. This video demonstrates the practical application and effectiveness of the locks in a home with toddlers.

## 7. MAINTENANCE

---

To ensure the longevity and proper function of your Safety 1st Magnetic Locking System:

- Regularly inspect the locks and latches for any signs of wear or damage.
- Clean the locks and surrounding areas with a damp cloth and mild soap. Avoid harsh chemicals that could damage the plastic.

- Ensure the magnetic key is stored in a safe, consistent location, out of reach of children, to prevent loss.

## 8. TROUBLESHOOTING

---

If you encounter any issues with your magnetic locking system, consider the following:

- **Lock not engaging:** Check for proper alignment between the lock and the latch. Ensure no debris is obstructing the mechanism.
- **Difficulty unlocking:** Verify that the magnetic key is placed directly over the lock mechanism. Ensure the lock is not in "unlock mode."
- **Loose installation:** Re-tighten any loose screws. If the adhesive is failing, consider re-mounting with fresh adhesive or screws if applicable.

For persistent issues, please refer to the manufacturer's support resources.

## 9. SPECIFICATIONS







---

Specification	Detail
Product Dimensions	10.5 x 5.75 x 2 inches
Item Model Number	HS133
Material Type	Plastic
Number Of Items	1 (set includes 8 locks and 1 key)
Style	Hardware Mount
Batteries Required	No
Item Weight	8 ounces

## 10. WARRANTY AND SUPPORT

---

For information regarding product warranty, returns, or customer support, please refer to the official Safety 1st website or contact their customer service directly. Specific warranty details are not provided in this manual.

	<p><a href="#">Safety 1st Adhesive Magnetic Locking System User Guide</a></p> <p>Comprehensive guide for installing and using the Safety 1st Adhesive Magnetic Locking System, including instructions for cabinets and drawers, troubleshooting, and safety information.</p>
	<p><a href="#">OUTSMART™ Flex Lock 3202006000 - Child Safety Cabinet Lock Installation and User Guide</a></p> <p>Comprehensive user manual and installation guide for the OUTSMART™ Flex Lock (Model 3202006000) by Safety 1st. Learn how to safely install, use, and maintain this childproofing lock for cabinets and drawers to protect your child.</p>
	<p><a href="#">Safety 1st Ear Otoscope User Guide IH481</a></p> <p>User guide for the Safety 1st Ear Otoscope (Model IH481) by Dorel Juvenile Group. Provides instructions for use, battery replacement, cleaning, troubleshooting, and warranty information.</p>
	<p><a href="#">Safety 1st Wide Doorways Fabric Gate 42066 User Guide</a></p> <p>User guide for the Safety 1st Wide Doorways Fabric Gate (Model 42066), providing detailed instructions for installation, usage, and care. Suitable for children aged 6 to 24 months, this gate fits openings from 38 to 60 inches.</p>
	<p><a href="#">Safety 1st HD Wi-Fi Baby Monitor MO163 User Guide</a></p> <p>User guide for the Safety 1st HD Wi-Fi Baby Monitor (Model MO163), covering setup, features, safety warnings, troubleshooting, and warranty information.</p>
	<p><a href="#">Safety 1st Grip'n Go Folding Walker Owner's Guide and Assembly Instructions</a></p> <p>Comprehensive owner's guide for the Safety 1st Grip'n Go Folding Walker, detailing assembly, usage, safety warnings, and care instructions for models 04025, 04010, and 04022A.</p>