

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SCHLEICH](#) /
- › [SCHLEICH Eventing Horse Set Model 42047 Instruction Manual](#)

SCHLEICH 42047

SCHLEICH Eventing Horse Set Model 42047 Instruction Manual

Brand: SCHLEICH | Model: 42047

INTRODUCTION

This instruction manual provides essential information for the SCHLEICH Eventing Horse Set, Model 42047. This set is designed for imaginative play, featuring a hand-painted horse, rider, and a jump obstacle. Please read this manual carefully to ensure proper use and care of your product.



Image 1: The Schleich Eventing Horse Set, featuring a horse with a rider and a jump obstacle.

SETUP

The SCHLEICH Eventing Horse Set (Model 42047) requires no assembly. All components are pre-assembled and ready for immediate play.

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all parts are present: one horse figure, one rider figure, and one jump obstacle.
2. **Placement:** Place the figures and jump on a flat, stable surface suitable for play.



Image 2: The Schleich Eventing Horse Set displayed within its retail packaging.

OPERATING INSTRUCTIONS

This set is designed for manual operation and imaginative role-play. No batteries or electronic components are required.

- **Rider Placement:** Position the rider figure on the horse's back. The rider's hands can be placed on the horse's reins for a secure grip.
- **Jump Obstacle:** Place the jump obstacle on a flat surface. The horse and rider can be manually guided over the jump to simulate eventing activities.
- **Creative Play:** Encourage creative storytelling and interaction with other Schleich figures and playsets (sold separately).

MAINTENANCE AND CARE

To ensure the longevity of your SCHLEICH Eventing Horse Set, follow these simple care instructions:

- **Cleaning:** Wipe figures gently with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the paint or material.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- **Handling:** Handle figures with care to prevent breakage, especially smaller parts.

TROUBLESHOOTING

This product is a simple toy set with minimal components. Most issues can be resolved with basic inspection.

Problem	Possible Cause	Solution
Figure appears dirty	Accumulation of dust or dirt from play.	Wipe gently with a damp cloth.
Figure does not stand stably	Uneven play surface or incorrect positioning.	Ensure figures are placed on a flat surface. Adjust positioning as needed.
Small part detached	Rough handling or accidental impact.	If a small part detaches, it may be possible to reattach it with a suitable adhesive, depending on the material and break point. Exercise caution.







SPECIFICATIONS

Brand	SCHLEICH
Model Number	42047
Set Name	Eventing Horse Set
Material Type(s)	Plastic
Number of Pieces	1 (refers to the set as a single item, though it contains multiple figures)
Product Dimensions (L x W x H)	17.53 x 20.07 x 11.43 cm
Item Weight	439.98 g
Manufacturer Recommended Age	4 - 12 years
Minimum Age (Months)	48 months
Assembly Required	No
Batteries Required	No
Operation Mode	Manual
Educational Objective	Encourages creativity and social interaction through role play
Indoor/Outdoor Use	Indoor

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the official SCHLEICH website or contact your retailer. Specific warranty details are not included in this manual.
Manufacturer: Schleich North America

Related Documents - 42047

	<p>Schleich Horse Club Princess Stable 42437: Assembly Instructions</p> <p>Detailed assembly instructions for the Schleich Horse Club Princess Stable (model 42437). This guide provides a textual description of all parts and assembly steps, replacing visual diagrams with clear instructions for building the toy playset.</p>
	<p>Schleich Horse Club Pick Up with Horse Box 42346 Assembly Instructions</p> <p>Step-by-step assembly guide for the Schleich Horse Club Pick Up with Horse Box playset (model 42346), featuring a parts list and detailed assembly instructions for children.</p>
	<p>Schleich Horse Club 42703 Open Stable: Assembly Instructions and Product Information</p> <p>Detailed assembly instructions, parts list, and product overview for the Schleich Horse Club 42703 Open Stable playset. Learn how to build and enjoy this toy for children.</p>
	<p>Schleich HORSE CLUB Stable 72118 Assembly Instructions</p> <p>Step-by-step assembly guide for the Schleich HORSE CLUB Stable playset (model 72118). Includes a comprehensive parts list and detailed instructions for building the toy horse stable.</p>
	<p>Schleich Horse Club Veterinary Vehicle and Trailer 42704 Assembly Instructions</p> <p>Step-by-step assembly guide for the Schleich Horse Club Veterinary Vehicle and Trailer playset (model 42704), detailing how to connect the various parts to build the toy.</p>
	<p>Schleich Horse Club Dually Truck with Horse Trailer Assembly Instructions</p> <p>Step-by-step assembly guide for the Schleich Horse Club Dually Truck and Horse Trailer toy set (Model 42705). Includes part identification and assembly instructions for creating the toy vehicle and trailer.</p>