

## DJ Tech POKETDJDUIO

# DJ Tech POKETDJDUIO DJ Mixer User Manual

## INTRODUCTION

---

The DJ Tech POKETDJDUIO is a portable USB DJ controller designed for aspiring DJs. This compact device integrates essential DJ functionalities, offering a straightforward way to mix music. It features a built-in audio interface, eliminating the need for external soundcards, and comes bundled with DJ software to facilitate immediate use.

## PRODUCT OVERVIEW

---

### Key Features

- USB DJ controller with integrated soundcard.
- High-quality 16-Bit @44.1kHz sound interface.
- Master output and headphone output for direct monitoring.
- Two high-definition jog wheels for precise control.
- Multi-function buttons for autoloop, hot cues, and sampler.
- Beatmatch counter for each deck.
- Includes Deckadance LE DJ software.

### Controls and Components

The POKETDJDUIO features a layout designed for intuitive DJ control. Key components include:

- **Jog Wheels:** Used for pitch bend, quick search, scratching, EQ adjustments, and FX parameter control.
- **Multi-function Buttons:** These three buttons can be assigned to trigger hot cues, activate autoloop functions, or control sample playback.
- **Transport Controls:** Standard play, pause, and cue buttons.
- **Volume Controls:** Faders and knobs for adjusting master and individual deck volumes.



*This image displays the front panel of the POKETDJDUO DJ Mixer, highlighting its two jog wheels, various buttons, and faders for mixing and control.*

## SETUP GUIDE

- 1. Connect to Computer:** Use a standard USB cable to connect the POKETDJDUO to an available USB port on your computer. The device is powered via USB.
- 2. Install Software:** Install the included Deckadance LE DJ software on your computer. Follow the on-screen instructions for installation.
- 3. Connect Audio Output:**
  - Connect your main speakers to the master output of the POKETDJDUO.
  - Connect your headphones to the dedicated headphone output for monitoring.
- 4. Launch Software:** Open the Deckadance LE software. The POKETDJDUO should be automatically recognized as a controller and audio device.
- 5. Audio Configuration:** Within the Deckadance LE software settings, ensure that the POKETDJDUO's integrated soundcard is selected for both master output and headphone monitoring.

Once these steps are completed, the POKETDJDUO is ready for use.

# OPERATING INSTRUCTIONS

---

## Basic DJ Functions

- **Loading Tracks:** Use the Deckadance LE software interface to browse and load audio tracks onto the virtual decks.
- **Playback Control:** Use the transport buttons (Play/Pause, Cue) on the POKETDJDUDUO to control track playback.
- **Mixing:** Adjust the volume faders and crossfader to blend between tracks on different decks.

## Advanced Controls

- **Jog Wheel Functions:**
  - **Pitch Bend:** Gently nudge the jog wheel to temporarily adjust the track's tempo for beatmatching.
  - **Scratch:** Activate scratch mode (if available in software) and manipulate the jog wheel for scratching effects.
  - **Quick Search:** Rotate the jog wheel to quickly navigate through a track.
  - **EQ/FX Control:** In certain modes, the jog wheels can be used to adjust equalizer parameters or effect levels.
- **Multi-function Buttons:**
  - **Hot Cues:** Set and trigger cue points within a track for instant jumps to specific sections.
  - **Autoloop:** Create and activate automatic loops of various lengths.
  - **Sampler:** Trigger pre-loaded samples or drum sounds. The Deckadance LE software includes 1000 sample sounds.
- **Beatmatching:** Utilize the automatic beat matching function within Deckadance LE. The beatmatch counter will provide visual feedback on synchronization.

## MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your POKETDJDUDUO DJ Mixer.

- **Cleaning:** Use a soft, dry cloth to wipe down the surface of the controller. Avoid abrasive cleaners or solvents. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.
- **Storage:** Store the device in a cool, dry place away from direct sunlight, extreme temperatures, and excessive dust.
- **Cable Management:** Avoid kinking or excessive bending of USB and audio cables to prevent damage.
- **Software Updates:** Periodically check for updates to the Deckadance LE software to ensure compatibility and access to the latest features.

## TROUBLESHOOTING

---

If you encounter issues with your POKETDJDUDUO, refer to the following common troubleshooting steps:

- **Device Not Recognized:**
  - Ensure the USB cable is securely connected to both the controller and the computer.
  - Try connecting to a different USB port on your computer.

- Restart your computer and the DJ software.
  - Verify that the necessary drivers for the POKETDJDUDUO are installed (usually part of the Deckadance LE installation).
- **No Sound Output:**
    - Check all audio cable connections to your speakers and headphones.
    - Ensure volume levels on the POKETDJDUDUO and within the Deckadance LE software are turned up.
    - Confirm that the POKETDJDUDUO's integrated soundcard is selected as the primary audio output device in your computer's sound settings and within Deckadance LE.
- **Software Issues:**
    - Ensure your Deckadance LE software is up to date.
    - Consult the Deckadance LE software manual or support resources for specific software-related problems.

## SPECIFICATIONS

| Feature                           | Detail   |
|-----------------------------------|--|
| <b>Model Number</b>               | POKETDJDUDUO                                   |
| <b>Item Weight</b>                | 1.76 pounds (0.8 kg)                           |
| <b>Product Dimensions</b>         | 6.1 x 6.1 x 3.25 inches (15.5 x 15.5 x 8.3 cm) |
| <b>Connectivity Technology</b>    | USB  |
| <b>Sound Interface Resolution</b> | 16-Bit   |
| <b>Sampling Rate</b>              | 44.1/48kHz                                     |
| <b>Line Output Level</b>          | 0.9V (Typical)                                 |
| <b>Phones Output Level</b>        | 1.3V (Typical)                                 |
| <b>THD+N (Line)</b>               | 0.02% (Typical)                                |
| <b>S/N Ratio (Line)</b>           | 90dB (Typical)                                 |
| <b>Number of Channels</b>         | 2  |
| <b>Power Source</b>               | Corded Electric (USB Powered)                  |
| <b>Color</b>                      | Black  |

## WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service, please refer to the documentation provided with your purchase or visit the official DJ Tech website. Contact details for customer support are typically available on the manufacturer's product page or in the included warranty card.

Always ensure you have your product model number (POKETDJDUI) and purchase details available when contacting support.