Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

B&G 5850-CC

B&G Tip Assembly Part 5850-CC Multijet BG2028 User Manual

Model: 5850-CC

1. Product Overview

The B&G 5850-CC Multeejet Crack & Crevice 4-Way Tip Assembly is a replacement component designed for use with B&G Primeline sprayers. Specifically, this tip assembly is intended for integration with the Extenda-Ban Value, facilitating precise application in crack and crevice treatments.
This assembly allows for versatile spray patterns, making it suitable for various pest control applications where targeted delivery is essential.



Figure 1: A close-up view of the B&G 5850-CC Multijet Tip Assembly, made of brass, showing its knurled rings and the four-way spray pattern selector at the top. This image illustrates the physical appearance of the tip assembly.

2. Setup and Installation

This section outlines the general procedure for installing the 5850-CC Multeejet Tip Assembly. Ensure the sprayer is depressurized and empty before beginning installation.

1. **Preparation:** Ensure your B&G Primeline sprayer is clean and free of any residual chemicals. Verify that the Extenda-Ban Value is securely attached to the sprayer wand.
2. **Removal of Old Tip (if applicable):** If replacing an existing tip, carefully unscrew the old tip assembly from the Extenda-Ban Value. Dispose of the old tip according to local regulations.
3. **Installation of New Tip:** Align the threaded end of the 5850-CC Multeejet Tip Assembly with the Extenda-Ban Value. Screw the tip assembly onto the valve clockwise until it is finger-tight.
4. **Secure Connection:** Using a wrench, gently tighten the tip assembly an additional quarter turn to ensure a secure, leak-free connection. Avoid over-tightening, as this can damage the threads or the tip assembly.
5. **Test for Leaks:** After installation, fill the sprayer with water and pressurize it. Check for any leaks around the newly installed tip assembly. If leaks are present, depressurize the sprayer and re-tighten the assembly.

3. Operating Instructions

The 5850-CC Multeejet Tip Assembly features a 4-way selector for different spray patterns. To change the spray pattern, rotate the knurled cap at the top of the tip assembly until the desired pattern aligns with the indicator mark on the body of the tip.
The available spray patterns are designed for specific applications:

- **Pin Stream:** For precise, targeted application in very narrow cracks and crevices.
- **Fan Spray:** For broader coverage along baseboards or surfaces.
- **Crack & Crevice:** A specialized pattern for reaching into tight spaces.
- **(Fourth pattern may vary, refer to specific product markings for exact details):**Often another variation of fan or cone spray for general application.

Always ensure the sprayer is properly pressurized according to the B&G sprayer's manual for optimal spray performance.

4. Maintenance

Proper maintenance extends the life and ensures the performance of your B&G Multeejet Tip Assembly.

- **Cleaning:** After each use, flush the tip assembly with clean water to remove any chemical residues. For stubborn clogs, disassemble the tip and clean individual components with a small brush and water. Avoid using metal objects that could scratch or damage the brass.
- **Inspection:** Regularly inspect the tip for wear, damage, or blockages. Check the O-rings and seals for deterioration and replace them if necessary to prevent leaks.
- **Storage:** Store the tip assembly in a clean, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure it is thoroughly cleaned and dry.

5. Troubleshooting

If you encounter issues with your 5850-CC Multeejet Tip Assembly, consider the following:

- **No Spray or Reduced Flow:**
  - Check for clogs in the tip orifice or internal channels. Clean as described in the Maintenance section.
  - Ensure the sprayer is adequately pressurized.
- **Leaking from Tip:**

- Verify the tip assembly is securely tightened to the Extenda-Ban Value.
- Inspect O-rings and seals for damage or improper seating. Replace if worn.

- **Inconsistent Spray Pattern:**
  - Ensure the spray pattern selector is fully engaged in the desired position.
  - Clean the tip to remove any partial blockages that might distort the spray.

If problems persist after troubleshooting, contact B&G customer support or a qualified service technician.

6. Specifications

Attribute	Detail
Model Number	5850-CC
Product Dimensions	1.85 x 2.55 x 1.25 inches
Item Weight	2.24 ounces
Manufacturer	B&G
Compatibility	B&G Primeline sprayers with Extenda-Ban Value

7. Warranty Information

Specific warranty details for the B&G 5850-CC Multeejet Tip Assembly are not provided in this document. For information regarding product warranty, please refer to the documentation included with your original B&G sprayer or contact B&G customer support directly.

8. Support

For further assistance, technical support, or to inquire about replacement parts, please contact B&G customer service. Contact information can typically be found on the B&G official website or on the packaging of your B&G sprayer.
When contacting support, please have your product model number (5850-CC) and any relevant purchase information ready.

© 2025 B&G. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004H48W1E

More documents and user manuals: **https://manuals.plus/**