

MOBO MBSW-8

MOBO Cronos MBSW-8 Smartwatch User Manual

Model: MBSW-8

1. INTRODUCTION

Thank you for choosing the MOBO Cronos MBSW-8 Smartwatch. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your smartwatch.

The MOBO Cronos MBSW-8 is a versatile smartwatch designed to keep you connected and informed. It features a responsive touchscreen display, Bluetooth connectivity for smartphone integration, and notification alerts.

2. WHAT'S IN THE BOX

Upon opening your MOBO Cronos MBSW-8 Smartwatch package, please verify that all the following items are included:

- MOBO Cronos MBSW-8 Smartwatch (Black)
- Charging Cable (specific to MBSW-8)
- User Manual (this document)

3. SETUP

3.1 Charging the Smartwatch

Before first use, fully charge your smartwatch. Connect the charging cable to the charging pins on the back of the smartwatch and to a standard USB power adapter (not included) or a computer's USB port.



Image: Back view of the MOBO Cronos MBSW-8 Smartwatch, highlighting the charging pins and model information.

The screen will indicate charging status. A full charge typically takes approximately 2 hours. The smartwatch uses a Lithium battery.

3.2 Powering On/Off

- **To Power On:** Press and hold the side button (if present) or tap the screen if it's a touch-only power-on.
- **To Power Off:** Navigate to the 'Settings' menu on the smartwatch, then select 'Power Off' or 'Shutdown'. Confirm your selection.

3.3 Pairing with Your Smartphone

To utilize all features, pair your smartwatch with a compatible smartphone (Android or iOS).

1. Ensure your smartphone's Bluetooth is enabled.
2. Download the companion app (e.g., 'MOBO Smart' or similar, check product packaging for exact app name) from your phone's app store.
3. Open the app and follow the on-screen instructions to create an account or log in.
4. In the app, select 'Add Device' or 'Pair New Device'.
5. The app will search for available devices. Select 'MBSW-8' or 'MOBO Cronos' from the list.
6. Confirm the pairing request on both your smartphone and the smartwatch.

Once paired, the smartwatch will synchronize time, date, and other data with your phone.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The MOBO Cronos MBSW-8 features a 1.3-inch touchscreen display for intuitive interaction.



Image: Front view of the MOBO Cronos MBSW-8 Smartwatch, displaying the time, date, and various status icons.

- **Swipe Up/Down:** Scroll through menus or notifications.
- **Swipe Left/Right:** Access different widgets or quick settings.
- **Tap:** Select an item or open an application.
- **Press and Hold:** May activate specific functions or change watch faces.

4.2 Notifications

Once paired with your smartphone, the smartwatch will display notifications for calls, messages, and app alerts. Ensure notification permissions are granted in the companion app on your phone.

4.3 Time and Date Synchronization

The smartwatch automatically synchronizes its time and date with your paired smartphone. No manual adjustment is typically required.

4.4 GPS Functionality

The MOBO Cronos MBSW-8 supports GPS functionality via your smartphone. This means it uses your phone's GPS to track location data for activities, rather than having a built-in GPS module.



Image: Angled view of the MOBO Cronos MBSW-8 Smartwatch, showing the display and strap design.

5. MAINTENANCE

5.1 Cleaning Your Smartwatch

- Wipe the screen and body with a soft, lint-free cloth.
- For stubborn marks, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.
- Ensure the charging pins are clean and dry before charging.

5.2 Battery Care

- Avoid fully discharging the battery frequently.
- Do not expose the smartwatch to extreme temperatures.

- If storing for an extended period, charge the battery to about 50% to prolong its lifespan.

5.3 Storage

Store your smartwatch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

6. TROUBLESHOOTING

6.1 Smartwatch Not Powering On

- Ensure the device is fully charged. Connect it to the charger for at least 30 minutes.
- Try pressing and holding the power button for 10-15 seconds.

6.2 Unable to Pair with Smartphone

- Confirm Bluetooth is enabled on your smartphone.
- Make sure the smartwatch is within Bluetooth range (typically 10 meters or 33 feet).
- Restart both your smartphone and the smartwatch.
- Forget the device in your phone's Bluetooth settings and try pairing again through the companion app.

6.3 Notifications Not Appearing

- Check notification permissions in your smartphone's settings for the companion app.
- Ensure the companion app is running in the background on your phone.
- Verify that 'Do Not Disturb' mode is not active on either your phone or smartwatch.

6.4 Screen Unresponsive

- Restart the smartwatch.
- Ensure the screen is clean and dry.

7. SPECIFICATIONS

Brand	MOBO
Model	MBSW-8
Display Size	1.3 Inches
Input Interface	Touchscreen
Connectivity Technology	Bluetooth
Wireless Standard	Bluetooth
Compatible Devices	Smartphone, Tablet, Laptop
Special Features	Notifications
GPS	GPS via smartphone

Battery Type	Lithium
Batteries Included	Yes
Product Dimensions	17.4 x 10 x 4.2 cm; 80 g
First Available Date	October 25, 2019

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official MOBO website. Keep your purchase receipt as proof of purchase for warranty claims.