

[Manuals.plus](#) /

› [Lorell](#) /

› Lorell Desk Shell, 66 by 30 by 29-1/2-Inch, Cherry Instruction Manual

Lorell LLR69408

Lorell Desk Shell Instruction Manual

Model: LLR69408

PRODUCT OVERVIEW

The Lorell Desk Shell, measuring 66 by 30 by 29-1/2-Inches and finished in Cherry, is a robust piece of office furniture. It features high-quality laminate construction with durable metal-to-metal cam lock connections. The design incorporates 3mm PVC edges for enhanced durability and adjustable floor guides to ensure stability on various surfaces. The desk includes predrilled holes with metal inserts, simplifying the attachment of compatible pedestals (sold separately). Its structural brackets are specifically designed to facilitate L-shape configurations when combined with bridge returns, offering versatile office layout options.



Image: The Lorell Desk Shell in Cherry finish, showcasing its rectangular design and integrated wire management grommets.

SAFETY INFORMATION

Warning:

This product is heavy and requires assistance to move. Improper assembly may lead to stability issues. Always review the 5-year limited warranty for safety-related information and ensure proper assembly for optimal stability and safe use.

SETUP AND ASSEMBLY

The Lorell Desk Shell requires assembly. It is strongly recommended that **two people** are involved in the assembly process due to the significant weight and size of the components. The furniture is designed with predrilled holes and metal inserts to simplify the attachment of compatible pedestals (sold separately).

Key Assembly Features:

- **Metal to Metal Cam Lock Connections:** These connections ensure a secure and stable assembly, providing long-lasting structural integrity.
- **Predrilled Holes with Metal Inserts:** These features simplify the process of attaching additional components, such as filing pedestals, ensuring a precise fit.
- **Adjustable Floor Guides:** Located at the base of the desk, these guides allow for easy leveling on uneven floor surfaces, preventing wobbling.



Image: The Lorell Desk Shell integrated into a complete office setup, demonstrating its potential configurations. For detailed, step-by-step assembly instructions, please refer to the official [Installation Manual \(PDF\)](#) provided by the manufacturer.

OPERATING INSTRUCTIONS

Wire Management:

The Lorell Desk Shell is equipped with integrated wire management grommets designed to help organize and conceal cables from electronic devices. These grommets are strategically placed on the desktop surface to facilitate neat cable routing.



Image: A close-up view of the wire management grommet, showing its design for routing cables.

L-Shape Configurations:

The desk is designed with specific brackets to facilitate seamless L-shape configurations when combined with bridge returns or other compatible Lorell desk components. This modularity allows for flexible and efficient office layouts, maximizing workspace utility.



Image: An example of the Lorell Desk Shell used in an L-shape configuration, demonstrating its modularity.

MAINTENANCE

To ensure the longevity and preserve the aesthetic appearance of your Lorell Desk Shell, adhere to the following maintenance guidelines:

- **Cleaning:** Wipe all surfaces with a soft, slightly damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the laminate finish.
- **Spills:** Clean up any spills immediately to prevent staining or absorption into the laminate material.
- **Protection:** Utilize coasters for beverages and desk pads for writing or computer equipment. This will protect the desk surface from scratches, heat marks, and liquid damage.
- **Adjustable Floor Guides:** Periodically inspect and adjust the floor guides on each leg to ensure the desk remains level and stable, preventing any wobbling.

TROUBLESHOOTING

Stability Issues:

If the desk feels wobbly or unstable after assembly:

- Ensure all cam lock connections are fully engaged and securely tightened.
- Adjust the individual floor guides on each leg to level the desk on uneven flooring.
- Verify that all assembly steps were followed precisely according to the [Installation Manual](#).

Damaged or Missing Parts:

If components were damaged during shipping or parts are missing upon initial unboxing:

- Contact Lorell customer support immediately. Provide your product model number (LLR69408) and a detailed description of the issue.
- Refer to the packing list included with your product to verify all expected components.

SPECIFICATIONS

Feature	Detail
Brand	Lorell
Model Number	LLR69408
Product Dimensions	66"D x 68.5"W x 29.5"H
Color	Cherry
Style	Modern
Base Material	Metal
Top Material Type	Metal, Plastic
Finish Type	Laminated
Special Feature	Wire Management
Item Weight	119 Pounds
Required Assembly	Yes
Recommended People for Assembly	2
Frame Joint Type	Cam Lock
Has Finished Back	Yes

WARRANTY AND SUPPORT

Warranty Information:

The Lorell Desk Shell is backed by a **Limited Warranty**. For comprehensive details regarding the terms, conditions, and coverage, please consult the warranty documentation included with your product or contact Lorell customer service directly. This warranty typically covers manufacturing defects and material flaws under normal use.

Customer Support:

For any assistance with assembly, inquiries about missing parts, or other product-related questions, please reach out to Lorell customer support. Additional resources and information may also be available on the [Lorell Store on Amazon](#).

Model Number: LLR69408

UPC: 035255694087



