

[Manuals.plus](#) /

› [Walker Edison](#) /

› Walker Edison Twin Roll-Out Trundle Frame Instruction Manual

Walker Edison Twin Roll-Out Trundle Frame

Walker Edison Twin Roll-Out Trundle Frame Instruction Manual

INTRODUCTION

The Walker Edison Twin Roll-Out Trundle Frame is designed to provide an additional sleeping surface or storage solution, easily sliding under an existing bed. This manual provides comprehensive instructions for the safe assembly, proper operation, and effective maintenance of your trundle frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always ensure all bolts, screws, and connections are securely tightened before use and periodically check them for tightness.
- Do not allow children to play on or around the trundle without adult supervision.
- Do not exceed the maximum weight capacity of 250 lbs (113.4 kg) to prevent damage or injury.
- Use only the recommended mattress size for the trundle frame. Mattress and bedding are NOT included.
- Keep small parts away from children during assembly to avoid choking hazards.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Trundle frame components (metal bars, side rails, end panels)
- 4 caster wheels
- Assembly hardware (bolts, nuts, washers)
- Necessary assembly tools (e.g., Allen wrench)
- Step-by-step instruction manual

SETUP AND ASSEMBLY

The Walker Edison Twin Roll-Out Trundle Frame ships ready-to-assemble with all necessary hardware and step-by-step instructions. Assembly is designed to be straightforward and requires no specialized experience.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratching. Verify all parts against the package contents list.
2. **Assemble Frame:** Follow the included step-by-step instructions to connect the frame components using the provided hardware. Ensure all connections are finger-tight initially.
3. **Attach Caster Wheels:** Securely attach the 4 caster wheels to the designated points on the trundle frame.
4. **Secure Plastic Clips (if applicable):** Some designs include plastic clips to hold slats in place. If you encounter difficulty inserting these, ensure the clip is oriented correctly. If it doesn't go in easily, flip the piece around before applying force.
5. **Final Tightening:** Once all components are assembled, go back and securely tighten all bolts and screws using the provided tools. Do not overtighten.



Image: The fully assembled Walker Edison Twin Roll-Out Trundle Frame, showing its sturdy metal construction and slat design.



Image: A close-up view of one of the caster wheels attached to the trundle frame, highlighting its mobility feature.

OPERATING INSTRUCTIONS

The trundle frame is designed for ease of use and mobility.

- **Placement:** Position the trundle frame under an existing bed frame that has sufficient clearance. Ensure the main bed frame is stable and secure.
- **Rolling Out:** To use the trundle, gently pull it out from under the main bed. The 4 caster wheels allow for smooth and easy movement across most floor surfaces.
- **Rolling In:** To store the trundle, push it back under the main bed until it is fully concealed.
- **Mattress:** Place a twin-sized mattress directly onto the trundle frame's slats. Ensure the mattress fits securely within the frame. (Mattress and bedding are NOT included).



Image: The Walker Edison Twin Roll-Out Trundle Frame shown pulled out from under a bunk bed, ready for use with a mattress and bedding.

MAINTENANCE

Proper maintenance will ensure the longevity and continued safe operation of your trundle frame.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Regular Checks:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Re-tighten if necessary.
- **Caster Wheels:** Keep the caster wheels free of debris (e.g., hair, lint) to ensure smooth rolling.

TROUBLESHOOTING

- **Trundle does not roll smoothly:** Check caster wheels for obstructions (e.g., carpet fibers, debris). Ensure wheels are securely attached and rotate freely.
- **Frame feels unstable or wobbly:** Verify that all assembly hardware is fully tightened. Refer to the assembly instructions to ensure all parts are correctly installed.
- **Difficulty with plastic clips during assembly:** As noted in the setup section, ensure plastic clips are oriented correctly. If a clip does not insert easily, flip it around.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	184.2 cm x 96.5 cm x 4 cm (76" L x 40" W x 4" H)
Item Weight	12.25 kg
Maximum Recommended Load	113.4 kg (250 lbs)
Material	Alloy Steel
Color	Black
Assembly Required	Yes
Included Components	Casters

WARRANTY INFORMATION

Specific warranty details for the Walker Edison Twin Roll-Out Trundle Frame may vary. Please refer to the manufacturer's official website, the original product packaging, or your purchase documentation for comprehensive warranty terms and conditions.

SUPPORT AND CONTACT INFORMATION

If you have any questions, require assistance with assembly, or need replacement parts, please contact Walker Edison customer support:

Phone: 1-801-433-3008

Email: service@walkeredison.com

Replacement parts are available. Please contact Walker Edison within 30 days of delivery for assistance with replacement parts.




Image: Contact information for Walker Edison customer support, including phone number and email address.

© 2024 Walker Edison. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B004I5BGEM>

More documents and user manuals: <https://manuals.plus/>