



[Manuals.plus](#) /

› [EnviroCare](#) /

› EnviroCare Micro-Filtration Vacuum Bags for Eureka Canister Vacuums (Style V, 3-Pack) Instruction Manual

EnviroCare Style V

EnviroCare Micro-Filtration Vacuum Bags for Eureka Canister Vacuums (Style V)

Instruction Manual

PRODUCT OVERVIEW

These EnviroCare Micro-Filtration Vacuum Bags are specifically designed for use with Eureka Canister Vacuums that utilize Style V bags. Each bag offers 99.7% filtration efficiency, effectively trapping microscopic particles and common allergens to help maintain cleaner air during vacuuming. This package contains three replacement bags, ensuring a consistent supply for your cleaning needs.



Image: The product packaging for EnviroCare Micro-Filtration Vacuum Bags, showing a 3-pack, alongside a single unfolded vacuum bag. The packaging highlights 99.7% filtration and compatibility with Eureka Canisters Style V, including series 3800, 3900, 6700, 6800, 8000, 8200, and 8900.

SETUP AND INSTALLATION

Follow these steps to correctly install your new EnviroCare Style V vacuum bag:

- 1. Power Off:** Always ensure your Eureka canister vacuum cleaner is unplugged from the electrical outlet before beginning any maintenance or bag replacement. This prevents accidental operation and ensures safety.
- 2. Access Bag Compartment:** Locate the bag compartment on your vacuum cleaner. This compartment typically opens by releasing a latch or pressing a button. Consult your specific Eureka vacuum cleaner's user manual if you are unsure about how to open it.
- 3. Remove Old Bag:** Carefully detach and remove the full or used vacuum bag. Most Style V bags feature a cardboard collar that slides into a designated holder within the vacuum. Gently pull this cardboard collar away from the vacuum's intake port. Dispose of the used bag responsibly according to local waste guidelines.
- 4. Insert New Bag:** Take a new EnviroCare Style V vacuum bag. Align the opening of the new bag's cardboard collar with the vacuum's intake port. Slide the collar firmly into the bag holder until it is securely seated and cannot be easily dislodged. Ensure the bag is fully unfolded inside the compartment without obstructing the closing mechanism.



Image: A close-up view of an EnviroCare Style V vacuum bag, highlighting the cardboard collar and the micro-filtration material. An arrow indicates the direction of airflow into the filter, and text indicates 'MicroFine Electrostatic Filter'.

5. **Close Compartment:** Close the bag compartment door firmly until it latches securely. If the door does not close easily, do not force it; recheck the bag's positioning to ensure it is not caught or misaligned.
6. **Reconnect Power:** Once the bag compartment is securely closed, plug the vacuum cleaner back into the electrical outlet. Your vacuum is now ready for operation with the new bag.

OPERATING GUIDELINES

For optimal cleaning performance and to maintain effective filtration, it is important to regularly monitor the fill level of your vacuum bag. Replace the bag when it is approximately two-thirds full, or if you observe a noticeable decrease in suction power. Operating the vacuum with an overfilled bag can significantly reduce cleaning efficiency, potentially strain the vacuum motor, and diminish air quality.

MAINTENANCE AND DISPOSAL

- These EnviroCare vacuum bags are designed for single use. Once a bag is full, it should be disposed of

and replaced with a new one. Do not attempt to empty and reuse the bags, as this will compromise their micro-filtration effectiveness and may lead to damage to your vacuum cleaner or reduced air quality.

- Dispose of all used vacuum bags in accordance with your local waste disposal regulations.

TROUBLESHOOTING

- **Reduced Suction:** If your vacuum's suction power decreases, first check if the bag is full and requires replacement. Also, ensure the bag is correctly installed within its compartment and is not obstructing the airflow path.
- **Dust Escaping:** If you notice dust escaping from the vacuum cleaner, verify that the vacuum bag is properly sealed within its compartment and that the compartment door is fully and securely closed.
- **Bag Not Fitting:** Confirm that you are using the correct Style V bags for your specific Eureka canister vacuum model. Refer to your vacuum's original user manual for precise compatibility information.

SPECIFICATIONS

Feature	Detail
Product Type	Micro-Filtration Vacuum Bags
Compatibility	Eureka Canister Vacuums, Style V (e.g., 3800, 3900, 6700, 6800, 8000, 8200, 8900 series, 52358A, 57698A)
Filtration Efficiency	99.7% (traps microscopic particles and allergens)
Quantity per Pack	3 Bags
Approximate Pack Dimensions (L x W x H)	9 x 6 x 2 inches
Approximate Item Weight (per pack)	3.84 ounces

WARRANTY AND SUPPORT

For specific warranty information regarding manufacturing defects or for product support, please refer to the official EnviroCare Technologies website or contact their customer service department directly. As these are replacement parts, warranty coverage typically addresses defects in materials or workmanship.

For additional information or to explore other products, you may visit the [EnviroCare Store on Amazon](#).