

[Manuals.plus](#) /

› [Inter Link](#) /

› Inter Link Los Angeles Single Bed Instruction Manual

Inter Link 20900225

Inter Link Los Angeles Single Bed Instruction Manual

Model: 20900225 | Brand: Inter Link

1. IMPORTANT SAFETY INFORMATION

Before beginning assembly or using the bed, please read and understand all safety instructions. Failure to follow these instructions may result in injury or damage to the product.

- Ensure correct assembly of all components. Incorrect assembly can lead to instability.
- Observe the maximum weight capacity of the bed frame. Overloading can cause structural failure.
- Be aware of potential pressure points during assembly and use.
- Keep small parts away from children during assembly to prevent choking hazards.

2. PACKAGE CONTENTS

Verify that all components are present before starting assembly. If any parts are missing or damaged, contact customer support.



Image 2.1: Diagram showing all components included in the Inter Link Los Angeles Single Bed package. This includes the headboard, footboard, side rails, and bed slats.

Tools Required (Not Included):

- Screwdriver (Phillips head recommended)
- Hammer (for slat pins, if applicable)
- Measuring tape (optional, for placement)

3. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly of your Inter Link Los Angeles Single Bed.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify the headboard, footboard, side rails, and bed slats.
2. **Attach Side Rails to Headboard:** Align the side rails with the pre-drilled holes on the headboard. Insert the provided screws and tighten them securely. Do not overtighten.



Image 3.1: Detail of a corner joint showing the secure attachment of a side rail to a bed post using screws.

3. **Attach Side Rails to Footboard:** Repeat the previous step to attach the other ends of the side rails to the footboard. Ensure the frame is square and stable.

4. **Install Bed Slats:** Place the bed slats across the side rails. Ensure they are evenly spaced and secured according to the design (e.g., using pre-drilled holes or pins). Some models may require nailing the slats; if so, use appropriate nails and ensure they do not split the wood.



Image 3.2: Detail showing how bed slats are attached to the inner ledge of the side rail, providing support for the mattress.

5. **Final Check:** Once all components are assembled, gently shake the bed frame to check for stability. Tighten any loose screws.



Image 3.3: Side view of the fully assembled Inter Link Los Angeles Single Bed frame, ready for a mattress.

4. OPERATING INSTRUCTIONS

The Inter Link Los Angeles Single Bed is designed for comfortable and stable sleep.

- **Mattress Placement:** Place a standard single mattress (approximately 90 x 200 cm) directly onto the bed slats. Ensure the mattress fits snugly within the frame.
- **Weight Capacity:** Do not exceed the recommended maximum weight capacity for the bed frame. Refer to the safety information or product specifications for details.
- **Intended Use:** This bed is designed for sleeping and resting. Avoid standing or jumping on the bed.

frame, as this can cause damage or injury.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your bed frame.

- **Cleaning:** The white painted pine wood surface is easy to maintain. Wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Moisture:** While the finish offers some protection, avoid prolonged exposure to excessive moisture.
- **Protect from Impact:** The pine wood, while solid, can be susceptible to dents from sharp impacts. Exercise care when moving furniture around the bed.

6. TROUBLESHOOTING

If you encounter any issues with your Inter Link Los Angeles Single Bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed frame feels unstable or wobbly.	Loose screws or incorrect assembly.	Check all connection points and tighten screws. Ensure all parts are correctly aligned as per assembly instructions.
Squeaking noises.	Loose joints, friction between wood parts, or mattress movement.	Tighten all screws. If squeaking persists, apply a small amount of furniture wax or lubricant to contact points between wood components. Ensure mattress is properly seated.
Wood appears dented or scratched.	Impact during assembly or use; pine wood can be soft.	Minor dents can sometimes be reduced with a damp cloth and gentle heat (e.g., iron over a cloth). For scratches, touch-up paint matching the white finish may be used.
Bed slats are damaged or broken.	Excessive weight, improper installation, or manufacturing defect.	Contact customer support for replacement slats. Ensure even weight distribution and avoid placing excessive localized pressure on slats.
Screws do not fit or are too short.	Incorrect screw selection or manufacturing variation.	Verify you are using the correct screws for each step. If screws are genuinely too short or faulty, contact customer support for replacements.

7. SPECIFICATIONS

Brand	Inter Link
-------	------------

Model	20900225
Color	White
Material	Pine Wood
Product Dimensions (L x W x H)	205 x 96 x 72 cm
Product Weight	15 kg
Recommended Mattress Size	90 x 200 cm (approx.)
Style	Modern




Image 7.1: Diagram illustrating the key dimensions of the Inter Link Los Angeles Single Bed: 205cm length, 96cm width, and 72cm height.

8. WARRANTY AND SUPPORT

For any questions, missing parts, or issues not covered in this manual, please contact Inter Link customer support or your retailer.

- **Returns:** This product is returnable within 30 days of receipt, subject to the retailer's return policy.
- **Customer Support:** Specialized customer support is available to assist you. Refer to your purchase documentation or the retailer's website for contact information.
- **Warranty:** Specific warranty details may vary by region and retailer. Please consult your purchase receipt or retailer for applicable warranty terms.

