

Bonaire BT014-U

Bonaire BT014-U Personal Space Mini Tower Fan Instruction Manual

Model: BT014-U

1. INTRODUCTION

Thank you for choosing the Bonaire BT014-U Personal Space Mini Tower Fan. This compact and efficient tower fan is designed to provide personal cooling in various indoor settings. Please read this manual thoroughly before operating your new fan to ensure safe and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Use this fan only as described in this manual. Other uses not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- To protect against electrical shock, do not immerse unit, plug, or cord in water or spray with liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Avoid contact with moving parts.
- Do not operate in the presence of explosive and/or flammable fumes.
- Do not place any part of the fan near an open flame, cooking or other heating appliance.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.

- To disconnect, grip plug and pull from wall outlet. Never yank on cord.
- Always use on a dry, level surface.
- Do not operate if the fan housing is removed or damaged.

3. PACKAGE CONTENTS

- Bonaire BT014-U Personal Space Mini Tower Fan
- Power Cord (integrated)

4. SETUP

Your Bonaire BT014-U Mini Tower Fan is designed for easy setup. Follow these steps to prepare your fan for use:

1. Carefully remove the fan from its packaging.
2. Place the fan on a firm, level surface. Ensure there is no obstruction to the airflow.
3. Uncoil the power cord and plug it into a standard 5 Volt electrical outlet.



Image: Bionaire BT014-U Mini Tower Fan placed on a table, ready for use.

5. OPERATING INSTRUCTIONS

The Bonaire BT014-U features intuitive push-button controls located on the top of the unit.

- **Power On/Off:** Press the **Power** button to turn the fan on or off.
- **Speed Settings:** The fan has 2 speed levels. Press the **Speed** button repeatedly to cycle through the available speeds (Low, High).
- **Oscillation:** To activate the oscillation feature, press the **Oscillation** button. The fan head will begin to move from side to side, distributing air across a wider area. Press the button again to stop oscillation at your desired position.

Your browser does not support the video tag.

Video: Demonstration of the JRD 13" Tower Fan's operation, including speed settings and oscillation. This video is provided by a seller and illustrates general tower fan functionality.

6. FEATURES

- **Compact Design:** Ideal for personal spaces, desks, or nightstands.
- **2 Speed Settings:** Choose between low and high airflow for personalized comfort.
- **Oscillation:** Distributes air across a wider area for enhanced cooling.
- **Quiet Operation:** Operates at a low noise level of 45 Decibels, suitable for bedrooms and offices.
- **Portable:** Lightweight design (3.5 Pounds) allows for easy relocation.
- **Easy Controls:** Simple push-button interface for straightforward operation.

7. MAINTENANCE

Regular cleaning of your fan will help to extend its life and ensure optimal performance.

1. Always unplug the fan before cleaning.
2. Use a soft, damp cloth to wipe the exterior surfaces of the fan.
3. Do not use gasoline, benzene, thinner, harsh cleaners, etc., as they will damage the fan.
4. Never immerse the fan in water.
5. For storage, clean the fan as instructed and store it in its original packaging or a suitable container in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not operate.	Power cord not plugged in.	Plug power cord into electrical outlet.
	No power at outlet.	Check circuit breaker or try another outlet.
Weak airflow.	Fan speed is too low.	Increase fan speed using the control buttons.
Excessive noise.	Fan is not on a level surface.	Place fan on a flat, stable surface.
	Obstruction in fan grille.	Unplug fan and remove any obstructions.

9. SPECIFICATIONS

- **Model Name:** BT014-U
- **Brand:** Bonaire

- **Color:** Black
- **Product Dimensions:** 6.7"D x 7.2"W x 13.4"H
- **Item Weight:** 3.5 Pounds
- **Power Source:** Corded Electric
- **Voltage:** 5 Volts
- **Wattage:** 30 watts
- **Noise Level:** 45 Decibels
- **Number of Power Levels:** 2
- **Control Method:** Push Button / Touch
- **Special Feature:** Portable
- **Installation Type:** Portable
- **Indoor/Outdoor Usage:** Indoor

10. WARRANTY AND SUPPORT

This Bonaire BT014-U Personal Space Mini Tower Fan comes with a **3-year limited warranty**. For warranty claims, technical support, or product inquiries, please refer to the contact information provided on the official Bonaire website or your purchase documentation.