

[Manuals.plus](#) /

› [Motorola](#) /

› Motorola HD Multimedia Dock for ATRIX 4G - Instruction Manual

Motorola 89459N

Motorola HD Multimedia Dock for ATRIX 4G - Instruction Manual

Model: 89459N

1. INTRODUCTION

The Motorola HD Multimedia Dock is designed to enhance the functionality of your Motorola ATRIX 4G smartphone. This dock allows you to connect your device to external displays, USB peripherals, and power, transforming your phone into a versatile multimedia and productivity hub. It enables features such as Webtop mode, providing a desktop-like experience, and facilitates easy charging and data transfer.



The Motorola ATRIX 4G phone, when placed in the dock, provides access to its features and Webtop mode.

2. PACKAGE CONTENTS

Verify that your package contains the following items:

- Motorola HD Multimedia Dock
- Remote Control
- Power Adapter



The included remote control allows for convenient navigation and control of the ATRIX 4G's functions while docked.



The power adapter provides the necessary electrical supply to the dock for charging the phone and powering connected peripherals.

3. FEATURES

The Motorola HD Multimedia Dock offers several features to enhance your mobile experience:

- Designed specifically for the Motorola ATRIX 4G.
- Connect multiple USB accessories for expanded functionality.
- Enables Webtop mode for a desktop-like computing experience.
- Provides immediate interaction with applications and shortcuts.

- Allows web browsing with a full Firefox browser when connected to a display.



The rear panel of the dock features a micro-HDMI output for display connection, three USB ports for peripherals, and a 3.5mm audio output.

4. SETUP

4.1 Connecting the Power Adapter

1. Connect the power adapter cable to the power input port on the rear of the Multimedia Dock.
2. Plug the power adapter into a standard electrical outlet.

4.2 Connecting to a Display

1. Connect a micro-HDMI to HDMI cable (not included) from the micro-HDMI port on the rear of the dock to an HDMI input on your television or monitor.
2. Ensure your display is set to the correct HDMI input source.

4.3 Connecting Peripherals

The dock features three USB-A ports for connecting external devices such as a keyboard, mouse, or USB storage.

1. Plug your USB peripherals into the available USB ports on the rear of the dock.



This view demonstrates the dock with essential cables connected, including HDMI for video output and USB for external devices.

4.4 Inserting the Motorola ATRIX 4G Phone

Important: The Motorola HD Multimedia Dock is designed for the Motorola ATRIX 4G phone without a protective case. Remove any phone cases before docking.

1. Align the Motorola ATRIX 4G phone with the docking slot, ensuring the phone's micro-USB and micro-HDMI ports match the dock's connectors.
2. Gently press the phone down into the dock until it is securely seated. The phone should begin charging, and the display may switch to a dock or Webtop interface.




Proper insertion of the Motorola ATRIX 4G phone into the dock ensures secure connection and activation of dock features.

5. OPERATING INSTRUCTIONS

5.1 Webtop Mode

Once your ATRIX 4G is docked and connected to an external display, Webtop mode should activate automatically. This mode provides a desktop-like environment, allowing you to:

- Access a full Firefox web browser.
- Use desktop versions of applications.
- Manage files and documents.
- Interact with your phone's features on a larger screen.



This image illustrates the Webtop Mode interface, which provides a desktop-like experience when the phone is connected to an external display via the dock.

5.2 Using the Remote Control

The included remote control allows for convenient navigation and control within Webtop mode and other docked applications. Familiarize yourself with the buttons for menu navigation, media playback, and system functions.

6. MAINTENANCE

To ensure the longevity and proper functioning of your Motorola HD Multimedia Dock, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior of the dock. Avoid using harsh chemicals, cleaning solvents, or abrasive materials.
- **Storage:** When not in use, store the dock in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the dock with care to prevent damage to the connectors and ports.

7. TROUBLESHOOTING

If you encounter issues with your Motorola HD Multimedia Dock, refer to the following common troubleshooting steps:

- **No Power:** Ensure the power adapter is securely connected to both the dock and a working electrical outlet.
- **No Display Output:** Verify that the HDMI cable is correctly connected to both the dock and the display. Check that your display is set to the correct HDMI input source.
- **Phone Not Recognized/Charging:** Ensure the Motorola ATRIX 4G phone is properly seated in the dock and that no protective case is interfering with the connection. Restarting the phone and re-docking it may resolve the issue.
- **Peripherals Not Working:** Confirm that USB peripherals are correctly plugged into the dock's USB ports. Test peripherals with another device if possible to rule out device malfunction.
- **Webtop Mode Not Activating:** Ensure the phone is fully docked and the HDMI connection to the display is active.

Some Webtop features, like the Firefox browser, may require an appropriate data plan from your service provider.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	6.04 x 1.44 x 8.58 inches
Item Weight	1.02 pounds (0.46 kg)
Item Model Number	89459N
Wireless Communication Technologies	Bluetooth
Connectivity Technologies	USB
Color	Black
Manufacturer	Motorola
Hardware Interface	USB
Compatible Devices	Motorola ATRIX 4G
Total USB Ports	3
Total HDMI Ports	1 (Micro-HDMI)
Wattage	18 watts
UPC	723755894594

9. SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please visit the official Motorola support website or contact Motorola customer service. Refer to your phone's documentation for specific support contact information.

10. WARRANTY INFORMATION

This product is covered by Motorola's standard limited warranty. Please refer to the warranty card included with your original purchase or visit the Motorola website for detailed terms and conditions regarding warranty coverage, duration, and claims procedures. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B004LWYYZ0>

More documents and user manuals: <https://manuals.plus/>