

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Sebo](#) /

> [SEBO 6391DA PARQUET Brush Instruction Manual](#)

Sebo 6391DA

SEBO 6391DA PARQUET Brush Instruction Manual

Model: 6391DA

INTRODUCTION

Thank you for choosing the SEBO 6391DA PARQUET Brush. This accessory is designed to provide effective and gentle cleaning for hard floor surfaces, such as hardwood, laminate, and tile, when used with compatible SEBO vacuum cleaners. Please read this manual thoroughly before use to ensure proper operation and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the vacuum cleaner is unplugged before attaching or detaching the brush.
- Do not use the brush on wet surfaces or to pick up liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Store the brush in a dry place when not in use.

SETUP AND INSTALLATION

The SEBO 6391DA PARQUET Brush is designed for easy attachment to compatible SEBO vacuum cleaner wands or hoses.

1. Ensure your SEBO vacuum cleaner is turned off and unplugged from the power outlet.
2. Locate the end of your vacuum's wand or hose where accessories are attached.
3. Align the opening of the SEBO 6391DA PARQUET Brush with the end of the wand/hose.
4. Push the brush firmly onto the wand/hose until it clicks securely into place. A secure connection is essential for optimal performance.



Image: The SEBO 6391DA PARQUET Brush, a dark gray vacuum attachment with a wide head and soft bristles, designed for cleaning hard floors. It features a cylindrical connection point for attachment to a vacuum wand or hose.

OPERATING INSTRUCTIONS

This parquet brush is ideal for cleaning delicate hard floor surfaces without scratching.

- Once securely attached, turn on your SEBO vacuum cleaner.
- Gently glide the brush head over your hard floor surfaces. The soft bristles are designed to pick up dust, dirt, and debris effectively while protecting your floors.
- For best results, use slow, overlapping strokes.
- The brush's swivel neck allows for easy maneuverability around furniture and into tight spaces.

CARE AND MAINTENANCE

Regular maintenance will prolong the life and effectiveness of your PARQUET brush.

- **Cleaning the Bristles:** Periodically inspect the bristles for tangled hair or debris. Use scissors or a brush cleaning tool to carefully remove any obstructions.
- **Wiping the Head:** Wipe the exterior of the brush head with a damp cloth to remove dust and grime. Do not immerse the brush in water.
- **Storage:** Store the brush in a clean, dry place, ideally attached to your vacuum or in a designated accessory storage area, to prevent damage to the bristles.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Brush not picking up debris effectively.	Bristles are clogged with hair or debris.	Clean the bristles as described in the "Care and Maintenance" section.
Brush detaches easily from wand/hose.	Not securely attached; incompatible wand/hose.	Ensure the brush is pushed firmly until it clicks. Verify compatibility with your SEBO vacuum model.
Brush leaves marks on floor.	Debris stuck in bristles or on the brush head.	Inspect and clean the brush head and bristles thoroughly.

SPECIFICATIONS

Model: 6391DA

Brand: Sebo

Type: Parquet Brush / Hard Floor Nozzle

Compatibility: Designed for SEBO Upright and Canister Vacuums (Note: Some older models may require specific adapters. Refer to your vacuum's manual.)

Color: Gray

Item Weight: 4 ounces

Package Dimensions: 11.7 x 5.5 x 2.5 inches

UPC: 759284920633, 789322606182, 676224013593, 676224063918

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your SEBO vacuum cleaner or visit the official SEBO website. This accessory is typically covered under the general accessory warranty terms.

For technical support or replacement parts, please contact SEBO customer service or an authorized SEBO dealer.

Contact information can usually be found on the SEBO official website or in your vacuum cleaner's main manual.

Note: Using non-genuine SEBO parts or unauthorized repairs may void your product's warranty.



© 2025 SEBO. All rights reserved.

This manual is for informational purposes only. SEBO reserves the right to make changes to products and specifications without prior notice.