

Cuddeback Attack Ir

Cuddeback Attack IR 5MP Game Camera Instruction Manual

Model: Attack Ir (1156)

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Cuddeback Attack IR 5MP Game Camera. Please read this manual thoroughly before using the camera to ensure optimal performance and longevity.

The Cuddeback Attack IR 5MP Game Camera is designed for capturing high-quality still images and video clips of wildlife, day or night. It features advanced infrared technology for discreet operation and a rapid trigger speed to minimize missed events.

2. PRODUCT OVERVIEW

The Attack IR camera is equipped with a 5-megapixel sensor, 36 high-power infrared LEDs, and a robust housing suitable for outdoor use. Key features include:

- 5-megapixel resolution for both day and night images and videos.
- 36 high-power infrared LEDs providing a true 60-foot flash range.
- Ultra-fast 1/4-second trigger speed.
- Exclusive Centered Subject Technology for improved capture.
- Ability to capture 30-second video clips at 24 frames per second.
- Guard Duty mode for continuous monitoring (5 pictures per minute).
- 60 MB internal memory and an SD card slot for expanded storage.
- Requires 4 D-cell batteries for operation.
- Includes a tree mount for easy installation.



Image 2.1: The Cuddeback Attack IR 5MP Game Camera. This image shows the camera's front view, highlighting its compact design and infrared LED array.

3. SETUP

3.1. Battery Installation

1. Open the camera's rear cover.
2. Insert 4 D-cell batteries into the battery compartment, ensuring correct polarity (+/-).
3. Close the rear cover securely.

3.2. SD Card Installation

1. Locate the SD card slot inside the camera.
2. Insert a compatible SD card (up to 32 GB recommended) into the slot until it clicks into place.
3. To remove, press the card gently to release it.

3.3. Mounting the Camera

The camera includes a tree mount for secure placement.

1. Attach the tree mount to a sturdy tree or post at the desired height and angle.
2. Secure the camera onto the two attachment points on the belt around the tree mount.
3. Ensure the camera is stable and pointed towards the area you wish to monitor.

4. OPERATING INSTRUCTIONS

4.1. Powering On and Setting Modes

The camera features a control dial for easy selection of operating modes and settings.

1. Open the camera's rear cover to access the control dial.
2. Turn the dial to select the desired interval between trigger events (e.g., 5 seconds, 30 minutes).
3. For continuous monitoring, select the "Guard Duty" setting, which captures 5 pictures per minute.
4. Close the rear cover securely to protect the internal components from the elements.

4.2. Capturing Images and Videos

Once powered on and configured, the camera will automatically capture images or videos based on motion detection and your selected settings. The 1/4-second trigger speed ensures quick response to movement.

4.3. Retrieving Images and Videos

1. Open the camera's rear cover.
2. Turn the control dial to the "OFF" position.
3. Carefully remove the SD card from its slot.
4. Insert the SD card into a compatible card reader on your computer or device.
5. Download the captured images and videos to your computer.
6. After downloading, it is recommended to format the SD card in the camera or erase its contents to prepare for further use.

5. MAINTENANCE

5.1. Battery Life

The Cuddeback Attack IR camera is designed for extended battery life, capable of capturing up to 50,000 images on a single set of 4 D-cell batteries, depending on usage and environmental conditions. Regularly check battery levels, especially before deploying the camera for long periods.

5.2. Cleaning

- Wipe the camera's exterior with a soft, damp cloth to remove dirt and debris.
- Ensure the lens and IR LEDs are clean and free from obstructions for clear image capture.
- Do not use harsh chemicals or abrasive cleaners.

5.3. Storage

When not in use, store the camera in a cool, dry place. Remove batteries if storing for an extended period to prevent leakage.

6. TROUBLESHOOTING

6.1. Camera Not Powering On

- Check that the 4 D-cell batteries are inserted correctly with proper polarity.
- Ensure batteries are fresh and fully charged.
- Verify the control dial is not set to "OFF".

6.2. No Images/Videos Captured

- Confirm an SD card is properly inserted and not full.
- Check the selected trigger interval setting; ensure it is appropriate for the desired capture frequency.
- Verify the camera's placement and angle to ensure it covers the intended detection area.
- Ensure the camera is not obstructed by foliage or other objects.

6.3. Blurry or Poor Quality Images

- Clean the camera lens and IR LED array.
- Ensure the camera is securely mounted to prevent movement.
- Check for condensation inside the lens, which may indicate a seal issue.

6.4. IR Failure / Black Images at Night

- Ensure batteries have sufficient power for IR illumination.
- Check for any physical obstructions blocking the IR LEDs.

7. SPECIFICATIONS

Feature	Specification
Brand	Cuddeback
Model Number	1156 (Attack Ir)
Effective Still Resolution	5 MP
Effective Video Resolution	5 MP

Trigger Speed	1/4-second
Flash Range	60 feet (36 high-power IR LEDs)
Internal Memory	60 MB
Memory Card Type	SD (up to 32 GB)
Night Vision	Night Color
Power Source	4 D-cell batteries
Waterproof Rating	IP54
Item Dimensions	11.75 x 6.5 x 5.25 inches
Item Weight	0.27 g
Mount Type	Tree Mount

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official Cuddeback website. Product registration may be required to activate your warranty, which is typically 18 months from the date of first use.

For technical support or service inquiries, please contact Cuddeback customer service directly. Contact details are usually available on the manufacturer's website or in the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question