

Camco 43672

Camco Folding Metal Step Stool (Model 43672) Instruction Manual

Detailed instructions for the safe and effective use of your Camco Folding Metal Step Stool.

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using the Camco Folding Metal Step Stool. Failure to follow these instructions may result in injury or damage.

- **Maximum Weight Capacity:** This step stool is designed to support a maximum weight of **200 lbs (90.7 kg)**. Do not exceed this limit.
- Always ensure the step stool is fully opened and stable on a flat, level, and non-slip surface before stepping onto it.
- Do not use the step stool on uneven or unstable ground.
- Avoid standing on the very edge of the step stool. Position your feet centrally on the platform.
- Keep hands and fingers clear of all moving parts, especially during the folding and unfolding process, to prevent pinching.
- Do not use the step stool if any parts are damaged or missing.
- This product is intended for adult use. Keep out of reach of children when not in use.

2. SETUP AND UNFOLDING

The Camco Folding Metal Step Stool arrives in a folded configuration for compact storage. Follow these steps to unfold it for use:

1. Place the folded stool on a flat, stable surface.
2. Grasp the top platform with one hand and the legs with the other.
3. Gently pull the legs outwards until they fully extend and the locking mechanisms engage. You should hear a click or feel the legs lock into place. Ensure the support bars on both sides are pushed down and locked.
4. Verify that all four legs are firmly on the ground and the stool is stable before applying any weight.



Figure 2.1: The Camco Folding Metal Step Stool in its fully open position.



Figure 2.2: Detail of the hinge mechanism, showing the engaged locking pin for stability.

3. OPERATING INSTRUCTIONS

Once unfolded and stable, the step stool can be used to safely reach elevated areas. Its lightweight aluminum construction makes it suitable for various applications.

- Use the stool to access hard-to-reach areas in kitchens, closets, or RVs.
- It can also serve as a convenient step for entering or exiting taller vehicles like trucks.
- Always maintain three points of contact (two hands and one foot, or two feet and one hand) when ascending or descending the stool.
- Do not lean excessively to the side while on the stool. Reposition the stool closer to your work area if necessary.

Folding for Storage:

To fold the stool for compact storage:

1. Ensure no weight is on the stool.
2. Locate the small posts on the brace bars on both sides of the stool.
3. Pull up on these posts until the brace bars become loose. Perform this action on both sides simultaneously or one after the other.
4. Once the braces are disengaged, gently push the legs inwards until the stool folds flat.



Figure 3.1: The step stool in its folded state, ready for storage.

4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your step stool.

- **Cleaning:** Wipe the stool with a damp cloth and mild detergent as needed. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** If the folding mechanism becomes stiff over time, apply a small amount of silicone-based lubricant or WD-40 to the hinge points and moving parts. This will help ensure smooth operation.
- **Inspection:** Periodically inspect the stool for any signs of damage, loose fasteners, or wear on the feet. Do not use if damaged.

5. TROUBLESHOOTING

- **Stool is difficult to fold or unfold:** Ensure the locking mechanisms are fully disengaged before attempting to fold

or unfold. Apply lubricant to the hinge points as described in the Maintenance section.

- **Sticker residue on the platform:** Some users have reported difficulty removing the product sticker from the platform. If residue remains after peeling, use a product like Goo Gone or a similar adhesive remover, following the product's instructions. Avoid scraping with sharp objects that could damage the surface.

6. SPECIFICATIONS

Model Number	43672
Brand	Camco
Material	Aluminum
Color	Silver
Maximum Height (Open)	11.5 inches (29.2 cm)
Weight Capacity	200 lbs (90.7 kg)
Item Weight	16 ounces (0.45 kg)
Number of Steps	1

7. WARRANTY INFORMATION

This Camco Folding Metal Step Stool is covered by a manufacturer's warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or visit the official Camco website.

8. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your Camco Folding Metal Step Stool, please contact Camco customer support. Contact information can typically be found on the product packaging or the official Camco website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question