

[Manuals.plus](#) /

› [BLACK+DECKER](#) /

› BLACK+DECKER Dustbuster Replacement Filter VF110 User Manual

BLACK+DECKER VF110

BLACK+DECKER Dustbuster Replacement Filter VF110 User Manual

Model: VF110

INTRODUCTION

This manual provides essential instructions for the proper installation, maintenance, and care of your BLACK+DECKER Dustbuster Replacement Filter, model VF110. Adhering to these guidelines will ensure optimal performance and longevity of your Dustbuster handheld vacuum.

PRODUCT OVERVIEW

The BLACK+DECKER VF110 is a washable replacement filter designed for various Dustbuster handheld vacuum models. Regular replacement and cleaning of the filter are crucial for maintaining the vacuum's suction power and efficiency.

Compatible Models:

- CHV9610
- CHV1210
- CHV1410
- CHV1410B
- CHV1410L
- CHV1510
- BDH2000L
- CHV1400
- CHV1500
- CHV1560

INSTALLATION INSTRUCTIONS

Follow these steps to replace the filter in your BLACK+DECKER Dustbuster handheld vacuum:

1. **Ensure the vacuum is turned off and unplugged**(if applicable) before beginning any maintenance.
2. **Locate the dust bowl release button or latch** on your Dustbuster. Press or slide it to detach the dust bowl from the main unit.
3. **Remove the old filter assembly** from the dust bowl. This typically involves twisting or pulling the filter out.
4. **Separate the old filter from its plastic frame** (if applicable). The VF110 filter is designed for tool-free installation.
5. **Insert the new VF110 replacement filter** into the dust bowl, ensuring it is seated correctly and securely.
6. **Reattach the dust bowl** to the main vacuum unit, ensuring it clicks firmly into place.



Image: The VF110 filter shown separated from the dust collection cup, illustrating the ease of removal and installation.

OPERATING PRINCIPLES

The VF110 filter is a critical component of your Dustbuster's suction system. It captures dust and debris, preventing them from entering the motor and being expelled back into the air. A clean filter ensures maximum airflow and efficient dirt collection.

Better suction

Regularly replacing filters helps improve suction power.



Image: The VF110 filter, highlighting its role in maintaining optimal suction power for your vacuum.

MAINTENANCE

To maintain peak performance of your Dustbuster, regular cleaning and timely replacement of the VF110 filter are essential.

Cleaning the Filter:

1. **Remove the filter** as described in the "Installation Instructions" section.
2. **Tap the filter gently** over a waste bin to dislodge loose dirt and dust.

- 3. **Rinse the filter under cool running water.** Ensure all trapped debris is washed away.
- 4. **Allow the filter to air dry completely** for at least 24 hours before reinserting it into the vacuum. Do not use heat to dry the filter, as this can damage the material.

Replacement Frequency: It is recommended to replace the filter every 6 to 9 months, or more frequently depending on usage and the type of debris collected. A new filter helps restore suction power and maintain air quality.



Image: A detailed view of the BLACK+DECKER VF110 filter, illustrating its design for effective filtration.

TROUBLESHOOTING

Reduced Suction Power:

- **Check the filter:** A clogged or dirty filter is the most common cause of reduced suction. Clean or replace the VF110 filter as per the maintenance instructions.
- **Ensure proper installation:** Verify that the filter is correctly seated and the dust bowl is securely attached to the vacuum.

SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	VF110
Product Dimensions	5.19" L x 3.62" W x 4.88" H
Item Weight	2.08 ounces
Material	Blend
Reusability	Reusable (Washable)
Included Components	1 washable filter

WARRANTY AND SUPPORT

This BLACK+DECKER VF110 Replacement Filter is covered by a **2-year limited warranty**. For detailed warranty information or technical support, please refer to the official BLACK+DECKER website or contact their customer service department. Keep your purchase receipt as proof of purchase.

