

## Sony RDPM5iP

# Sony RDPM5IP 30-Pin iPhone/iPod Portable Speaker Dock Instruction Manual

Model: RDPM5iP

## INTRODUCTION

The Sony RDP-M5iP speaker dock is designed to enhance your music experience on the go. This portable speaker dock offers rich sound reproduction and convenient features for your 30-pin iPhone or iPod devices.

## Key Features:

- Up to 10 hours of continuous AAA battery operation for portable use.
- Easy-access battery compartment for quick battery swaps.
- Charges your iPod or iPhone while docked, preventing battery drain.
- Stereo speakers deliver full, rich bass tones for an enjoyable listening experience.

## SETUP

Follow these steps to set up your Sony RDPM5IP speaker dock:

1. **Power Connection:** Connect the provided AC power adapter to the DC IN jack on the speaker dock and then to a wall outlet. Alternatively, for portable use, insert 4 AAA batteries into the battery compartment.
2. **Device Docking:** Carefully align your 30-pin iPhone or iPod with the dock connector on the speaker and gently push down until it is securely seated.
3. **Power On:** Press the power button on the speaker dock or the remote control to turn on the device.
4. **Volume Adjustment:** Use the volume controls on the speaker dock or remote control to set your desired listening level.

## Enhancing Connectivity:

For wireless streaming from newer devices, a 30-pin Bluetooth adapter can be used. For charging older iPods with modern USB-C chargers, a USB-C to 30-pin cable is available.

**Video:** Connecting a ZIOCOM Bluetooth adapter to a 30-pin Sony speaker dock. This video demonstrates how to easily integrate a Bluetooth adapter into your existing 30-pin dock, allowing for wireless audio streaming from compatible devices.

**Video:** Charging an iPod Classic with a USB-C to 30-pin cable. This video illustrates the use of a USB-C to 30-pin adapter cable to charge and sync older iPod Classic models with modern USB-C power sources, ensuring continued usability of legacy devices.

**Video:** KabelDirekt USB-C to 30-pin adapter demonstration. This video provides a brief overview of the KabelDirekt USB-C adapter, showcasing its functionality for charging and data transfer between USB-C devices and older Apple products with 30-pin connectors.

## OPERATING INSTRUCTIONS

---

Once your device is docked and the speaker is powered on, you can control your music playback:

- **Music Playback:** Music from your docked iPhone or iPod will automatically play through the speaker.
- **Volume Control:** Use the '+' and '-' buttons on the speaker or remote to adjust the volume.
- **Track Navigation:** Use the 'Previous' and 'Next' track buttons on the remote control to skip songs.
- **Play/Pause:** Use the 'Play/Pause' button on the remote control to control playback.
- **Remote Control:** The included remote allows convenient control of playback functions from a distance.

## MAINTENANCE

---

To ensure optimal performance and longevity of your speaker dock:

- **Cleaning:** Wipe the exterior of the speaker dock with a soft, dry cloth. Avoid using liquid cleaners or solvents.
- **Battery Replacement:** When operating on batteries, replace all 4 AAA batteries when the power indicator shows low battery. Ensure correct polarity when inserting new batteries.
- **Storage:** Store the speaker dock in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

## TROUBLESHOOTING

---

If you encounter issues with your Sony RDPM5IP, try the following:

- **No Power:** Ensure the AC adapter is securely connected to both the speaker dock and a working power outlet. If using batteries, check if they are inserted correctly and have sufficient charge.
- **No Sound:** Verify that your iPhone/iPod is properly docked. Check the volume levels on both the speaker dock and your device. Ensure the device is playing music.
- **Remote Control Not Working:** Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the speaker dock.
- **Poor Sound Quality:** Ensure your device is securely docked. Try adjusting the volume. If using a Bluetooth adapter, ensure it is properly connected and paired.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Product Dimensions	6.46 x 8.9 x 6.5 inches
Item Weight	1 pounds (16 ounces)
Batteries Required	4 AAA batteries
Compatible Devices	iPod, iPhone (30-pin connector)
Hardware Interface	USB Docking Station
Wattage	4 watts
Color	Black

## **WARRANTY AND SUPPORT**

---

This product is covered by Sony's standard manufacturer warranty. For detailed warranty information, product registration, or technical support, please refer to the documentation included with your purchase or visit the official Sony support website.

Always ensure you are using genuine accessories and following recommended guidelines to maintain your product's warranty validity.