Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jaclo 814-SC

Jaclo 814-SC Finger Touch Drain without Overflow Holes, Satin Chrome User Manual

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Jaclo 814-SC Finger Touch Drain without Overflow Holes. Please read this manual thoroughly before installation and retain it for future reference. Proper installation and care will ensure optimal performance and longevity of your product.

Product Overview

The Jaclo 814-SC is a high-quality finger touch drain designed for sinks that do not have an overflow hole. Its satin chrome finish provides a durable and aesthetically pleasing appearance. The finger touch mechanism allows for easy opening and closing of the drain.



A detailed view of the Jaclo 814-SC Finger Touch Drain, showcasing its satin chrome finish, the threaded upper body for installation, and the smooth lower pipe section. The finger touch stopper is visible at the top.

Setup and Installation

Professional installation is recommended. Ensure all local plumbing codes are followed. Tools required typically include a wrench, plumber's putty or silicone sealant, and a cloth.

1. **Prepare the Sink Opening:** Ensure the sink drain opening is clean and free of debris.
2. **Apply Sealant:** Apply a bead of plumber's putty or silicone sealant around the underside of the drain flange (the top part that sits in the sink).
3. **Insert Drain Body:** Insert the drain body through the sink opening from the top. Press firmly to create a seal.

4. **Secure from Below:** From underneath the sink, slide the rubber washer, friction washer, and mounting nut onto the threaded portion of the drain body.
5. **Tighten Connections:** Hand-tighten the mounting nut, then use a wrench to tighten it securely. Do not overtighten, as this can damage the sink or drain. Wipe away any excess sealant.
6. **Connect to P-Trap:** Connect the lower portion of the drain to your existing P-trap assembly. Ensure all connections are tight to prevent leaks.
7. **Test for Leaks:** Fill the sink with water and then drain it, carefully checking all connections for any signs of leakage.

Operating Instructions

The Jaclo 814-SC features a simple finger touch mechanism for controlling water flow.

- **To Close the Drain:** Gently press down on the top of the drain stopper until it clicks into the closed position. This will seal the drain, allowing the sink to hold water.
- **To Open the Drain:** Gently press down on the top of the drain stopper again until it clicks into the open position. This will allow water to flow freely down the drain.

Maintenance

Regular cleaning and maintenance will help preserve the finish and functionality of your drain.

- **Cleaning the Finish:** Clean the satin chrome finish regularly with a soft cloth and mild soap and water. Rinse thoroughly and dry immediately to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or chemical-based cleaning agents, as these can damage the finish.
- **Check for Debris:** Periodically remove the stopper and check for any hair or debris that may have accumulated, which could impede drainage. Clean as necessary.

Troubleshooting

If you encounter issues with your drain, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Slow Draining	Accumulation of hair or debris in the drain.	Remove the stopper and clear any obstructions.
Water Leakage	Loose connections or insufficient sealant during installation.	Check all connections for tightness. Reapply plumber's putty or sealant if necessary.
Stopper Not Sealing Properly	Debris under the stopper or a worn seal.	Clean the stopper and the drain seat. Inspect the rubber seal for damage and replace if needed.
Stopper Mechanism Sticking	Mineral buildup or lack of lubrication.	Clean the mechanism thoroughly. A small amount of silicone grease can be applied to moving parts if accessible.

Specifications

Key specifications for the Jaclo 814-SC Finger Touch Drain:

Feature	Detail
Brand	Jaclo
Model Number	814-SC
Color	Satin Chrome
Item Weight	0.91 Pounds (approximately 14.5 ounces)
Product Dimensions	3 x 3 x 7 inches
UPC	020111018466
Overflow Holes	None
Manufacturer	Standard Plumbing Supply

Warranty Information

For specific warranty details regarding your Jaclo 814-SC Finger Touch Drain, please refer to the documentation provided with your purchase or contact Jaclo directly. Warranty terms and conditions may vary.

Support

If you require further assistance or have questions not covered in this manual, please contact Jaclo customer support or your authorized retailer. Provide your model number (814-SC) when seeking support.

Manufacturer: Standard Plumbing Supply

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004NQA552

More documents and user manuals: **https://manuals.plus/**