

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BOSKA](#) /

› [Boska Partyclette To Go Raclette Grilling Set \(Model 852040\) - Instruction Manual](#)

BOSKA 852040

Boska Partyclette To Go Raclette Grilling Set

MODEL: 852040

Introduction

The Boska Partyclette To Go Raclette Grilling Set offers a portable and convenient way to enjoy melted cheese. This set utilizes tea lights to gently melt cheese in a non-stick pan, perfect for enhancing various dishes. Its compact design makes it suitable for use in diverse settings, from intimate dinners to outdoor gatherings.

Safety Information

- Use only standard tea lights as the heat source. Do not use other flammable materials.
- Always place the raclette set on a stable, heat-resistant surface.
- Keep the unit away from flammable objects, curtains, and other combustible materials.
- Do not leave the raclette set unattended while in use.
- Keep out of reach of children and pets.
- The pan and metal parts will become hot during use. Use the wooden handle and spatula to avoid direct contact with hot surfaces.
- Allow the unit to cool completely before cleaning or storing.

Package Contents

Verify that all components are present in your Boska Partyclette To Go Raclette Grilling Set:

- 1 x Raclette Base (with wooden feet)
- 1 x Non-stick Raclette Pan with foldable wooden handle
- 1 x Spatula
- 3 x Tea Lights
- 1 x Instruction Manual (this document)

Setup

1. Unpack all components from the packaging.
2. Place the raclette base on a flat, stable, and heat-resistant surface.

3. Insert the three provided tea lights into the designated slots within the raclette base.
4. Unfold the handle of the raclette pan and place the pan securely on top of the base, ensuring it is centered over the tea lights.



Figure 1: Assembled Boska Partyclette To Go Raclette Grilling Set with melted cheese and spatula.

Video 1: Overview of the Boska Holland Partyclette To-Go Taste, Mini Tea Light Raclette Set, demonstrating its compact design and ease of assembly.

Operating Instructions

1. After setting up the unit, carefully light the tea lights in the base.
2. Place your desired cheese (e.g., raclette cheese, cheddar, brie) into the non-stick raclette pan.
3. Position the pan over the lit tea lights. The cheese will begin to melt within approximately 3-4 minutes, depending on the type and thickness of the cheese.
4. Once the cheese is melted to your preference, use the included spatula to scrape the melted cheese directly onto your food, such as bread, vegetables, or meat.



Figure 2: A hand lighting the tea lights within the raclette base, initiating the heating process.



Figure 3: A person using the spatula to scrape melted cheese from the raclette pan onto a piece of bread.



Figure 4: The raclette set in use, melting cheese to be served with nachos and other accompaniments.

Video 2: Demonstration of the Partylette ToGo Vienna, showcasing its use for melting cheese and serving with various foods.

Cleaning and Maintenance

- Allow all components to cool completely before cleaning.
- The non-stick raclette pan is designed for easy cleaning. It is also dishwasher safe.
- Hand wash the wooden base and handle with mild soap and water. Do not soak wooden parts.
- Ensure all parts are thoroughly dry before storing.

Storage

The Boska Partylette To Go Raclette Grilling Set features a foldable design for compact storage. Once clean and dry, fold the pan handle and store all components together in a safe, dry place.

Troubleshooting

- **Cheese not melting sufficiently:** Ensure tea lights are fully lit and positioned directly under the pan.

Replace old tea lights with new ones if necessary. Allow adequate time for the cheese to melt.

- **Cheese sticking to the pan:** Although the pan is non-stick, ensure it is clean before use. Avoid using metal utensils that could scratch the non-stick coating.

Specifications

Model Number	852040
Material	Cast iron and wood
Color	Black
Product Dimensions (L x W x H)	7.28"D x 3.86"W x 0.31"H
Item Weight	1.01 pounds (0.46 Kilograms)
Special Feature	Portable




Figure 5: Dimensional diagram of the Boska Partylette To Go Raclette Grilling Set.

Warranty and Support

Boska is committed to providing durable and high-quality food tools. The Boska Partylette To Go Raclette Grilling Set is designed for lasting performance. For any product inquiries or support, please refer to the manufacturer's official website or contact their customer service directly.