

Sonic Alert SBJ525SS

Sonic Alert SBJ525SS Digital Alarm Clock Instruction Manual

Model: SBJ525SS

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Sonic Alert SBJ525SS Digital Alarm Clock. Please read this manual thoroughly before using the device to ensure proper function and longevity. This alarm clock is designed to provide reliable timekeeping and alarm functions, including a powerful vibrating bed shaker, loud audible alarm, and visual alert features.

SAFETY INFORMATION

- Ensure the power adapter is connected to a standard electrical outlet.
- Do not expose the unit to water or excessive moisture.
- Avoid placing the unit near heat sources or in direct sunlight.
- Keep out of reach of children.
- Use only the provided power adapter and bed shaker.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Sonic Alert SBJ525SS Digital Alarm Clock Unit
- 12-Volt Vibrating Bed Shaker
- Power Adapter
- Instruction Manual

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your alarm clock.



Image Description: A diagram illustrating the Sonic Alert SBJ525SS Digital Alarm Clock. Key features highlighted include the 12 or 24-hour display, battery backup, dual alarms, selectable vibrate/buzz combination, adjustable volume and tone, 5-level dimmer, and the super shaker bed vibrating unit. The clock supports 120V & 240V power.

The clock features a large digital display, control buttons for time and alarm settings, and adjustment knobs for volume and tone. A dedicated port is available for the bed shaker connection.

SETUP

1. Power Connection

1. Connect the power adapter to the DC IN jack on the back of the alarm clock.
2. Plug the power adapter into a standard electrical wall outlet. The display will illuminate.

2. Battery Backup Installation

The alarm clock requires 2 AA batteries (not included) for battery backup functionality. This ensures your time and

alarm settings are retained during a power outage.

- Locate the battery compartment on the bottom of the unit.
- Open the battery compartment cover.
- Insert 2 AA batteries, observing the correct polarity (+/-).
- Replace the battery compartment cover.



SONIC BLAST ALARM CLOCKS

Inspired by our Classic Sonic Bomb, the Sonic Blast Alarm Clocks are loud bluetooth alarm clocks that are available in 2 different models

- 1) SB775 Projection Alarm Clock
- 2) SB750 Non-Projection Alarm Clock



Image Description: A graphic illustrating the battery backup feature of the alarm clock. It shows the clock on a nightstand with a small circular battery icon (CR2032, 3V) next to it, indicating the type of battery used for backup. The text emphasizes that batteries are not included and are for retaining settings during power outages.

3. Time Setting

1. Press and hold the **TIME SET** button. The hour digits will begin to flash.
2. Press the **HOUR** button repeatedly to adjust the hour. Observe the PM indicator for correct AM/PM setting.
3. Press the **MIN** button repeatedly to adjust the minutes.
4. Press **TIME SET** again to confirm the time.
5. To switch between 12-hour and 24-hour format, press the **12/24H** button (if available, otherwise it might be part of time set cycle).

4. Bed Shaker Connection

The vibrating bed shaker is an integral part of the Sonic Alert system, designed for heavy sleepers or individuals with hearing impairments.

1. Locate the jack labeled **SHAKER** on the back of the alarm clock.
2. Insert the plug of the bed shaker into this jack.
3. Place the bed shaker under your pillow, between your mattress and box spring, or under a fitted sheet for optimal vibration.

SUPER BED SHAKER TO SHAKE YOU AWAKE

3 MODES



Shaker



Loud Alarm



Alarm + Shaker



6ft Long
Cable



Place Under Pillow



Under Fitted Sheet



Under Mattress

Image Description: A composite image showing three different methods for placing the super bed shaker: under a pillow, under a fitted sheet, and under a mattress. The image also highlights the 6ft long cable of the shaker.

OPERATING INSTRUCTIONS

1. Setting Alarms (Dual Alarms)

The SBJ525SS features dual alarms, allowing you to set two independent wake-up times.

1. Press and hold the **ALARM SET/OFF** button once for Alarm 1. The hour digits for Alarm 1 will flash.
2. Use the **HOUR** and **MIN** buttons to set the desired alarm time.
3. Press **ALARM SET/OFF** again to confirm Alarm 1 and proceed to Alarm 2. The hour digits for Alarm 2 will flash.
4. Use the **HOUR** and **MIN** buttons to set the desired time for Alarm 2.
5. Press **ALARM SET/OFF** a third time to confirm Alarm 2 and exit alarm setting mode.
6. To activate or deactivate an alarm, press the **ALARM SET/OFF** button briefly (not held). Each press cycles through Alarm 1 ON, Alarm 2 ON, Both Alarms ON, Both Alarms OFF. An indicator light on the display will

show which alarm(s) are active.



Image Description: A bedroom scene with a couple sleeping, and the Sonic Alert alarm clock prominently displayed on a nightstand. The text overlay emphasizes the "Dual Alarm Clock" feature, allowing two different alarms to be set for reliable wake-up times.

2. Alarm Modes (Vibrate, Sound, Both)

The alarm clock offers various alert modes:

- **Vibrate Only:** The bed shaker will activate without an audible alarm.
- **Sound Only:** The audible alarm will sound without bed shaker activation.
- **Both:** Both the bed shaker and audible alarm will activate simultaneously.

To select the alarm mode, use the **ALARM MODE** switch located on the side or back of the unit. Cycle through the options until your desired mode is selected.

Shake-Up Your Mornings


never sleep past your alarm clocks



Powerful
6-volt bed shaker



102dB loud alarm with
adjustable tone & volume
control



Alarm & bed shaker
test mode



Built-in red
flashing lights



Image Description: A woman sleeping in bed with the Sonic Alert alarm clock and its bed shaker visible on the adjacent nightstand. The image highlights the clock's features: a powerful 6-volt bed shaker, 102dB loud alarm with adjustable tone and volume, alarm and bed shaker test mode, and built-in red flashing lights.

3. Snooze Function

When the alarm sounds, press the large **SNOOZE** button on top of the unit to temporarily silence the alarm. The alarm will sound again after the set snooze duration.

- The snooze duration is adjustable from 1 to 30 minutes. Refer to the full instruction manual for specific steps on adjusting the snooze time.




Image Description: A man sleeping in bed with the Sonic Alert alarm clock on his bedside table. An overlay graphic shows a slider indicating the adjustable snooze duration from 1 to 30 minutes.

4. Brightness Dimmer

Adjust the display brightness to your preference using the 5-level dimmer function.

- Locate the **DIMMER** control (often a slider or button) on the unit.
- Adjust the control to cycle through the 5 brightness levels, from brightest (5) to dimmest (1).



Five-Level Dimmer

Helps you sleep sounder



Image Description: A woman sleeping in a bedroom with the Sonic Alert alarm clock on her nightstand. Below, a series of five clock images illustrate the different brightness levels of the display, from level 5 (brightest) to level 1 (dimmest), demonstrating the five-level dimmer feature.

5. Volume and Tone Adjustment

Customize the audible alarm sound to your preference.

- Use the **VOL** (Volume) knob/slider to increase or decrease the alarm's loudness.
- Use the **TONE** knob/slider to adjust the pitch of the alarm sound.



Image Description: A close-up view of the Sonic Alert alarm clock, specifically highlighting the volume control slider on its side. The accompanying text explains how to adjust the sound with ease using the knobs for volume and tone.



MANUAL INCLUDED

The Sonic Bomb Jr. alarm clock comes with an instruction manual to guide you through the setup and features of the alarm clock




Image Description: The Sonic Alert alarm clock on a white surface, with a graphic overlay demonstrating the adjustable tone feature. Sound waves emanate from the clock, and a slider indicates the range of tone adjustments available.

6. USB Charging Port Usage

The alarm clock includes a built-in USB port for charging compatible handheld devices.

- Locate the USB charging port on the side or back of the unit.
- Connect your device's USB charging cable to the port.
- Ensure your device begins charging. Note that charging speed may vary depending on the device and cable.

Built-in USB Charging Port



Compatible with
Most Handheld Devices



Battery Backup
for Extra Security



Image Description: A woman reaching for her smartphone, which is connected and charging via the built-in USB port on the Sonic Alert alarm clock, placed on a nightstand next to her bed.

MAINTENANCE

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace backup batteries annually or when the battery low indicator appears to ensure continuous backup functionality.
- **Storage:** If storing the unit for an extended period, remove the backup batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock display is off or flickering.	Power adapter not connected or faulty; power outage.	Ensure power adapter is securely plugged in. Check wall outlet. If power outage, battery backup should maintain time (display will be off).
Alarm does not sound/vibrate.	Alarm not activated; incorrect alarm mode selected; volume too low; bed shaker not connected.	Verify alarm is ON (indicator light). Check alarm mode switch. Increase volume. Ensure bed shaker is securely plugged in.
Time/Alarm settings are lost after power outage.	Backup batteries are dead or not installed.	Install fresh AA batteries in the battery compartment.
USB charging is slow or not working.	Device incompatibility; faulty USB cable; device requires higher power output.	Try a different USB cable. Ensure your device is compatible with standard USB charging. The clock's USB port provides standard charging output.

SPECIFICATIONS

Brand	Sonic Alert
Model Number	SBJ525SS
Display Type	Digital
Special Features	Alarm, Auto Dimmable, Snooze, Vibrating Bed Shaker, USB Charging Port, Red Flashing Alert Lights
Power Source	Corded Electric with Battery Backup (2 AA batteries required, not included)
Product Dimensions	5"W x 5"H
Material	Plastic
Alarm Loudness	Up to 102dB (with bed shaker)

WARRANTY AND SUPPORT

The Sonic Alert SBJ525SS Digital Alarm Clock comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Sonic Alert website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Sonic Alert customer service:

- **Website:** www.sonicalert.com
- **Contact Information:** Refer to the official website or product packaging for the most current contact details.




Image Description: An open instruction manual for the Sonic Bomb Jr. alarm clock, showing detailed operational instructions and diagrams. This image signifies that a manual is included with the product for user guidance.

Related Documents - SBJ525SS

	Sonic Alert SBJ525SS Sonic Boom Alarm Clock & Bed Shaker User Manual Comprehensive instructions for the Sonic Alert SBJ525SS Sonic Boom Alarm Clock & Bed Shaker, covering setup, operation, features, battery backup, and troubleshooting. Includes warranty and recycling information.
	Sonic Boom Alarm Clock & Bed Shaker SBB500SS-v3 Operation Manual Detailed operation instructions for the Sonic Alert Sonic Boom Alarm Clock & Bed Shaker, Model SBB500SS-v3. Learn how to set alarms, time, use test mode, and understand features like the bed shaker and battery backup.
	Sonic Alert SB300ss Sonic Boom Alarm Clock with Bed Shaker User Manual Comprehensive user manual for the Sonic Alert SB300ss Sonic Boom Alarm Clock with Bed Shaker. Includes detailed operation instructions, features, setup guides for time, alarm, and vibrator, warranty information, and safety warnings.
	Sonic Boom Alarm Clock & Bed Shaker SBJ525SS-v3 User Manual and Instructions Comprehensive user manual and operating instructions for the Sonic Alert SBJ525SS-v3 Sonic Boom Alarm Clock & Bed Shaker, covering setup, features, operation, safety, and warranty information.

	Sonic Boom SB200ss Travel & Bedside Alarm Clock with Bed Shaker - Operation Manual User manual and operation instructions for the Sonic Alert SB200ss, a travel and bedside alarm clock featuring a bed shaker, adjustable tone and volume, and battery backup.
	Sonic Alert SBT600ss Sonic Traveler: Operation Manual & Features Comprehensive guide to the Sonic Alert SBT600ss Sonic Traveler alarm clock, featuring a bed shaker, 5-level dimmer, USB charging, and adjustable settings. Includes setup, operation, safety, and warranty information.

Documents - Sonic Alert – SBJ525SS




[\[pdf\]](#) User Manual Instructions Diagram

Sonic Alert CC the instruction manual In case function could not resume please use product in other location Attention should be drawn to environmental SA SBJ525SS harriscomm newsletter support

Sonic Boom Alarm Clock Bed Shaker Model **SBJ525SS-v3** OPERATION INSTRUCTIONS MPORTANT Please read these instructions carefully before use and retain for future reference. See operating instructions on back. Use only the supplied or recomended Sonic Alert adaptor to connect the unit. Warning: ...

lang:en score:52 filesize: 137.44 K page_count: 5 document date: 2014-07-28



[\[pdf\]](#) Instructions Diagram

ManualsLib Makes it easy to find manuals online! Search through 700 000 online and instruction user service guides owners installation Provided By MANUALSLIB COM manualslib sbj525ssv3 solidsignal

Manuals |||

Sonic Boom Alarm Clock Bed Shaker Model **SBJ525SS-v3** OPERATION INSTRUCTIONS MPORTANT Please read these instructions carefully before use and retain for future reference. See operating instructions on back. Use only the supplied or recomended Sonic Alert adaptor to connect the unit. Warning: ...


lang:en score:52 filesize: 234.13 K page_count: 5 document date: 2016-11-03



[\[pdf\]](#) User Manual

Sonic Alert CC GE User Guides Geemarc UK Model SBJ525SS Guide German geemarc de sites 5 2018 12 |||

RHK-003 for Europe Sonic Alert Sonic Boom Wecker Vibrationskissen Model **SBJ525SS** BEDIENUNGSANLEITUNG Wichtig Bitte lesen Sie diese Anleitung vor der Verwendung sorgfältig durch und bewahren Sie sie zur späteren Bezugnahme auf. Siehe Bedienungsanleitung auf der Rückseite. Verwenden Sie zum Anschließen... lang:de **score:51** filesize: 280.1 K page_count: 4 document date: 2014-03-28



[Sonic Alert SBJ525SS Sonic Boom Alarm Clock & Bed Shaker User Manual](#)

Comprehensive instructions for the Sonic Alert SBJ525SS Sonic Boom Alarm Clock & Bed Shaker, covering setup, operation, features, battery backup, and troubleshooting. Includes warranty and recycling information.


lang:en **score:49** filesize: 506.21 K page_count: 4 document date: 2020-12-08



[\[pdf\]](#) Installation Guide Instructions

Sonic Alert CC FR User Guides Geemarc UK French Model SBJ525SS ENGLISH for Europe Rev2 geemarc fr sites 3 2018 12 |||


Sonic Alert Rveil Boom Sonic et vibreur de lit Modle **SBJ525SS** MODE D'EMPLOI IMPORTANT Veuillez lire attentivement cette notice et la conserver pour toute référence ultérieure. Consultez les instructions de fonctionnement au verso du document. - Utilisez exclusivement l'adaptateur fourni pour brancher... lang:fr **score:47** filesize: 324.72 K page_count: 4 document date: 2016-10-07



[Sonic Boom Alarm Clock & Bed Shaker SBJ525SS-v3 User Manual and Instructions](#)

Comprehensive user manual and operating instructions for the Sonic Alert SBJ525SS-v3 Sonic Boom Alarm Clock & Bed Shaker, covering setup, features, operation, safety, and warranty information.

lang:en score:44 filesize: 148.35 K page_count: 5 document date: 2013-11-14




[\[pdf\] User Manual Instructions Diagram](#)

Sonic Alert 71 CC images na ssl amazon I 71bEhVtbpL Boom Alarm Clock Manual |||

Sonic Boom Alarm Clock Bed Shaker Model **SBJ525SS**-v3 OPERATION

INSTRUCTIONS MPORTANT Please read these instructions carefully before use and retain for future reference. See operating instructions on back. Use only the supplied or recomended Sonic Alert adaptor to connect the unit. Warning: ...

lang:en score:35 filesize: 177.38 K page_count: 5 document date: 2017-02-03



[\[pdf\] Instructions Guide](#)


Sonic Alert SBJ525SS User Guide Teltext Inc 3 Set alarm wake time per instructions for setting above

WARNING TO PREVENT FIRE OR SHOCK HAZARD DO NOT EXPOSE THIS APPLIANCE RAIN

Created Date 4 18 2011 11 43 50 AM teltext content userguides

...

lang:en score:32 filesize: 982.77 K page_count: 2 document date: 2011-10-04



[\[pdf\] Instructions](#)

teledynamics 99 00 mm English Sonic Alert Model SBJ525SS Bomb Alarm Clock Bed Shaker

OPERATION INSTRUCTIONS IMPORTANT Please read these instructions carefully before use and retain for SA SBJ525SSdoc1 tdresources

...


lang:en score:30 filesize: 1.13 M page_count: 2 document date: 2011-04-18



[\[pdf\] Warranty](#)

new Sonic Bomb Jr SBJ525ss TeleDynamics Our SB525ss AKA The has been designed for guys and girls of all ages on a mission budget Don t be fooled by it s name! This is no regular packed with the great stuff that made Bomb® preferred 001b602c f376 4ab0 9223 62b1ad1a472d teledynamics tdresources Sonic Bomb Jr. SBJ525ss Our SB525ss AKA The Bomb Jr., has been designed for guys and girls of all ages, on a mission and a budget. Don t be fooled by it s name This is no regular Jr., it s packed with all the great stuff that has made the Sonic Bomb the preferred weapon of students throughout the w...

lang:en score:23 filesize: 4.29 M page_count: 1 document date: 2013-08-28



[Harris Communications Catalog: Solutions for Hearing Loss](#)


Explore Harris Communications' comprehensive catalog featuring assistive listening devices, amplified phones, and communication solutions for individuals with hearing loss.

lang:en score:21 filesize: 27.61 M page_count: 73 document date: 2018-10-23

[\[pdf\] User Manual Instructions Diagram](#)

Sonic Alert CC Home ControlsSNOOZE button 8 press after alarm has sounded The will be turned off for 9 minutes extra sleep come back again minutesSONSASBJ525SS Manualhomecontrols homecontrols products s SON SonicAlert SONSASBJ525SS Manual srsItd AfmBOooLBA4r5UqMkHRPiWH6vTK6Uw0Sy6l2D0Lj7V9GkjGL5d7slv3 ControlsSonic minutes3 Set wake time per instructions setting above Alarm can shut temporarily the day or permanently 1 homecontrols AfmBOooLBA4r5UqMkHRPiWH6vTK6Uw0Sy6l2D0Lj7V9GkjGL5d7slv3homecontrols AfmBOopA1jiSBXHQjNWzs6OJ cl7 BQ83EQvPqwgYhiMTfluZ6vXePIQ 1 2 Press and hold Time Button 6 at same Minute to advance clock display rapidly until minute is correct A homecontrols BQ83EQvPqwgYhiMTfluZ6vXePIQhomecontrols AfmBOop1JNqk yNOM6FWhd4aOdu0V6AET8ZRD8m57SZ E Hb5QO8efa A Setting 1 Hour 7 rapidly homecontrols Hb5QO8efahomecontrols AfmBOooVYc4G4xJ5Gn1qo1ZJkSqin8yxgDhKr2BlqxuTENGnott6EBUr rapidly 1 When goes simply AL 10 itself on next if the homecontrols AfmBOooVYc4G4xJ5Gn1qo1ZJkSqin8yxgDhKr2BlqxuTENGnott6EBUrhomecontrols AfmBOoojv2y2tDbcf5YiMMkmnwbY2MIKLC7cSi9t6R 1SYZKd2n4lhM7 the 2 desired volume using Volume knob 12 buzzsound 3 Adjusting Alarm homecontrols 1SYZKd2n4lhM7homecontrols AfmBOooiFHQWYXac9nphax 0e jCGYcNgjOQqNzsveZHBps2 Way8qT Alarm 2 homecontrols Way8qThomecontrols AfmBOoqMDe9c8oo5PxCXrPYJ49hJ2bva3N1vE VeWV2BSU8dR2CTNeN9 SNOOZE minuteshomecontrols VeWV2BSU8dR2CTNeN9homecontrols AfmBOor6U0jFZgvXJiGPirALsy wqhxAvtip0d9W4IBVMGHi2ZJwWN1w minutesAlarm shuthomecontrols wqhxAvtip0d9W4IBVMGHi2ZJwWN1whomecontrols AfmBOoo k2odOZsAqrQbN1fSRRy nQGYHSA3Vlzt XI5NYdRmUub3fZJ shutTo adjust duration SET 5 six seconds show default as 30 release homecontrols XI5NYdRmUub3fZJhomecontrols AfmBOorDTXSEFE8OfsWd89acOORFFiWqo7tlrNwhf6ovt8FeDlkp0kly release 3 SNOOZE once change brightness brightness homecontrols AfmBOorDTXSEFE8OfsWd89acOORFFiWqo7tlrNwhf6ovt8FeDlkp0klyhomecontrols AfmBOoq9VLH9ZFd52OUcyWMwW9h9zSIXtp9WYHVHRH15VkJvBo9zmE4v7 brightness A lighted dot 4 in upper left of indicated PM For AM indication does not light up Setting alarm homecontrols AfmBOoq9VLH9ZFd52OUcyWMwW9h9zSIXtp9WYHVHRH15VkJvBo9zmE4v7homecontrols AfmBOooWWggBL9pqlSuX2 UZbYoBUyKkTXVw0Y6ridWCiLEwfA4mcxnI brightness 3 Duration 30 A AfmBOopsCbX1Lo0pAtJtLnRjRHR5SDMippwo7N FANGDXkFpowG1p vChomecontrols alarm 2 UZbYoBUyKkTXVw0Y6ridWCiLEwfA4mcxnIhomecontrols AfmBOoqKN5m1tFGJ7EcyhY6F3mFk95cteh3hoX3cOcnMuqqm9U5GhwPV 30 3

AfmBOorWUpXfKdXVgVvdC67hnOJwbaiH khxl vQuFWT7mCD00 d4jfqhomecontrols 30 1 the A
AfmBOoqdvVqWcKB LOFGPzr WhG4Bs v3lua9eskoWDYjmBH00LOpMSthomecontrols the The a Boom
Clock Bed Shaker with features like tone indicator vibrator out jack It function switch buzz A
AfmBOorZrmv1MUBx0HwjJqJgAcAYopUJcfyxMOOTlloFi1CIPqsCUHs4homecontrols 30 Hour enter hour
selection mode release when shows H 24 changed1
AfmBOopisma0cukQjwQABaEPxa5s7GTg3vgTr3dilCz9B5dEoT LyrSFhomecontrols Alarm Warning To
prevent fire shock hazard do expose this appliance rain moisture Before connecting mains power make
sure that thehomecontrols
AfmBOoqKN5m1tFGJ7EcyhY6F3mFk95cteh3hoX3cOcnMuqqm9U5GhwPvVhomecontrols
AfmBOorJppbq2MghK5QQSTmny1bcgRSoaoLF5a1Zat2NqzQBoYuK fhx the1 You may homecontrols
fhxhomecontrols AfmBOooP9AFFOcrGiK ystEC2fDOGKwzxYnAyMDGuwkr3xO2lmhcLR may Alarm
ystEC2fDOGKwzxYnAyMDGuwkr3xO2lmhcLRhomecontrols
AfmBOooTVS2M13uxLuvSirXg6DsAztOGGLwJcDZB96BH4HZEEnR56jmle may 3 Place under mattress
pillow USB Charging This equipped convenient charging port panel allows you to Alarm
AfmBOooCSymHCffhniqBon3yGe4As EJlvatdhYVSL6llGYHU6 kWYhomecontrols shutSNOOZE
AfmBOooTVS2M13uxLuvSirXg6DsAztOGGLwJcDZB96BH4HZEEnR56jmlehomecontrols
AfmBOopheRncuanUAbfwOohiqTeBe74lzNXJ1wgRM hnWApVn1VyLbDt minutes1 Attach bed shaker
VIBRATOR input 13 2 select slide Function Switch 11 VIB BUZZ positionhomecontrols
hnWApVn1VyLbDthomecontrols
AfmBOoqaTPmjkec5fKyrX1GJeGYOLvWtFRKipHDBkv5J6jkPJkFB1WHR positionSNOOZE
AfmBOoqaTPmjkec5fKyrX1GJeGYOLvWtFRKipHDBkv5J6jkPJkFB1WHRhomecontrols
AfmBOorP41mzTbnoJcC1vhFxEdcO BPDDz Aok8 3O6AD26bjhXcFO1 minutesSNOOZE
3O6AD26bjhXcFO1homecontrols AfmBOoomeWY92u5VFqdlOBsqPnapwFhq0gl ihAo dkSZJqBvJOpNrlL
dkSZJqBvJOpNrlLhomecontrols AfmBOopFult7BJGskyjKBOJHr uobbajNYbf9wMpF88ENJ9MyBjCYiS9
uobbajNYbf9wMpF88ENJ9MyBjCYiS9homecontrols AfmBOooDfEqyppSx19rJ3
7xZPRTT5ghAxLpCVpFgjPrPc8KV5mHnnWT
7xZPRTT5ghAxLpCVpFgjPrPc8KV5mHnnWThomecontrols
AfmBOopB0IWowV1KEwmu3MtVhksZ2LMNIsJY7PeBZ CtEMCNfrhJK w
AfmBOoo03pmrL6DfE3WtIFWnVvX9ShH5QCROZPoS7NOM23nrs4WM4Eikhomecontrols
whomecontrols AfmBOorKzJLishx3t6nsfNjNoVvctPZcSmy6FglqF2Cq4JjAxTodfSwx
AfmBOorKzJLishx3t6nsfNjNoVvctPZcSmy6FglqF2Cq4JjAxTodfSwxhomecontrols
AfmBOorugwrj9e4UQVhbVKa o5sNXQAQNN1Aamj9ansk7cLBqTWNvK
o5sNXQAQNN1Aamj9ansk7cLBqTWNvKhomecontrols AfmBOopnBMsiJChe7tasacw
95O3dcgoWC0Ca9loIfgq So3jlJhsrZz
AfmBOooQOqmPwMGuDcnwzDKXnXkdNWMxFePpHCpBNC5vssJ8xkP7F74Zhomecontrols
AfmBOoqHB1zCxYpTlp1 1zYiShMYl3CBct433trP1t44L3vjQV xwObUhomecontrols
So3jlJhsrZzhomecontrols AfmBOoozevMNSUrmu1m6thfOFFk5ZAalauOfjrH 7fJW8BuFjWbjCr4v
7fJW8BuFjWbjCr4vhomecontrols AfmBOopVk L3dt9EmkOKvXiNrv9bG6grWkzCkz LNPJqNa3hhTllc9
LNPJqNa3hhTllc9homecontrols AfmBOoox560vpvrnLZa wVz2pYK9yby6JNxtl6i69Dtwkv7FpYfgOG6
AfmBOoq2DM0DecWQjvAnAHqb23OqLYCOewHLWQ oLwn3KTmlpTrx1uRhomecontrols
AfmBOoqR5C92 nE2Pk 4q 4DPalAQs9XZmpiruYmOgoXtOF3tZRh3cBbhomecontrols
AfmBOoqUjtXaN6kW1vcLfj4H YC0tdh2il prjVWGK5UPbgd0aNdvU7homecontrols
AfmBOooCyisrTQBYTfUMVFg zb1ICHsX8caTOVhAU7MZU5d796lNtp7homecontrols ShakerSonic
AfmBOorUh1NQAvFdtxqij77rSj 647zj4VGIhxodPmkogV8A9uvqd7dnhomecontrols
AfmBOopmL5MiLiTl5l9JzVuOd4qNKNqDSUaSNytR9EzQ42Xl6oVVbtfRhomecontrols
wVz2pYK9yby6JNxtl6i69Dtwkv7FpYfgOG6homecontrols AfmBOor3pnx3V76DIYSX I
DQIMzxZidFnqhDaweBBUjqr5KAPve4yJb DQIMzxZidFnqhDaweBBUjqr5KAPve4yJbhomecontrols
AfmBOoqocc4hVfUe Hr7C50GJuXasf PFxYxadOovB8hc3DD laXCd71 laXCd71homecontrols
AfmBOoqzyiSjvQ 5pQm PKRcO7pQ4hhzfx6g9aZJVn smT5leE0UA7o minutes2
AfmBOoqvhrjNLpyj9mIU4pCO8sgfYQK7TOXBDVPdqAc9tVabRIIATfhomecontrols
smT5leE0UA7ohomecontrols AfmBOopT1Rhlg1ugFamNikYx08v3WjQRf3Ny9tBCYbJGrmOSKSoguWYP
AfmBOopT1Rhlg1ugFamNikYx08v3WjQRf3Ny9tBCYbJGrmOSKSoguWYPhomecontrols




AfmBOophxSjTnz4Pw2D8VXjRxkdZ6icm6GHNPkMTP8WHAX tRR9IxAgo AfmBOopa7cCmKF57T
qGjIGG8SWcdB3T00U9IqC39Ujm6d57VDtE8hfuhomecontrols A To AfmBOop8IGQ5tWIE12
NhfRZnfgcLbt m9kGBPExdw7vbwTWpLJONW0Ohomecontrols
AfmBOorXryPj132ISlbuV6sNeaoTz0TnZYkcuVe 4xVFeGU8aCtYsBAihomecontrols
AfmBOorhJCGe8oj0QQR5nnmQB0erWwCe5v4M26nCQXxkywo2di2n8CJchomecontrols release Alarm
AfmBOoojtlUiCWtXjfYwepIVzP17IcUSPvKIN5o38ZoyM1XcdsOWd2pKhomecontrols
AfmBOoqZfFkiPMSwFA0HdUKJzAU9rbVTRP8HeJcvW70b1XFBR21FU1yQhomecontrols
prjVWVG5UPbgd0aNdvU7
AfmBOooHyQ3BVmnewbpQ8fWe0xL5bLUH2hFzwfQ0NCZycvalpsPeDWShomecontrols
oLwn3KTmlpTrx1uR AfmBOop9wq3JlZwdXtkHIBN4xZnCZez djllFr uP3qU OTsIdee95wlhomecontrols
zb1ICHsX8caTOVhAU7MZU5d796lNtp7 shutThe may between 59
AfmBOoc9G91suwMmmJLt9zqegweVDdkloqy36kxi2ECx71WiDT9cQDDhomecontrols shutAlarm
AfmBOopdx8DhdeLjoTGWiLEbenpOR5zy385zMsG2p A0nirMBulxWyShomecontrols
4DPaIAQs9XZmpiruYmOgoXtOF3tZRh3cBb AfmBOopsywS U
F93F8ak9AVxuDrovGmlxOCFYC7wY8yjZjv0dq40jSnbhomecontrols permanently positon set
orhomecontrols AfmBOopuOqzr hcsIH0eyBaWZysrEeqzleI9C daRv N39xPRBb1zh0Uhomecontrols
AfmBOoodElbfLHr84Yr7S0ACWGiwrXO5huEbl4H5raKGI4KW 84TZw8Whomecontrols xw0bU
AfmBOoo53vAy7hqdzXHn3DtCjQxz9cwJ pylr3UY6LH40m67RbrAdmVihomecontrols
AfmBOooQOqmPwMGuDcnwzDKXnXkdNWMxFePpHCpBNC5vssJ8xkP7F74Z
AfmBOooOXv4fCrogWfUfBh 3ly4E6vuinfhVqea4C MPu7MYwg1LQLbbHhomecontrols
AfmBOoogxbSYkjBNZGfRCQhLMs RMnGCBUI8Eyg3jTh6l9NgZvUkmcKLhomecontrols
AfmBOoo7xAzZvWCLf1J266Pr9KfdbqWnPeyj J4QOTnFKQFquWytKWMhomecontrols
AfmBOopuFaMPt0ZYHD3Zrd mD01dQLAkqPxJE3veYYyBahDg6CSkKgZdhomecontrols
AfmBOoo03pml6DfE3WtIFWnVvX9ShH5QCROZPoS7NOM23nrs4WM4Eik
AfmBOopmtyw0T9xUDL7PtweM4hoeohXdsfU4n2OIX8z6ujQab3rx606rhomecontrols
AfmBOorxGjHqifMuozKiH1nSFaVdeSxuT V4jsncLAUlav3MZBf915Nmhomecontrols or1 2 homecontrols
AfmBOooxSMLlIKih0F3cq6QAG hpDSDvUVjnEz 6mQXycAU3ktoheE3V
AfmBOoq0MMknZ41oUbM8Vv4XXUnAcQ7ZhANcjqvclxe4 00 JOPKVXhomecontrols N39xPRBb1zh0U
AfmBOoo7jFBFPq9WaW8DBImstzHXBs2ib2eXlPdAU3 G8kZXJUHUZfLhomecontrols
AfmBOoc9G91suwMmmJLt9zqegweVDdkloqy36kxi2ECx71WiDT9cQDD AfmBOoq
xu3eUDPK3zRA88zge8kKu3SwGBv19gSr4LhIDovAf9yussjKhomecontrols A0nirMBulxWyS
AfmBOoqbCmtuhG2Ll1gS93RAzyxJbGy eOwsUmvNb9vpRCjBIC4j7PBhrhomecontrols
AfmBOoojtlUiCWtXjfYwepIVzP17IcUSPvKIN5o38ZoyM1XcdsOWd2pK
AfmBOop6e4BP4afEb0CdReX7XkhF oPbJtUOj yOu2fSgdJEnRmvsRAOhomecontrols
m9kGBPExdw7vbwTWpLJONW0O AfmBOorO3Zwtj3B9u4eoDuesVuiJ5R V3AUcX8 bWYldi
7l9E7l6jArhomecontrols AfmBOoqvhrhjNLpyj9mIU4pCO8sgfYQK7TOXBDVPdqAc9tVabRIlATf
AfmBOopkJNVJOmb74dwibSXlFYya4O5Vu9UddIUz FNza3svOAUILCehomecontrols AfmBOoqe hn
zJnWw30eegpEOWi PbY2V021bN Jbu3aO7HLSeVP147Whomecontrols
AfmBOoqHblvWohd3LcU10EC2p d dFN6OA5uNsmhfTE38Chk81k2Fb5Ghomecontrols
AfmBOordX1VLq2pzoxGCEY 15o7 usYXvetTWds2HwiRRUT Y03vHmDfhomecontrols
AfmBOoqsfC4VLzJBSKpWw2P9VW8X38nzj0GuIMHQ2ag1W4iZIW VKYxJhomecontrols to homecontrols
AfmBOoqwWo48ZK6WYXZDosemt72Vw4m5 t6kRKHK zSMRpxhgLiu fhhomecontrols kWY
AfmBOop6ajsJ6Gq ibjJHotO3v9bk3sBHaP6m2fYWdOzVAQDXndm9wFihomecontrols
AfmBOoruZ4CJfR4XV9lxfzMoqDMWgyopNj9wIZKYtze Zc0qkyp5YLXvhomecontrols
AfmBOoqmbKWYc9T1g1biYF D6piDuzTw0hpzh IX61ol3u1yF7odEpu9homecontrols
AfmBOorgmbVDx7D40D365pfjP yerc9VAA8X82ekP1VLdOpZm2wrVoqOhomecontrols
buzz homecontrols AfmBOooWq Ed88DH6B6e5eOfpKmfA6nzy7Y5C9OJJEXckvQl6x0Nghomecontrols
AfmBOorZrmv1MUBx0HwjJqJgACAYopUJcfyxMOOTlloFi1CIPqsCUHs4
AfmBOorsGpCRAM0GCHv1Hy4CUqJy E7ihuJXPeTeqvHEhgvEdFZAACPDhomecontrols
v3lua9eskoWDYjmBH00LOpMSt changedhomecontrols AfmBOoo0M2S8lJBxbZFFcUi
Uw4y56U2haPLV9X21r2YRXwy5mZNC1bShomecontrols LyrSF 30 homecontrols
AfmBOoryfkDalzW82uqqL 4GWD3f1V2dJn BVXuTwFgyQjgVJltyEPpMhomecontrols d4jfq AfmBOopZ

QEZocg8RWUTFuHpNirJ9kcq4Xp8BkRRM7fLoa6woP0TARNhomecontrols vC AfmBOorrhnyBE6J
e1eIPAAmn7bx9H49yIG98mXoHEdHR8OYKSCx6HKqhomecontrols
AfmBOoq3Y9oe2ARPIWWmffISjwx0VijVILXHFEOWI fnUIHzw7KC0xfdhomecontrols
AfmBOorkJw8RnfN8yY7d7MXky FKlZQ0T83UfTetDiYRR3S8GNvSvLrfhomecontrols AfmBOooXt3s1A71
6Wc94TpL5XnFnf4llwM46NRLSqqQZ u goyxireuhomecontrols
AfmBOooj7kEJyjaxGykfi4u3W4UbmSFxOPGYoC4iGu3yZNN6OuCGJJ4homecontrols AfmBOoo7ps
IVlcLDXdnD f4heblMaXD1X4cnen eLtMRHevDD6pOn8xhomecontrols
AfmBOopDqzduKs1DdQlyM8uwqcVx0anuD0VTx0W48yaO4TSUYvBBw4Fhomecontrols
AfmBOoq2NiNa6VFN6tEXQG1R87S 4OGCaKCsAfZor62mbyILGuBLpGauhomecontrols
AfmBOopHwsELInWr6xubX5iKayCOoFCBRsLGOObIZ49G0Up4aCqb9qEDhomecontrols
AfmBOopCRdSL2skbvp8k8JHcoJkz4xgVdQWB4 nUTTogsyuLeK2HE5 hhomecontrols AfmBOoqNw
IGUoAlvC4ULqkp1EV0dDBa52rFXHtTwPvqTyHY JjR0PCshomecontrols Shakerhomecontrols
AfmBOopp6dBYDCeQuinfNhrOXoqygBI1 feP9W1HEUDiDUHisRIQOK1i AfmBOoqaqU9iM5X
J6xX6lwSeNEUvzXgAdwJI5dROPNICM NvxGTIMlqhomecontrols FKlZQ0T83UfTetDiYRR3S8GNvSvLrf
AfmBOoqu1WKNxwL3 lzp54YB1t6AqtyMwFdLu5WT wRQVllIEOjheUD7homecontrols NvxGTIMlq
AfmBOorpiNlaHNL4NO0 BLJclgJ59tF2LoyXqh6MYhDGK OyVDm8rAVhomecontrols
QEZocg8RWUTFuHpNirJ9kcq4Xp8BkRRM7fLoa6woP0TARN |||

Sonic Boom Alarm Clock Bed Shaker Model **SBJ525SS**-v3 OPERATION

INSTRUCTIONS MPORTANT Please read these instructions carefully before use and retain for future reference. See operating instructions on back. Use only the supplied or recomended Sonic Alert adaptor to connect the unit. Warning: ...

lang:en score:20 filesize: 148.35 K page_count: 5 document date: 2013-11-14



[pdf] Catalog

Assistive Listening Devices from HARC Mercantile Ltd 20230113 Catalog 2020 w cover

10656852413501695133 cdn shopify s files 1 2998 7196 |||

Volume 20 HARC Mercantile, Ltd. Solutions for daily living for the Hard of Hearing and Deaf... Cal ... - 25 smaller than its big brother but still has 102 dB alarm and bedshaker. One year warranty. SA-**SBJ525SS** 39.00 Bunker Bomb with Super ShakerTM - The Bunker Bomb is the perfect wake up for outdoo...

lang:en score:9 filesize: 14.23 M page_count: 36 document date: 2023-01-13