

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nautica](#) /

› [Nautica Men's N17546G NST 06 Multifunction Watch Instruction Manual](#)

Nautica N17546G

Nautica Men's N17546G NST 06 Multifunction Watch Instruction Manual

Model: N17546G

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Nautica Men's N17546G NST 06 Multifunction Blue Dial Steel Bracelet Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.





Image 1: Front view of the Nautica N17546G NST 06 Multifunction Watch, showcasing its blue dial, stainless steel bracelet, and multifunction sub-dials.

SETUP

1. Initial Time Setting

- 1. Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the outermost position.
- 2. Set the time:** Rotate the crown to move the hour and minute hands clockwise until the correct time is displayed.
- 3. Push in the crown:** Once the time is set, push the crown back into its normal operating position.

2. Setting Multifunction Dials (Day, Date, 24-Hour)

Your N17546G watch features multifunction sub-dials for day, date, and 24-hour time. Specific setting instructions may vary slightly by movement, but generally involve:

- Date Setting:** Pull the crown to the first click position (if applicable) and rotate it in one direction to adjust the date.
- Day Setting:** Pull the crown to the first click position (if applicable) and rotate it in the opposite direction to adjust the day.
- 24-Hour Sub-dial:** This sub-dial typically synchronizes with the main hour hand and does not require separate adjustment. It indicates whether the main time is AM or PM.

Note: Avoid setting the date or day between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism. If you need to adjust during this period, first set the time outside this window, adjust the date/day, then reset the time.

OPERATING YOUR WATCH

Timekeeping

The Nautica N17546G is powered by a reliable quartz movement, ensuring accurate timekeeping. The main hands display hours, minutes, and seconds. The sub-dials provide additional information:

- **Day Sub-dial:** Indicates the current day of the week.
- **Date Sub-dial:** Displays the current day of the month.
- **24-Hour Sub-dial:** Shows the current time in a 24-hour format, useful for distinguishing AM/PM.



Image 2: The Nautica N17546G watch displayed on a wrist, illustrating its size and fit.

MAINTENANCE

Water Resistance

Your Nautica N17546G watch is water resistant to 100 meters (330 feet). This makes it suitable for snorkeling and swimming. However, it is **not suitable for diving**.

- Ensure the crown is fully pushed in before any contact with water.
- Do not operate the crown or pushers while the watch is wet or submerged.
- Avoid exposing the watch to hot water, steam, or sudden temperature changes, as this can compromise the water seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly with a soft cloth.

Cleaning and Care

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dirt and perspiration.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.
- The mineral crystal is durable but not scratch-proof. Avoid contact with sharp or abrasive objects.

Battery Replacement

The watch is powered by a CR2 battery. When the battery runs low, the watch may stop or the second hand may skip. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch has stopped or is running intermittently.	Low or depleted battery.	Replace the battery (recommended by a professional).
Date/Day does not change at midnight.	Time is set incorrectly (e.g., AM/PM confusion) or date/day was set during restricted hours.	Adjust the time past 12 PM to ensure correct AM/PM. Reset date/day outside 9 PM - 3 AM window.
Condensation appears under the crystal.	Temperature change or compromised water resistance.	Seek professional inspection immediately to prevent internal damage.

SPECIFICATIONS

- **Model Number:** N17546G
- **Movement:** Quartz
- **Case Material:** Stainless Steel
- **Case Diameter:** 46 mm
- **Dial Color:** Blue
- **Bracelet Material:** Stainless Steel
- **Water Resistance:** 100 meters (330 feet)
- **Crystal:** Mineral
- **Functions:** Hour, Minute, Second, Day, Date, 24-Hour Time Zone
- **Battery Type:** 1 CR2 battery (required)
- **Item Weight:** 0.28 g (approx.)



Image 3: The Nautica N17546G watch presented in its official Nautica branded box, indicating the product packaging.




WARRANTY AND SUPPORT


For warranty information and support, please refer to the documentation included with your purchase or contact the seller of record. Nautica watches typically come with a manufacturer's warranty covering defects in materials and workmanship. For further assistance or to locate an authorized service center, please visit the official Nautica website or contact their customer service department.

[Visit the Nautica Store on Amazon](#) for more information on Nautica products.



Related Documents - N17546G

	<p>Nautica T300 True Wireless Stereo Earbuds User Guide Features, Specs, and Support</p> <p>Comprehensive user guide for the Nautica T300 True Wireless Stereo Earbuds with Charging Case. Learn about features, setup, safety, warranty, and technical specifications.</p>
	<p>Nautica T220 True Wireless Stereo Earbuds with Charging Case - User Manual</p> <p>Get detailed instructions for your Nautica T220 True Wireless Stereo Earbuds. This guide covers setup, pairing, charging, technical specs, safety, and warranty. Visit technofashion.com for support.</p>
	<p>Nautica Audio Eyewear Powered by Lucyd® User Manual and Features</p> <p>Explore the features, setup, and usage of Nautica Audio Eyewear, smart glasses powered by Lucyd®. Learn about music control, calls, voice commands, and compatible apps.</p>
	<p>Nautica T120 True Wireless Stereo Earbuds User Manual & Specifications</p> <p>Comprehensive user guide and technical specifications for Nautica T120 True Wireless Stereo Earbuds with Charging Case. Learn how to use, pair, charge, and maintain your earbuds. Includes safety information and warranty details.</p>
	<p>Инструкция по эксплуатации часов Nautica: Полное руководство пользователя</p> <p>Подробное руководство пользователя для часов Nautica. Узнайте о функциях, настройке и уходе за вашими часами Nautica, включая водостойкость, подсветку INDIGLO и различные модели.</p>



[Nautica H110 Bluetooth Stereo Sport Earphones User Manual and Specifications](#)

Official user manual and technical specifications for the Nautica H110 Bluetooth Stereo Sport Earphones, covering setup, usage, safety, warranty, and troubleshooting.