



[Manuals.plus](#) /

› [Haul Master](#) /

› Haul Master Mover's Dolly 93888 Instruction Manual

Haul Master 93888

Haul Master Mover's Dolly 93888 Instruction Manual

Model: 93888 | Brand: Haul Master

INTRODUCTION

Thank you for choosing the Haul Master Mover's Dolly, Model 93888. This instruction manual provides essential information for the safe and effective use, setup, operation, and maintenance of your dolly. Please read this manual thoroughly before using the product and retain it for future reference. This dolly is designed to assist in moving heavy or bulky items with a weight capacity of up to 1000 lbs.

PRODUCT FEATURES

- **1000 lb. Weight Capacity:** Designed to handle heavy loads with ease.
- **Hardwood Frame:** Provides durability and strength for reliable performance.
- **Carpeted Surfaces:** Protects items from scratches and helps prevent shifting during transport.
- **3" Hard-Rubber Swivel Casters:** Ensures smooth movement and 360-degree maneuverability on various surfaces.
- **Height from Ground:** Approximately 5-1/2 inches, offering good clearance.
- **Dimensions:** 18" L x 12-1/4" W x 5" H (approximate).

SAFETY INFORMATION

Always prioritize safety when using the Mover's Dolly. Failure to follow these instructions may result in injury or damage to property.

- **Weight Limit:** Do not exceed the maximum weight capacity of 1000 lbs. Overloading can cause structural failure and injury.
- **Load Distribution:** Distribute the load evenly across the dolly's surface to maintain stability.
- **Secure Load:** Always secure items on the dolly to prevent them from falling during transport. Use straps or ropes if necessary.

- **Surface Conditions:** Use the dolly on flat, stable, and clear surfaces. Avoid uneven terrain, stairs, or inclines.
- **Personal Protective Equipment:** Wear appropriate safety gear, such as gloves and closed-toe shoes, when handling heavy items.
- **Clear Path:** Ensure your path is clear of obstacles, children, and pets before moving the dolly.
- **Proper Lifting Techniques:** Use proper lifting techniques when placing items onto or removing them from the dolly to prevent back injuries.

SETUP

The Haul Master Mover's Dolly Model 93888 comes pre-assembled and ready for immediate use. No assembly is required.

1. **Unpacking:** Carefully remove the dolly from its packaging.
2. **Inspection:** Before first use, inspect the dolly for any signs of damage, loose casters, or worn carpeted surfaces. Do not use if damaged.
3. **Placement:** Place the dolly on a flat, stable surface where you intend to load items.



Image 1: The Haul Master Mover's Dolly in a home setting, ready for use. This image shows the dolly's compact size and design.

OPERATING INSTRUCTIONS

1. **Prepare the Load:** Ensure the item you intend to move is properly packed and secured. Remove any loose parts or items that could fall.
2. **Position the Dolly:** Carefully slide the dolly underneath the item you wish to move. Ensure the item's weight is centered on the dolly's carpeted surfaces for maximum stability.
3. **Lift and Place:** If the item is too heavy to lift directly, use a lever or another person to slightly raise one side of the item, then slide the dolly underneath. Repeat for the other side if using multiple dollies.
4. **Move the Item:** Gently push or pull the item to its desired location. The 360-degree swivel casters allow for easy navigation around corners and obstacles.
5. **Unload:** Once at the destination, carefully remove the item from the dolly. If necessary, use the

reverse of the loading procedure.



Image 2: Detailed view of the Haul Master Mover's Dolly with key dimensions highlighted, showing its compact and functional design.

MAINTENANCE

Regular maintenance will ensure the longevity and safe operation of your Haul Master Mover's Dolly.

- **Cleaning:** Wipe down the hardwood frame with a damp cloth as needed. Clean the carpeted surfaces with a brush or vacuum to remove debris.
- **Caster Inspection:** Periodically check the casters for wear, damage, or debris accumulation. Remove any hair, string, or other obstructions from the wheel axles.
- **Lubrication:** Apply a small amount of lubricant to the swivel mechanisms of the casters if they become stiff or squeaky.
- **Storage:** Store the dolly in a dry place, away from extreme temperatures and direct sunlight, to prevent wood warping or damage to the casters.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dolly is difficult to move or steer.	Casters are dirty or obstructed. Casters need lubrication. Load is unevenly distributed.	Clean casters and remove debris. Apply lubricant to swivel mechanisms. Re-distribute the load evenly.
Item slides off the dolly.	Load is not properly centered. Item is not secured. Dolly is on an uneven surface.	Ensure load is centered on carpeted surfaces. Use straps to secure the item. Move the dolly to a flat, stable surface.
Dolly makes excessive noise.	Casters are dry or worn.	Lubricate casters. Inspect for wear and consider replacement if severely worn.

SPECIFICATIONS

Model: 93888

Brand: Haul Master

Material: Hardwood frame, hard-rubber casters, carpeted surfaces

Color: Grey/Hardwood

Weight Capacity: 1000 lbs.

Item Weight: 5.3 lbs.

Overall Dimensions (L x W x H): 18" x 12-1/4" x 5-1/2" (approximate)

Caster Wheel Diameter: 3 inches

Number of Wheels: 4 (swivel casters)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Haul Master website or contact their customer service department. Keep your purchase receipt as proof of purchase.