

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HARBOR BREEZE](#) /
- › [Harbor Breeze Southlake 36-inch White Ceiling Fan Instruction Manual](#)

HARBOR BREEZE Southlake LP8077LWH

Harbor Breeze Southlake 36-inch White Ceiling Fan Instruction Manual

Model: LP8077LWH

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Harbor Breeze Southlake 36-inch White Ceiling Fan. Please read all instructions carefully before beginning installation to ensure proper function and safety.

Key Features

- White finish for a classic aesthetic.
- Includes blades in a weatherproof natural accent finish.
- Integrated white frosted light kit for illumination.
- 3-speed reversible motor for year-round comfort.
- Comes with a 4.5-inch downrod for standard installation.



Image: The Harbor Breeze Southlake 36-inch White Ceiling Fan, featuring three white blades and a central frosted light fixture.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing the fan.
- Ensure all electrical connections comply with local codes, ordinances, and the National Electrical Code (NEC).
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Before installation, disconnect power by turning off the circuit breakers to the fan's junction box.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting a minimum of 35 lbs (15.9 kg).
- Do not bend the blade brackets during installation or cleaning.
- Keep hands, tools, and other objects clear of the fan blades when the fan is operating.
- Do not operate the fan if any part is damaged.
- This fan is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning installation:

- Motor Housing Assembly
- Fan Blades (3)
- Blade Brackets (3)
- Downrod and Hanger Ball Assembly
- Mounting Bracket
- Canopy
- Light Kit Assembly with Frosted Glass Shade
- Hardware Pack (screws, washers, wire nuts)

INSTALLATION GUIDE

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

Step 1: Mounting the Fan

1. Secure the mounting bracket to the ceiling outlet box using the screws provided. Ensure the outlet box is securely fastened to the building structure.
2. Feed the electrical wires from the outlet box through the center hole of the mounting bracket.



Image: Illustration of a mounting bracket being secured to a ceiling electrical box.

Step 2: Assembling the Downrod and Motor

1. Insert the downrod through the canopy and then through the motor housing.
2. Align the holes in the downrod with the holes in the motor collar and insert the cross pin. Secure with the cotter pin.
3. Tighten the set screws on the motor collar to secure the downrod.

Step 3: Wiring the Fan

1. Carefully lift the fan assembly and hang the hanger ball into the mounting bracket.
2. Connect the fan's electrical wires to the household wires according to the wiring diagram provided in the full manual (typically: black to black, white to white, green/bare to ground). Use the provided wire nuts.
3. Ensure all connections are secure and tucked neatly into the outlet box.

Step 4: Attaching Blades and Light Kit

1. Attach each fan blade to its blade bracket using the screws provided.
2. Secure each blade assembly to the motor housing.
3. Connect the light kit wires to the corresponding wires from the fan motor.
4. Attach the light kit assembly to the bottom of the motor housing.

5. Install the frosted glass shade by twisting it into place or securing it with the provided screws.

OPERATING YOUR CEILING FAN

Your Harbor Breeze Southlake ceiling fan is controlled by a pull chain for fan speed and another for the light.

Fan Speed Control

The fan features a 3-speed reversible motor. Pull the fan speed chain to cycle through the following settings:

- **1st Pull:** High Speed
- **2nd Pull:** Medium Speed
- **3rd Pull:** Low Speed
- **4th Pull:** Off

To reverse the direction of the fan blades (for summer or winter operation), locate the slide switch on the motor housing. Ensure the fan is off before changing the direction.

Light Control

The integrated light kit is controlled by a separate pull chain. Each pull will toggle the light On or Off.

CARE AND MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Tightening Screws:** Check all screws, especially those on the blade attachments, at least twice a year. Tighten any loose screws to prevent wobbling and noise.
- **Light Bulb Replacement:** If the light kit uses replaceable bulbs (this model has a built-in light source, so replacement is not typically user-serviceable for the LED/fluorescent component itself, but the frosted shade can be removed for access if needed for cleaning or professional service).
- **No Lubrication Needed:** The motor is permanently lubricated and does not require oiling.

TROUBLESHOOTING GUIDE

Before attempting any repairs, ensure the power supply to the fan is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Blown fuse or tripped circuit breaker.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace fuse or reset breaker.
Fan wobbles	Loose blade screws; Improperly balanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is securely fastened.
Fan is noisy	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws; Ensure no parts are rubbing; Verify blades are not hitting anything.
Light does not work	Loose wire connection in light kit; Faulty light kit component.	Check light kit wiring connections; Contact customer support if the built-in light source is faulty.

TECHNICAL SPECIFICATIONS

Brand	HARBOR BREEZE
Model Name	Southlake
Item Model Number	LP8077LWH
UPC	840506058064
Color	White
Material	Metal
Assembled Diameter	36 Inches
Item Weight	22.4 pounds
Room Type	Indoor (Living Room, Bedroom, Office)
Power Source	Corded Electric
Voltage	120 Volts
Control Method	Pull Chain (Fan Speed, Light)
Light Source Type	Built-in (LED or Fluorescent)
Included Components	Light Kit, 4.5 in. Downrod
Assembly Required	No (refers to the main unit, but user assembly is required for installation)

WARRANTY AND CUSTOMER SUPPORT

Harbor Breeze products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Harbor Breeze website. If you encounter any issues or have questions regarding your Southlake ceiling fan, please contact Harbor Breeze customer support for assistance.

Note: Warranty information was not explicitly provided in the product data. Please consult the manufacturer's official documentation for the most accurate and up-to-date warranty terms.