

[Manuals.plus](#) /

› [Eurofase](#) /

› Eurofase Sliver Small Pendant Light Instruction Manual (Model 20444-020)

Eurofase 20444-020

Eurofase Sliver Small Pendant Light Instruction Manual

Model: 20444-020 | Brand: Eurofase

1. INTRODUCTION

Thank you for choosing the Eurofase Sliver Small Pendant Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1.1: The Eurofase Sliver Small Pendant Light, featuring a satin nickel finish and a sleek, conical design.

2. SAFETY INFORMATION

For your safety, always follow these precautions during installation and operation:

- Always turn off the power supply at the main circuit breaker before installing, cleaning, or servicing the fixture.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections are made in accordance with local codes and ordinances.
- Do not exceed the maximum wattage specified for the bulb.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture.

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

3. PACKAGE CONTENTS

Carefully unpack your fixture and identify the following components. Ensure all parts are present and undamaged before proceeding with installation.

- Pendant Light Fixture (1)
- Mounting Hardware Kit (1)
- Instruction Manual (1)

Note: GU10 light bulb is required and sold separately.

4. SETUP AND INSTALLATION

Professional installation is recommended. If you are not familiar with electrical wiring, consult a qualified electrician.

1. **Turn Off Power:** Before starting, ensure the power to the installation area is turned off at the circuit breaker.
2. **Prepare Mounting:** Attach the mounting bracket to the junction box in the ceiling using the provided screws.
3. **Electrical Connections:** Connect the fixture's wires to the household wires according to standard electrical codes (black to black, white to white, ground to ground). Secure connections with wire nuts.
4. **Mount Canopy:** Carefully push the fixture's canopy up to the ceiling, covering the junction box and mounting bracket. Secure it with the provided screws or nuts.
5. **Adjust Height:** The pendant features an adjustable height. Loosen the set screw on the canopy to adjust the cable length as desired, then tighten to secure.
6. **Install Bulb:** Insert one GU10 halogen bulb (max 50W) into the socket at the bottom of the pendant. Ensure it is seated correctly.
7. **Restore Power:** Once installation is complete, restore power at the circuit breaker.



Image 4.1: Dimensional diagram of the pendant light, showing a 12-inch fixture length and a total adjustable cable length of up to 72 inches.

5. OPERATING INSTRUCTIONS

The Eurofase Sliver Small Pendant Light operates like a standard light fixture connected to a wall switch. If connected to a compatible dimmer switch, the light output can be adjusted.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming:** If installed with a compatible dimmer switch, rotate or slide the dimmer control to adjust the brightness level. Ensure the GU10 bulb used is dimmable.



Image 5.1: Example installation of multiple Eurofase Sliver pendant lights illuminating a dining table.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your pendant light.

- **Cleaning:** Turn off power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Ensure power is off and the bulb has cooled before attempting to replace it. Gently twist and pull out the old GU10 bulb. Insert a new GU10 halogen bulb (max 50W) by aligning the pins and pushing it into the socket, then twisting to secure.

7. TROUBLESHOOTING

If you encounter issues with your pendant light, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture; Loose wiring; Faulty bulb	Check circuit breaker; Verify wire connections; Replace bulb.
Light flickers	Loose bulb connection; Incompatible dimmer switch; Faulty bulb	Ensure bulb is securely seated; Verify dimmer compatibility; Replace bulb.
Fixture is hot to the touch	Incorrect bulb wattage	Ensure bulb wattage does not exceed 50W.

8. SPECIFICATIONS

Feature	Detail
Brand	Eurofase
Model Name	SLIVER
Model Number	20444-020
Color	Satin Nickel
Material	Metal, Glass
Product Dimensions	2.75"L x 2.75"W x 12"H (Fixture)
Max Cable Length	72 inches
Light Source Type	Halogen
Bulb Base	GU10
Max Wattage	50 watts
Voltage	120 Volts
Special Features	Adjustable Height, Dimmable
Installation Type	Semi Flush Mount
Item Weight	1.99 Pounds
Certification	ETL

9. WARRANTY AND SUPPORT

This Eurofase product is covered by a manufacturer's limited warranty. For specific warranty terms, conditions, and duration, please refer to the documentation included with your purchase or contact Eurofase customer support directly.

For technical assistance, replacement parts, or any questions regarding your Eurofase Sliver Small Pendant Light, please visit the official Eurofase website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question