

## Eurofase 20444-037

# Eurofase Sliver Small 1-Light Pendant (Model 20444-037) Instruction Manual

Model: 20444-037 | Brand: Eurofase

## 1. PRODUCT OVERVIEW

The Eurofase Sliver Small 1-Light Pendant, Model 20444-037, is an indoor lighting fixture designed to provide indirect halogen light. It features a hand-polished metal body and is suitable for various indoor settings such as kitchens, dining rooms, bedrooms, and living rooms.

### Key Features:

- Black finish metal body
- Indirect light source
- Requires one GU10 halogen light bulb (up to 50 watts)
- Dimmable functionality (requires compatible dimmer switch, sold separately)
- Adjustable height
- Semi-flush mount installation
- Product Dimensions: 2.75"L x 2.75"W x 12"H



Image 1.1: Front view of the Eurofase Sliver Small 1-Light Pendant in black finish.

## 2. IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before beginning installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards that could cause injury or property damage.

- **WARNING: Risk of Electric Shock.** Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National

Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring installations.

- Do not install this fixture in wet or damp locations. This product is intended for indoor use only.
- Ensure the fixture is securely mounted to a structurally sound ceiling.
- Do not exceed the maximum wattage specified for the light bulb.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Please check your local laws before purchasing this product.

### 3. PACKAGE CONTENTS

---

Carefully unpack the fixture and check that all components are present and undamaged. Retain all packaging materials until you are satisfied with the product.

- Pendant Fixture (1)
- Mounting Hardware (e.g., canopy, mounting plate, screws, wire nuts)
- Instruction Sheet (1)

*Note: Light bulb is not included and must be purchased separately.*

### 4. SETUP AND INSTALLATION

---

Assembly is required for this fixture. Due to the nature of electrical installations, it is highly recommended that a qualified, licensed electrician performs the installation.

#### Before You Begin:

1. Turn off power at the main circuit breaker or fuse box.
2. Ensure you have all necessary tools (e.g., screwdriver, wire strippers, electrical tape, ladder).
3. Review local electrical codes and requirements.

#### Installation Steps:

1. **Prepare Mounting:** Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
2. **Adjust Height:** The pendant's cord length can be adjusted. Determine the desired hanging height and secure the cord within the canopy mechanism according to the detailed instructions provided in the package.
3. **Electrical Connections:** Connect the fixture's wires to the corresponding household wires (black to black, white to white, ground to ground) using wire nuts. Ensure all connections are tight and secure.
4. **Secure Canopy:** Carefully push the canopy up to the ceiling, covering the junction box and mounting plate. Secure it in place with the provided screws or fasteners.
5. **Install Bulb:** Insert one GU10 halogen bulb (max 50W) into the socket. Do not overtighten.
6. **Restore Power:** Once installation is complete and all connections are checked, restore power at the circuit breaker.



Image 4.1: Example installation of Eurofase Sliver Pendants in a kitchen environment.

## 5. OPERATING INSTRUCTIONS

---

### Powering On/Off:

Once installed and power is restored, the pendant light can be operated via a standard wall switch. If connected to a dimmer switch, the light intensity can be adjusted.

### Dimmable Functionality:

This fixture is dimmable. To utilize this feature, ensure you have a compatible dimmer switch installed in your electrical system. Follow the dimmer switch manufacturer's instructions for operation.

## 6. CARE AND MAINTENANCE

---

Regular care will help maintain the appearance and functionality of your pendant light.

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure power is off and the bulb has cooled completely before attempting to replace it. Carefully remove the old GU10 bulb and insert a new one, ensuring it is seated correctly.

Do not exceed the maximum 50W rating.

## 7. TROUBLESHOOTING

If you experience issues with your pendant light, refer to the following common problems and solutions:

| Problem                        | Possible Cause                                                                       | Solution                                                                                                                                                     |
|--------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Light does not turn on         | No power to the fixture; Loose wiring connection; Faulty bulb; Faulty switch.        | Check circuit breaker/fuse; Verify all wire connections are secure; Replace bulb; Test switch.                                                               |
| Light flickers                 | Loose bulb connection; Incompatible dimmer switch; Loose wiring; Faulty bulb socket. | Ensure bulb is securely seated; Verify dimmer switch compatibility; Check wiring connections; If socket feels loose, professional inspection is recommended. |
| Light is too dim or too bright | Incorrect bulb wattage; Dimmer setting.                                              | Ensure bulb wattage is within specified range (max 50W); Adjust dimmer switch.                                                                               |

If the problem persists after attempting these solutions, contact a qualified electrician or Eurofase customer support.

## 8. PRODUCT SPECIFICATIONS

| Specification           | Detail                      |
|-------------------------|-----------------------------|
| Brand                   | Eurofase                    |
| Model Name              | SLIVER                      |
| Part Number             | 20444-037                   |
| Color                   | Black                       |
| Material                | Metal                       |
| Style                   | Modern                      |
| Light Fixture Form      | Pendant                     |
| Product Dimensions      | 2.75"L x 2.75"W x 12"H      |
| Indoor/Outdoor Usage    | Indoor                      |
| Power Source            | Corded Electric             |
| Installation Type       | Semi Flush Mount            |
| Special Features        | Adjustable Height, Dimmable |
| Light Source Type       | Halogen                     |
| Number of Light Sources | 1                           |

| Specification     | Detail         |
|-------------------|----------------|
| Voltage           | 120 Volts      |
| Wattage           | 50 watts (Max) |
| Bulb Base         | GU10           |
| Item Weight       | 1.94 pounds    |
| Assembly Required | Yes            |
| UPC               | 773546213271   |

## 9. WARRANTY AND CUSTOMER SUPPORT

### Warranty Information:

This Eurofase product comes with a limited manufacturer's warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions. The warranty covers defects in materials and workmanship under normal use.

### Customer Support:

For technical assistance, warranty claims, or to purchase replacement parts, please contact Eurofase customer support. You can find more information and contact details by visiting the official Eurofase store:

[Visit the Eurofase Store on Amazon](#)

© 2023 Eurofase. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**