

[Manuals.plus](#) /

› [Varta](#) /

› Varta 18682 LED Hand Flashlight User Manual

Varta 18682

Varta 18682 LED Hand Flashlight User Manual

Model: 18682

1. INTRODUCTION

Thank you for choosing the Varta 18682 LED Hand Flashlight. This manual provides essential information for the safe and efficient use of your new device. Please read this manual thoroughly before operation and retain it for future reference.



Image 1: The Varta 18682 LED Hand Flashlight, a robust black plastic device with a large LED lens and an integrated handle, designed for portable illumination.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following safety precautions:

- Do not look directly into the LED light. The intense light can cause temporary vision impairment or eye damage.
- Keep the flashlight away from water and excessive moisture. This product is not waterproof.
- Do not attempt to disassemble or modify the flashlight. This may void the warranty and pose a safety risk.
- Store the flashlight in a cool, dry place when not in use.
- Keep out of reach of children.
- Use only the specified charging method for the integrated rechargeable battery.

3. PRODUCT OVERVIEW

The Varta 18682 is a powerful and durable LED hand flashlight designed for various applications. Key features include:

- **Rechargeable Design:** Equipped with an integrated battery for convenient recharging.
- **High-Performance LED:** Features a 3W LED light source for bright illumination.
- **Durable Construction:** Made from robust plastic material.
- **Ergonomic Handle:** Designed for comfortable and secure grip.

4. SETUP

Before first use, it is recommended to fully charge the flashlight's internal battery.

1. Locate the charging port on the flashlight.
2. Connect the appropriate charging cable (not specified in product details, assume standard USB or AC adapter) to the flashlight and a power source.
3. Allow the flashlight to charge until the charging indicator (if present, not specified) shows a full charge, or for the recommended duration as per the charger's instructions.
4. Disconnect the charging cable once charging is complete.

5. OPERATION

Operating the Varta 18682 LED Hand Flashlight is straightforward:

- **Turning On/Off:** Locate the power button, typically positioned near the handle. Press the button once to turn the flashlight on. Press it again to turn the flashlight off.
- **Light Modes:** (If applicable, not specified) Some flashlights may have multiple light modes (e.g., high, low, strobe). Repeatedly pressing the power button may cycle through these modes. Refer to specific product labeling if multiple modes are present.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your flashlight:

- **Cleaning:** Wipe the exterior of the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the flashlight in a cool, dry place. It is advisable to partially charge the battery every few months to maintain its health.
- **Battery Care:** Avoid fully discharging the battery frequently, as this can reduce its lifespan. Recharge the flashlight when the light output noticeably diminishes.

7. TROUBLESHOOTING

If you encounter issues with your Varta 18682 LED Hand Flashlight, refer to the table below:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is discharged.	Charge the flashlight fully.
Light is dim.	Low battery charge.	Recharge the flashlight.
Flashlight does not charge.	Charging cable or adapter is faulty; charging port is dirty.	Try a different charging cable/adapter. Clean the charging port gently.

8. SPECIFICATIONS

Detailed technical specifications for the Varta 18682 LED Hand Flashlight:

Feature	Specification
Model Number	18682
Light Source Type	LED (3W)
Brightness	150 Lumens
Power Source	Rechargeable Battery
Material	Plastic
Dimensions (L x W x H)	13 x 32 x 25 cm
Weight	1.51 kg (3.33 lbs)

9. WARRANTY AND SUPPORT

Varta products are manufactured to high quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Varta website.

For technical support, troubleshooting assistance beyond this manual, or spare parts, please contact Varta customer service through their official channels. Contact information can typically be found on the product packaging or the Varta website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B004RPMFZM>

More documents and user manuals: **<https://manuals.plus/>**