



Manuals.plus /

› X-Acto /

› X-Acto X411 No. 11 Nonrefillable Blade Dispenser Instruction Manual

X-Acto X411

X-Acto No. 11 Classic Fine Point Blades Dispenser (Model X411)

Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective use of your X-Acto No. 11 Classic Fine Point Blades Dispenser, Model X411. This product offers a safe and convenient way to store, dispense, and dispose of X-Acto No. 11 precision blades. Each dispenser contains 15 precision-crafted carbon blades designed for various delicate tasks. The dispenser is non-refillable and includes a dedicated slot for used blade disposal.

SAFETY INFORMATION

WARNING: X-ACTO blades are extremely sharp. Improper handling can result in severe injury.

- Always handle blades with extreme caution.
- Wear safety goggles to protect your eyes from potential blade fragments or debris.
- Keep out of reach of children and pets.
- Do not attempt to sharpen or modify blades.
- Ensure blades are securely attached to a compatible X-Acto handle before use.
- Dispose of used blades immediately and safely in the designated slot on the dispenser or a proper sharps container.

PRODUCT OVERVIEW



Figure 1: X-Acto No. 11 Classic Fine Point Blades Dispenser, Model X411, showing the packaging with product details and safety warnings.

The X-Acto X411 dispenser is designed for convenience and safety. It features a mechanism to dispense new blades one at a time and a separate, secure slot for the disposal of used blades. The dispenser is clearly marked with the blade type (No. 11 Classic Fine Point) and quantity (15 blades).

SETUP

The X-Acto X411 dispenser comes pre-loaded with 15 No. 11 blades and requires no assembly. Simply remove the dispenser from its packaging. Ensure you have a compatible X-Acto knife handle (Type A handle recommended) ready for blade attachment.

OPERATING INSTRUCTIONS

1. Dispensing a New Blade

1. Locate the dispensing mechanism on the X411 dispenser. This is typically a sliding tab or button.

2. Carefully slide the tab or press the button to expose a single new No. 11 blade.
3. Using a compatible X-Acto knife handle, securely grasp the base of the exposed blade. Refer to your knife handle's instructions for proper blade insertion.
4. Once the blade is firmly attached to the handle, retract the dispensing mechanism to ensure no other blades are exposed.

2. Using the Blade

X-Acto No. 11 Classic Fine Point Blades are ideal for:

- Delicate precision cutting
- Detailing
- Trimming
- Stripping

These blades are suitable for working with materials such as paper, plastic, balsa wood, and basswood. Always use a cutting mat and apply appropriate pressure for the material being cut.

3. Disposing of Used Blades

The X411 dispenser features a dedicated slot for safe disposal of used blades. This slot is designed to prevent accidental contact with sharp edges.

1. Carefully remove the used blade from your X-Acto knife handle.
2. Locate the used blade disposal slot on the dispenser.
3. Insert the used blade into the slot, ensuring it slides completely inside the dispenser.
4. Once all 15 blades have been used and disposed of, the entire non-refillable dispenser should be discarded according to local regulations for sharp objects.

MAINTENANCE

The X-Acto X411 dispenser is a non-refillable unit and requires minimal maintenance. Keep the dispenser clean and free of debris. Store it in a dry, safe place away from direct sunlight and extreme temperatures. Do not attempt to open or disassemble the dispenser, as this may compromise its safety features.

TROUBLESHOOTING

Blade Does Not Dispense:

- Ensure the dispensing mechanism is fully engaged.
- Check if the dispenser is empty. The dispenser holds 15 blades; once depleted, it will no longer dispense.
- Do not force the mechanism. If a blade is stuck, gently tap the dispenser on a hard surface to dislodge it. If the issue persists, the dispenser may be faulty and should be discarded safely.

Used Blade Slot Appears Jammed:

- Ensure you are inserting only one blade at a time.
- Do not attempt to retrieve blades from the disposal slot. This is a safety hazard.
- If the slot is completely blocked, the dispenser should be discarded safely.

SPECIFICATIONS

Model:	X411
Blade Type:	No. 11 Classic Fine Point
Blades per Dispenser:	15
Dispenser Type:	Nonrefillable
Product Dimensions:	5.35 x 2.45 x 0.8 inches
Weight:	0.8 ounces
Manufacturer:	ELMERS PRODUCT INC

WARRANTY INFORMATION

Specific warranty details for the X-Acto X411 No. 11 Nonrefillable Blade Dispenser are not provided in this manual. For information regarding product warranty, please refer to the product packaging or contact X-Acto customer support directly.

SUPPORT

For further assistance or inquiries regarding your X-Acto product, please visit the official X-Acto website or contact their customer service department. Contact information is typically available on the manufacturer's website or product packaging.

