

Leitmotiv LM665

Leitmotiv Melange Grande Pendant Lamp LM665

User Manual

1. INTRODUCTION

Thank you for purchasing the Leitmotiv Melange Grande Pendant Lamp, Model LM665. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read this manual thoroughly before installation and retain it for future reference.

This pendant lamp is designed for indoor use only and requires hardwired electrical installation. It features a distinctive design by BOX32 and is intended to be a central lighting element in your living space.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these safety precautions:

- Always disconnect power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.
- Installation should be performed by a qualified electrician or a competent person familiar with electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.
- Use only E27 bulbs with a maximum wattage of 40W per bulb. Do not exceed the recommended wattage.
- This fixture is for indoor use in dry locations only. Do not expose to water or moisture.
- Do not connect this fixture to an ungrounded electrical system.
- Avoid touching the bulbs directly with bare hands during operation or immediately after turning off, as they can be hot.
- Keep flammable materials away from the lamp.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before installation. If any parts are missing or damaged, contact your retailer.

- Leitmotiv Melange Grande Pendant Lamp fixture (Model LM665)
- Mounting hardware (ceiling plate, screws, wire connectors)
- Instruction Manual

Note: E27 light bulbs are not included and must be purchased separately.

4. SETUP AND INSTALLATION

This lamp requires hardwired installation to a ceiling electrical box. Professional installation is recommended.

1. Prepare for Installation:

- Turn off the power at the circuit breaker or fuse box to the outlet box where you will install the fixture.
- Ensure the power is off by testing the circuit with a voltage tester.
- Unpack the fixture and its components carefully.

2. Mount the Ceiling Plate:

- Attach the mounting plate to the ceiling electrical box using the screws provided. Ensure it is securely fastened.

3. Wire the Fixture:

- Connect the fixture's wires to the corresponding wires from the ceiling electrical box using the wire connectors.
- Connect the black wire (live) from the fixture to the black wire (live) from the ceiling.
- Connect the white wire (neutral) from the fixture to the white wire (neutral) from the ceiling.
- Connect the green or bare copper wire (ground) from the fixture to the ground wire from the ceiling or the ground screw on the mounting plate.
- Ensure all connections are secure.

4. Secure the Fixture:

- Carefully tuck all wires into the electrical box.
- Attach the lamp fixture to the mounting plate, securing it with the provided screws or decorative nuts.

5. Install Light Bulbs:

- Screw ten (10) E27 base light bulbs (not included) into the lamp sockets. Ensure bulbs are no more than 40W each.

6. Restore Power:

- Turn the power back on at the circuit breaker or fuse box.
- Test the lamp by turning it on with your wall switch.



Image of the Leitmotiv Melange Grande Pendant Lamp (Model LM665) in white, showcasing its design and how it appears when installed.

5. OPERATING INSTRUCTIONS

The Leitmotiv Melange Grande Pendant Lamp is operated via a standard wall switch connected to its electrical circuit. There are no integrated controls on the fixture itself.

- **Turning On/Off:** Use the wall switch connected to the lamp's circuit to turn the light on or off.
- **Bulb Replacement:**
 - a. Ensure the lamp is turned off at the wall switch and the power is disconnected at the circuit breaker.
 - b. Allow bulbs to cool completely before touching.
 - c. Carefully unscrew the old E27 bulb.
 - d. Screw in a new E27 bulb, ensuring it does not exceed 40W.
 - e. Restore power and test.

6. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your lamp.

- **Cleaning:**
 - Always turn off the lamp and disconnect power before cleaning.
 - Allow the fixture to cool down.
 - Wipe the lamp with a soft, dry, or slightly damp cloth.

- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- This fixture is not water resistant; do not spray water directly onto it.
- **Inspection:** Periodically check the wiring and connections for any signs of wear or damage. If any issues are found, consult a qualified electrician.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up.	• Power is off at the switch or circuit breaker. • Bulb(s) are loose or burnt out. • Incorrect wiring.	• Check the wall switch and circuit breaker. • Tighten or replace bulbs. • Consult a qualified electrician to check wiring.
Lamp flickers.	• Loose bulb connection. • Faulty bulb. • Loose wiring connection.	• Tighten bulbs. • Replace faulty bulb(s). • Consult a qualified electrician to check wiring.

8. SPECIFICATIONS

Brand:	Leitmotiv
Model:	LM665
Designer:	BOX32 Design
Color:	White
Material:	Metal
Dimensions:	Diameter: 60 cm, Max Height: 150 cm
Bulb Type:	E27 (10 bulbs required, not included)
Max Wattage:	40W per bulb
Voltage:	230V
Installation Type:	Hardwired, Ceiling Mount, Semi-flush mount
Control Method:	Wall Switch
Usage:	Indoor only
Water Resistance:	Not water resistant
Item Weight:	491 Grams (approx. 1.08 lbs)

9. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase. If you require technical support or have questions regarding your Leitmotiv Melange Grande Pendant Lamp, please contact your point of purchase or the manufacturer, Present Time GmbH, for assistance.

Please have your model number (LM665) and proof of purchase ready when contacting support.

© 2023 Leitmotiv. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question