

Mr. Christmas 39691

Mr. Christmas Goodnight Lights Santa Ornament Controller (Model 39691) Instruction Manual

Breath-Activated Christmas Tree Light Controller

1. INTRODUCTION

The Mr. Christmas Goodnight Lights Santa Ornament Controller (Model 39691) offers a convenient and festive method for managing your Christmas tree lights. This unique ornament features a breath-activated sensor that allows you to effortlessly turn your tree lights on and off, eliminating the need to manually plug and unplug cords.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe operation and prevent damage to the product or injury.

- Keep this product out of reach of children and pets.
- Do not use near open flames or direct heat sources.
- Do not immerse the ornament or control box in water or expose to excessive moisture.
- Use only as intended for controlling Christmas tree lights.
- Do not attempt to modify or repair the device. Unauthorized modifications may void the warranty and pose safety risks.
- Discontinue use immediately if the product appears damaged or malfunctions.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Mr. Christmas Goodnight Lights Santa Ornament
- Control Box Adapter

4. SETUP INSTRUCTIONS

Follow these steps to set up your Santa Ornament Controller:

1. **Unpack Components:** Carefully remove the Santa ornament and the control box adapter from their

packaging.

2. **Connect Tree Lights:** Locate the control box on the adapter cord. Plug your Christmas tree lights (with a maximum total wattage of 420W) directly into the receptacle on the control box.
3. **Power Connection:** Plug the control box adapter into a standard, functional electrical wall outlet.
4. **Hang Ornament:** Hang the Santa ornament on a branch of your Christmas tree. Position it in an easily accessible location where you can comfortably blow into the candle.





Image 1: The Santa ornament and its control box, demonstrating how Christmas tree lights plug into the control unit.



Image 2: The Santa ornament hanging on a decorated Christmas tree, ready for operation.

5. OPERATING INSTRUCTIONS

The Santa Ornament Controller uses a breath-activated sensor for operation:

- **To Turn Lights On/Off:** Gently blow into the candle held by the Santa ornament. The integrated motion sensor will detect the airflow and toggle the power to the Christmas tree lights connected to the control box.

Video 1: An official demonstration of the Mr. Christmas Goodnight Lights Santa Ornament Controller, showing how to activate the lights by blowing into the candle.

6. MAINTENANCE

Proper care will extend the life of your ornament:

- **Cleaning:** Gently wipe the Santa ornament and control box with a soft, dry cloth. Do not use abrasive cleaners, solvents, or excessive moisture, as these can damage the finish or electronic components.
- **Storage:** When not in use, store the ornament and control box in their original packaging or a protective container in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Santa Ornament Controller, refer to the following common problems and solutions:

- **Lights Not Turning On/Off:**
 - Ensure the control box adapter is securely plugged into a live electrical outlet.
 - Verify that your Christmas tree lights are properly plugged into the control box.
 - Check that the total wattage of your connected lights does not exceed the maximum capacity of 420W.
 - Confirm you are blowing directly and firmly into the candle on the Santa ornament.
 - Inspect all cords and the ornament for any visible damage.

8. SPECIFICATIONS

Product Dimensions	3.6 x 3 x 5.6 inches
Item Weight	1.1 pounds
Manufacturer	Mr. Christmas
Item Model Number	39691
Material	Plastic
Maximum Load	420W (for connected lights)
Batteries Required	No

5.6"









3.7"

Image 3: The Santa ornament with its approximate height and width dimensions indicated.

9. WARRANTY AND SUPPORT

Warranty information for the Mr. Christmas Goodnight Lights Santa Ornament Controller (Model 39691) is not provided in the available product details. For specific warranty terms, technical assistance, or customer support, please contact Mr. Christmas customer service directly through their official website or contact channels.

Related Documents - 39691

	<p>Mr. Christmas Climbing Santa Instruction Manual</p> <p>Detailed instructions for setting up, operating, and troubleshooting the Mr. Christmas Climbing Santa animated holiday decoration. Includes safety warnings and warranty information.</p>
	<p>Mr. Christmas Alexa LED 300 Icicle Lights - Instruction Manual & Setup Guide</p> <p>Detailed instructions for the Mr. Christmas Alexa LED 300 Icicle Lights (Item # 68328). This guide covers unboxing, setup, connecting to Amazon Alexa, manual control, creating routines, troubleshooting connectivity issues, and important safety precautions for indoor use.</p>
	<p>Mr. Christmas Alexa Bistro Light: Smart LED String Lights Instruction Manual & Setup Guide</p> <p>This instruction manual provides comprehensive guidance for the Mr. Christmas Alexa Bistro Light (Model No: E308678). Learn how to set up, connect to Amazon Alexa, control lighting modes via voice or manually, automate with routines, troubleshoot connectivity issues, and adhere to important safety instructions. Suitable for indoor and outdoor use, these smart LED string lights offer customizable colors, festive patterns, and adjustable brightness.</p>
	<p>Mr. Christmas 6.5ft RGB Alexa Christmas Tree (Item # 68323) - Instruction Manual</p> <p>Comprehensive instruction manual for the Mr. Christmas 6.5ft RGB Alexa-enabled Christmas Tree (Item # 68323). Learn how to assemble, set up with Alexa, control lighting modes, and troubleshoot common issues.</p>
	<p>Mr. Christmas Alexa LED 300 Mini Lights Instruction Manual</p> <p>Comprehensive instruction manual for the Mr. Christmas Alexa LED 300 Mini Lights (Item # 68327). Learn how to set up, connect to Alexa, control modes manually or via voice, automate with routines, troubleshoot connectivity issues, and follow important safety guidelines.</p>
	<p>Mr. Christmas RGB Christmas Pathway Tree Instruction Manual</p> <p>Instruction manual for the Mr. Christmas RGB Christmas Pathway Tree (Item # 68326), detailing assembly, setup, Alexa integration, manual controls, and troubleshooting.</p>