Tommy Bahama 735645

Tommy Bahama All Terrain Beach Cart Instruction Manual

Model: 735645
Brand: Tommy Bahama

Introduction

Thank you for choosing the Tommy Bahama All Terrain Beach Cart. This manual provides essential information for the safe and efficient use, assembly, and maintenance of your new beach cart. Please read these instructions carefully before using the product and retain them for future reference.



Image: The Tommy Bahama All Terrain Beach Cart, loaded with beach essentials, positioned on a sandy beach.

Product Features

The Tommy Bahama All Terrain Beach Cart is designed for convenience and durability, making your beach trips effortless. Key features include:

- **High Capacity:** Capable of holding up to 4 beach chairs, a full-size 48-quart cooler, and additional beach gear.
- **Insulated Storage:** Features a removable insulated cargo bag with zippered side pouches for keeping items cool and organized.
- **All-Terrain Wheels:** Equipped with 10-inch extra-wide rear wheels and dual-steer front wheels for easy navigation across various surfaces, including sand.
- **Weight Capacity:** Supports a maximum load of 100 lbs.
- **Compact Storage:** Designed to fold flat for convenient storage and transport.
- **Umbrella Holder:** Integrated holder for securing a beach umbrella.
- **Durable Construction:** Built with a powder-coated steel frame and durable mesh fabric that dries quickly.
- **Cushioned Handle:** Provides a comfortable grip during transport.

Setup Instructions

The Tommy Bahama All Terrain Beach Cart comes mostly pre-assembled and is designed for quick setup.

1. **Unfolding the Cart:** Place the folded cart on a flat, stable surface. Gently pull the main frame sections apart until the cart fully extends and locks into its open position. Ensure all locking mechanisms are securely engaged.
2. **Attaching the Cargo Bag:** If removed for storage, reattach the insulated cargo bag to the designated hooks or straps on the cart frame.
3. **Inspecting Wheels:** Verify that all four wheels are securely attached and can rotate freely.



Image: The Tommy Bahama All Terrain Beach Cart shown in its folded configuration, ready for compact storage.

Operating Instructions

To ensure optimal performance and longevity of your beach cart, follow these operating guidelines:

1. **Loading the Cart:** Distribute weight evenly within the mesh basket and on the chair rack. Place heavier items at the bottom. The cart can accommodate up to four beach chairs on its dedicated rack.
2. **Using the Umbrella Holder:** Secure your beach umbrella in the integrated holder to prevent it from shifting during transport.
3. **Navigating on Sand:** For soft, deep sand, it is recommended to pull the cart backwards, utilizing the larger rear wheels for better traction and easier movement. On packed sand or harder surfaces, the cart can be pushed or pulled forward.
4. **Weight Limit:** Do not exceed the maximum weight capacity of 100 lbs to prevent damage to the cart and ensure safe operation.



Image: The beach cart loaded with multiple beach chairs, a cooler, and various beach accessories, demonstrating its capacity.



Image: A person pulling the Tommy Bahama All Terrain Beach Cart across a sandy beach, showcasing its maneuverability.

Maintenance

Regular maintenance will extend the life of your Tommy Bahama All Terrain Beach Cart:

- **Cleaning:** After each use, especially after exposure to saltwater and sand, rinse the cart thoroughly with fresh water. Allow it to air dry completely before folding and storing.
- **Lubrication:** Periodically check and lubricate moving parts, such as wheel axles and folding joints, with a silicone-based spray to ensure smooth operation and prevent corrosion.
- **Storage:** Store the cart in a dry, cool place away from direct sunlight when not in use. Folding the cart flat will save space.
- **Inspection:** Regularly inspect the frame, fabric, and wheels for any signs of wear, damage, or loose components. Tighten any loose screws or bolts as needed.

Troubleshooting

If you encounter issues with your beach cart, refer to the following common solutions:

- **Difficulty Rolling on Soft Sand:** If the front wheels sink into soft sand, try pulling the cart backwards. The larger rear wheels are designed for better flotation and easier movement in challenging sandy conditions.
- **Stiff Folding Mechanism:** Ensure all sand and debris are cleared from the joints. Apply a small amount of lubricant to the folding points if necessary.
- **Unstable Load:** Redistribute items to balance the weight. Ensure heavy items are placed low and centered. Secure all items with bungee cords or straps if needed (not included).

Specifications

Product Dimensions (Open)	40"D x 27"W x 31"H
Product Dimensions (Folded)	27"W x 32"L x 10"D
Brand	Tommy Bahama
Material	Alloy Steel (Frame), Durable Mesh Fabric
Color	Royal Blue
Special Feature	Foldable
Recommended Uses	Outdoor, Beach, Camping, Picnic
Handle Material	Plastic (Cushioned)
Tire Type	Tubeless, 10" Extra Wide Rear Wheels
Item Weight	17 Pounds
Number of Wheels	4
Weight Limit	100 Pounds
Assembly Required	Yes (Minimal)
Item Model Number	735645

Warranty and Support

For warranty information or product support, please contact Tommy Bahama customer service. Details regarding specific warranty terms and conditions may be available on the official Tommy Bahama website or through your retailer.

Always refer to the manufacturer's official channels for the most accurate and up-to-date support information.